

Powered by Trust™

 **Bharat Bijlee**

BBVERT **BL52** Series



USER MANUAL

Table of Contents

| | |
|--|------------|
| Chapter 1 Safety | 1 |
| 1.1 General Safety | 1 |
| 1.2 Warning Label | 3 |
| 1.3 AC Drive Application Precautions | 3 |
| 1.4 Warranty | 5 |
| Chapter 2 Product | 6 |
| 2.1 Component Names | 6 |
| 2.2 Receiving Checklist | 13 |
| 2.3 Nameplate | 13 |
| 2.4 Model Number Definition | 14 |
| 2.5 Power Ratings | 14 |
| 2.6 Common Specifications | 16 |
| 2.7 Product Dimensions | 18 |
| 2.8 Options | 29 |
| Chapter 3 Drive Installation | 31 |
| 3.1 Installation Environment | 31 |
| 3.2 Installation Direction and Spacing | 32 |
| 3.3 Keypad and Terminal Cover Installation | 34 |
| 3.4 Wiring Protection | 35 |
| 3.5 Keypad Remote Usage | 35 |
| Chapter 4 Wiring | 40 |
| 4.1 Wiring Safety | 40 |
| 4.2 Main Circuit | 41 |
| 4.3 Control Circuit | 48 |
| 4.4 I/O Connections | 57 |
| 4.5 Connection to PC | 61 |
| 4.6 Wiring Checklist | 62 |
| Chapter 5 Keypad | 63 |
| 5.1 Keypad | 63 |
| 5.2 Parameter List | 69 |
| Chapter 6 Troubleshooting | 116 |
| 6.1 Alarm And Fault Displays | 116 |
| 6.2 Fault Detection | 121 |
| 6.3 Operation Errors | 129 |
| 6.4 Auto-Tuning Fault Detection | 131 |
| Chapter 7 Communications | 132 |
| 7.1 Modbus Communication Specifications | 132 |
| 7.2 Connecting to Controller/PLC/HMI | 132 |
| 7.3 Modbus Data | 134 |

Chapter 1 | Safety

1.1 General Safety

Safety Information :

Caution : Identifies information about practices or circumstances that can cause personal injury or equipment damage.

Warning : Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

1.1.1 Usage

Caution

- The drive is used to control the speed of 3 phase synchronous and asynchronous motors, which must not be used for single phase or other purposes. Failure to comply could cause drive damage or serious injury by fire.
- The drive must not be used in any medical equipment in which human life may involve.
- The drive is manufactured according to strict quality control standard. However, bypass the safety protection in case the drive failure causes death or serious injury.

1.1.2 Receiving

Warning

- Do not install damaged drive or any drive without complete components inside. Failure to comply could result in accident.
- The product must be complete, including packaging, instruction and accessories.

1.1.3 Installation

Warning

- Carry the drive by the bottom as carrying by the front cover may cause injury and damage from the main body of the drive falling.
- Attach the drive to metal or other nonflammable materials. Keep away from heat and flammable items.
- A control panel must have cooling fans, air vents and room for ventilation when the drive is installed inside.
- The mounting surface in contact with the heat sink should be made of metal, which provides good thermal conductivity and prevents flammability.
- Please check the dust-proof and moisture-proof conditions to avoid the external environment affecting the inverter function.

1.1.4 Wiring

Caution

- Allow only qualified electrical engineers to install the drive. Failure to comply could cause electrical shocks to personnel or damage to the drive.
- Ensure the power supply is off when connecting. Failure to comply could cause electrical shocks.
- Ensure the ground terminal PE is properly wired. Failure to comply could cause electrical shocks from the drive cover. Therefore ground the drive and motor for personnel safety.
- Do not touch the main circuit terminal. Keep the main circuit off drive cover to avoid electrical shocks.
- The terminal for braking resistor is B1 and B2. Do not connect it to any other terminals. Failure to comply could cause a fire.


Warning

- Do not connect three-phase power supply to terminals U, V and W. Failure to comply could damage the drive.
- An output reactor is recommended when the cable connecting between the drive and motor is over 100 meters. Failure to comply could result in drive damage with over-current caused by over-distributed capacitance.
- Never connect the output terminals to capacitors or unapproved LC/RC filters. Failure to comply could damage the drive components.
- Separate the drive main circuit cables and control circuit cables. Failure to comply could cause interference to the control signals
- Ensure the phase of power supply and rated voltage match the label on the drive. Failure to comply could drive damage.

1.2 Warning Label

The warning label is on the front of the drive. Please read it carefully and follow the instructions.

- Read the user manual before operation.
- Risk of electrical shock. Shut off main power and wait for 5 minutes before servicing.
- Hot surface. Risk of burn.



1.3 AC Drive Application Precautions

1.3.1 AC Drive Selection

1.3.1.1 Drive Capacity

Before driving motors, ensure the motor rated current is lower than the drive rated output. In addition, when a single AC drive is driving more than 1 motor in parallel, make sure the drive capacity is higher than 110% of total motor rated current.

1.3.1.2 Starting Torque

The motor characteristics at start and during acceleration are limited by the drive overcurrent. If higher starting torque is needed, use a higher rating drive or increase capacity of both motor and drive.

1.3.1.3 Emergency Stop

When a drive fault occurs, protection function will be automatically triggered to shut off the output but the motor may not stop immediately. Therefore please install mechanical brake if immediate stop is necessary.

1.3.2 Settings

1.3.2.1 Upper Limits

The maximum output frequency of the drive is 400Hz. If the upper limit is set incorrectly, the motor will run at higher than its rated speed and cause danger. Please set the limit of output frequency in Frequency Upper Limit parameter. The default setting of the rated output frequency is 60Hz.

1.3.2.2 DC Braking

Excessive DC braking current and duration could cause motor overheat.

1.3.2.3 Acceleration /Deceleration Time (Acc./Dec. Time)

Acceleration and deceleration time is determined by the motor torque, load torque and load inertia. Set a longer Acc./Dec. time after Stall Prevention function is triggered. In addition, the acceleration and deceleration time will be extended depending on the Stall Prevention duration. If faster acceleration and deceleration are required, install proper braking options or use a higher rating motor and AC drive.

1.3.3 General Handling

1.3.3.1 Wiring

Connecting power supply to output terminals U/T1, V/T2 and W/T3 will damage the drive. Check all the connections and wiring sequence before turning on the power. Failure to comply could cause drive damage.

1.3.3.2 Maintenance

Capacitors in the drive may still be charged for a short time after shutting off the power. Wait for the amount of time specified on the drive before any maintenance. Failure to comply could cause electrical shocks to personnel. Besides, do not touch the heatsink which can be very hot during operation. Replace the cooling fan only when the heatsink has cooled down after shutting off the power. In addition, when a synchronous motor is coasting to stop, it regenerates voltage to keep the drive terminals live even when the drive power is off. Wait until the motor is fully stopped before drive maintenance. Failure to comply could cause electrical shocks to personnel.

1.3.3.3 Wiring Tools

Use only the tools suggested by the terminal supplier during drive maintenance.

1.3.3.4 Transportation and installation

Do not expose the drive to the environment containing the halogens or DOP gas during transportation or installation.

1.4 Warranty

1.4.1 Warranty Period

Contact Bharat Bijlee / Drives Sales Partner for details.

1.4.2 Warranty Restrictions

Warranty is not applicable when the drive is not properly used according to the manual regardless warranty period.


Chapter 2 | Product

2.1 Component Name

This section illustrates each components of the drive.

2.1.1 IP20 Enclosure

Frame 1




- A - Heatsink
- B - Conduit bracket
- C - Rubber bushing
- D - Cooling fan
- E - Cooling fan guard

- F - Terminal cover screw
- G - Conduit screw
- H - Front cover
- I - Front cover screw
- J - Terminal cover

- K - Keypad

Frame 2




A - Heatsink
B - Conduit bracket
C - Rubber bushing
D - Cooling fan
E - Cooling fan guard

F - Terminal cover screw
G - Conduit screw
J - Terminal cover

K - Keypad

Frame 3




A - Heatsink
B - Conduit bracket
C - Rubber bushing
D - Cooling fan
E - Cooling fan guard

F - Terminal cover screw
G - Conduit screw
H - Front cover
I - Front cover screw
J - Terminal cover

K - Keypad

Frame 4




A - Heatsink
B - Wiring outlet cover
C - Wiring outlet plug
D - Cooling fan
E - Fan cover

F - Front wiring cover mounting screw
G - Wiring outlet cover mounting screws
H - Front upper cover
I - Front upper cover mounting screws
J - Front wiring cover

K - Keypad

Frame 5




A - Heatsink
B - Wiring outlet cover
C - Wiring outlet plug
D - Cooling fan
E - Fan cover

F - Front wiring cover mounting screw
G - Wiring outlet cover mounting screws
H - Front upper cover
I - Front upper cover mounting screws
J - Front wiring cover

K - Keypad

Frame 6




A - Cooling fan
B - Fan cover

C - Front upper cover
D - Front upper cover mounting screw

E - Operating keyboard
F - Front wiring cover

Frame 7



A - Cooling fan
B - Fan cover

C - Front upper cover
D - Front upper cover mounting screw


E - Operating keyboard
F - Front wiring cover

2.2 Receiving Checklist

Check the following when receiving the drive :

- | | |
|----|--|
| 1. | Is the packaging box in good condition? Any damage or damp ? If so, contact the distributor or local BBL representative. |
| 2. | Is the model label on the box same as what you purchased? If not, contact the distributor or local BBL representative. |
| 3. | After opening the box, is there any damp mark inside the box? Any damage or crack on the drive enclosure? If so, contact the distributor or local BBL representative. |
| 4. | Does the drive nameplate show the same model number as the carton label? If not, contact the distributor or local BBL representative. |
| 5. | Is keypad in the carton? If not, contact the distributor or local BBL representative. |

2.3 Nameplate



Model number →
Input power supply →
Output power supply →
Applicable motor rating →

MODEL : BL52-407P5-H3-E20
INPUT : AC 3PH, 380-480 V, 25.1A
OUTPUT : AC 2PH, 0...Uin, 18.5A, 0 - 599Hz
AC MOT : 11kW
SERIAL NO. : 12H7P5433D19330040
Customer service contact +91 22-27637290 service@bharatbijlee.com




Bharat Bijlee

BL52



2.4 Model Number Definition



* : Under Development

2.5 Power Ratings

| 400V Class | | | | | | | | | | | | | | | | | | | | | |
|---------------------|-------------------------|--|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|-----|--|
| Model No. | BL52 | 0P40 | 0P75 | 01P5 | 02P2 | 03P7 | 05P5 | 07P5 | 011P | 015P | 018P | 022P | 030P | 037P | 045P | 055P | 075P | 090P | 110 | | |
| Max. Motor Capacity | HP | HD | 0.5 | 1 | 2 | 3 | 5 | 7.5 | 10 | 15 | 20 | 25 | 30 | 40 | 50 | 60 | 75 | 100 | 125 | 150 | |
| | | ND | 1 | 2 | 3 | 5 | 7.5 | 10 | 15 | 20 | 25 | 30 | 40 | 50 | 60 | 75 | 100 | 125 | 150 | 175 | |
| | kW | HD | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | |
| | | ND | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 10 | 132 | |
| Rated Input | Voltage/ Frq | three phase, 380~480 V, -15% ~ +10%, 50/60Hz | | | | | | | | | | | | | | | | | | | |
| | Current | (ND) | 2.8 | 5 | 6.5 | 9.6 | 15.2 | 20.4 | 34 | 42 | 45.6 | 54 | 78 | 93.6 | 102 | 125 | 150 | 180 | 210 | 250 | |
| Rated Output | Current | (ND) | 2.3 | 4.1 | 5.4 | 8 | 12.6 | 17 | 25 | 31 | 38 | 45 | 60 | 72 | 92 | 115 | 150 | 180 | 215 | 248 | |
| | | (HD) | 1.8 | 3.4 | 4.2 | 5.5 | 9.5 | 12.6 | 18.5 | 25 | 32 | 38 | 45 | 60 | 75 | 92 | 115 | 150 | 180 | 215 | |
| | Output Frequency(Hz) | 0~400 Hz | | | | | | | | | | | | | | | | | | | |
| | Carrier Frequency (kHz) | 2~12 | | | | | 2~15 | | | | | 2~12 | | | | | 2~10 | | | | |
| Cooling Method | Fan | | | | | | | | | | | | | | | | | | | | |
| Frame Size | 1 | | | 2 | | | 3 | | | 4 | | | 5 | | | 6 | | | 7 | | |

| 200V class*1 | | | | | | | | | | | |
|------------------------------|-------------------------|----|---|------|------|------|------|------|------|------|------|
| Model No. | BL52 | | 0P40 | 0P75 | 01P5 | 02P2 | 03P7 | 05P5 | 07P5 | 011P | 015P |
| Max. Motor Capacity | HP | HD | 0.5 | 1 | 2 | 3 | 5 | 7.5 | 10 | 15 | 20 |
| | | ND | 1 | 2 | 3 | 5 | 7.5 | 10 | 15 | 20 | 25 |
| | kW | HD | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 |
| | | ND | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 |
| Voltage (V) / Frequency (Hz) | | | Three phase , 200V ~ 240V , -15% ~ +10% , 50/60Hz | | | | | | | | |
| Rated Output | Current | HD | 4 | 6.4 | 8 | 12 | 17.5 | 25 | 33 | 47 | 60 |
| | | ND | 5 | 8 | 10 | 15 | 22 | 30 | 40 | 56 | 65 |
| | Output Frequency(Hz) | | 0 ~ 400 Hz | | | | | | | | |
| | Carrier Frequency (kHz) | | 2 ~ 15 kHz | | | | | | | | |
| Cooling Method | | | Fan | | | | | | | | |
| Frame size | | | 1 | | | 2 | | 3 | | 4 | |

2.6 Common Specifications

| | Item | Specification |
|------------------------|---|--|
| Control Characteristic | Control Method | V/F, Sensorless Voltage Vector Control (SVVC) |
| | Output Frequency | 0 to 400 Hz |
| | Frequency Accuracy | Digital Input: Within $\pm 0.01\%$ of the max. output frequency |
| | | Analog Input: Within $\pm 0.1\%$ of max. output frequency (-10°C to $+50^{\circ}\text{C}$) |
| | Frequency Setting Resolution | Digital Input : 0.01Hz |
| | | Analog Output: 1/1000 of max. frequency |
| | Starting Torque ^{*1} | 150% / 1.5Hz (V/F) |
| | | 150% / 0.5Hz (IM Sensorless Voltage Vector Control) |
| | Speed Control Range ^{*1} | 1: 40 (V/F) |
| | | 1:120 (IM Sensorless Voltage Vector Control) |
| | Speed Control Accuracy ^{*1} | $\pm 3\%$ (Sensorless Voltage Vector Control) |
| | Speed Response | Over 5Hz (Sensorless Voltage Vector Control) |
| | Acc/Dec Time | 0.0 to 6000.0 sec |
| | Braking Torque | Approx. 20% |
| Filter | Options C2 ($\leq 20\text{kW}$) · C3 ($\geq 20\text{kW}$) | |
| V/F Pattern | 15 fixed patterns and 1 programmable pattern | |
| Overload Capacity | 120% for 1 min. in every 10 min. (Normal Duty) | |
| | 150% for 1 min. in every 10 min. (Heavy Duty) 180% for 10 sec.. in every 10 min. (Heavy Duty) 200% for 1 sec.. in every 10 min. (Heavy Duty) | |
| Parameter Function | Power Restart, Speed Search, Over Torque / Under Torque Detection, Multi-Step-Speed, Acc./Dcc Switch, S-curve Acc./Dcc., 3-Wire Sequence Control, Auto-Tuning, Cooling Fan ON / OFF Switch, Slip Compensation , Torque Compensation, Frequency Jump, Upper/Lower Limits for Frequency Command, DC braking at Run/Stop, PID Control including Pause Function, Energy Saving Mode, Fault Reset, Kinetic Energy, Auto Voltage Adjustment, Wobble, Traverse, etc. | |
| Operating Environment | Area of Use | Indoor without corrosive gas/liquid or flammable gas/liquid/oil mist/dust |
| | Ambient Temperature | -10°C to $+50^{\circ}\text{C}$ for open type, below 95% RH without froze or condensation |
| | Storage Temperature | -20°C to $+60^{\circ}\text{C}$ |
| | Altitude | Up to 1000 meters |
| | Shock | 10 to 20 Hz (9.8 m/s ²) , 20 to 55 Hz (5.9 m/s ²) |
| | Enclosure | IP20 |

| | | |
|-----------------------|--|---|
| Number of I/O (F1-F2) | Analog Input (AI) | 1 point (A2 0V~10V, 0 or 4~20mA) |
| | Digital Input (DI) | 4 points |
| | Analog Output (AO) | 1 point (AM 0~10V / 0 or 4~20mA) |
| | Analog Input (AI) | 1 point (A2 0V~10V, 0 or 4~20mA) |
| | Digital Output (DO) | 1 point |
| | Relay Output (RO) | 1 point |
| Number of I/O (F3-F7) | Analog Input (AI) | 2points (A1: 0~10V,-10~10V /A2: 0 or 4~20mA,0~10V,0~5V) |
| | Digital Input (DI) | 7 points |
| | Analog Output (AO) | 2 points (FM:0~10V,-10~10V /AM: 0 or 4~20mA,0~10V) |
| | Digital Output (DO) | 1 point |
| | Relay Output (RO) | 2 points |
| | Pulse Input (PI) | 1 point (1 point digital input sharing support) |
| | Pulse Output (PO) | 1 point |
| Communications | Modbus (RS-485 port), Max. high speed is 115.2kbbs | |


*1. Results tested in labs

2.7 Product Dimensions mm [inch]

2.7.1 400V Frame Size

Frame 1


BL52-40P40-H3-E20, BL52-40P75-H3-E20, BL52-401P5-H3-E20, BL52-402P2-H3-E20



| Series | Frame | Dimensions in mm [inch] | | | | | | | | | |
|--------|-------|-------------------------|--------------|---------------|---------------|-----------------|---------------|---------------|---------------|--------------|--------------|
| | | W | W1 | H | H1 | D | D1 | S1 | Φ | $\Phi 1$ | $\Phi 2$ |
| BL52 | 1 | 113 [4.45] | 93 [3.66] | 143 [5.63] | 131 [5.16] | 158.4 [6.24] | 151 [5.89] | 5.5 [0.22] | 5.5 [0.22] | 22 [0.87] | 22 [0.87] |

Frame 2


BL52-403P7-H3-E20, BL52-405P5-H3-E20



| Series | Frame | Dimensions in mm [inch] | | | | | | | | | |
|--------|-------|-------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|--------------|--------------|
| | | W | W1 | H | H1 | D | D1 | S1 | Φ | Φ1 | Φ2 |
| BL52 | 2 | 145 [5.71] | 128 [5.04] | 184 [7.25] | 172 [6.77] | 168 [6.56] | 161 [6.34] | 5.5 [0.22] | 5.5 [0.22] | 22 [0.87] | 28 [1.10] |

Frame 3


BL52-407P5-H3-E20, BL52-4011P-H3-E20



| | | Dimensions in mm [inch] | | | | | |
|--------|-------|-------------------------|-----------|------------|-----------|-----------|-----------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 3 | 225[8.79] | 202[7.89] | 260[10.16] | 242[9.46] | 198[7.74] | 190[7.42] |
| | | S1 | Ø | Ø1 | Ø2 | Ø3 | |
| | | 6.5[0.25] | 6.5[0.25] | 22[0.86] | 35[1.36] | 44[1.73] | |

Frame 4


BL52-4015P-H3-E20, BL52-4018P-H3-E20



| | | Dimensions in mm [inch] | | | | | |
|--------|-------|-------------------------|---------------|-----------------|-----------------|-----------------|-----------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 4 | 235[9.25] | 212[8.35] | 340[13.38] | 322[12.68] | 218.2[8.59] | 210[8.27] |
| | | S1 | \varnothing | $\varnothing 1$ | $\varnothing 2$ | $\varnothing 3$ | |
| | | 6.5[0.26] | 6.5[0.26] | 22[0.87] | 28[1.10] | 35[1.38] | |

Frame 5





BL52-4022P-H3-E20, BL52-4030P-H3-E20



| | | Dimensions in mm [inch] | | | | | |
|--------|-------|-------------------------|------------|------------|------------|-------------|-----------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 5 | 281[10.397] | 257[10.03] | 385[15.03] | 367[14.33] | 218.9[8.55] | 211[8.24] |
| | | S1 | Φ | $\Phi 1$ | $\Phi 2$ | $\Phi 3$ | $\Phi 4$ |
| | | 6.5[0.26] | 6.5[0.26] | 22[0.87] | 28[1.10] | 35[1.38] | 44[1.72] |

Frame 6


BL52-4037P-H3-E20, BL52-4045P-H3-E20, BL52-4055P-H3-E20



| | | Dimensions in mm [inch] | | | | | |
|--------|-------|-------------------------|------------|------------|-----------|------------|------------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 6 | 304[11.88] | 270[10.55] | 550[21.48] | 53[20.70] | 323[12.62] | 315[12.30] |
| | | S1 | ∅ | ∅1 | ∅2 | ∅3 | ∅4 |
| | | 11[0.43] | 11[0.43] | 22[0.87] | | | |

Frame 7

BL52-4075P-H3-E20, BL52-4090P-H3-E20, BL52-4110P-H3-E20




| Dimensions in mm [inch] | | | | | | | |
|-------------------------|-------|-----------------|-----------------|------------|------------|------------|----------|
| Series | Frame | W | W1 | H | H1 | D | S1 |
| BL52 | 7 | 344[13.43] | 260[10.15] | 665[25.97] | 640[25.00] | 350[13.67] | 11[0.43] |
| | | $\varnothing 1$ | $\varnothing 2$ | | | | |
| | | 11[0.43] | 19[0.74] | | | | |

2.7.2 200V Frame Size

Frame 1


BL52-20P40-H3-E20, BL52-20P75-H3-E20, BL52-201P5-H3-E20, BL52-202P2-H3-E20



| Series | Frame | Dimensions in mm [inch] | | | | | | | | | | |
|--------|-------|-------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|--------------|--------------|------------------------|
| | | W | W1 | H | H1 | D | D1 | S1 | Φ | Φ1 | Φ2 | Φ3 x L |
| BL52 | 1 | 145 [5.71] | 128 [5.04] | 184 [7.25] | 172 [6.77] | 168 [6.61] | 161 [6.34] | 5.5 [0.22] | 5.5 [0.22] | 22 [0.87] | 28 [1.10] | 30 x 20 [1.18x0.79] |

Frame 2


BL52-203P7-H3-E20



| Series | Frame | Dimensions in mm [inch] | | | | | | | | | |
|--------|-------|-------------------------|---------------|----------------|---------------|---------------|---------------|---------------|---------------|--------------|--------------|
| | | W | W1 | H | H1 | D | D1 | S1 | Φ | Φ1 | ΦS |
| BL52 | 2 | 165 [6.5] | 147 [5.79] | 260 [10.24] | 247 [9.72] | 178 [7.01] | 171 [6.73] | 5.5 [0.22] | 5.5 [0.22] | 22 [0.87] | 28 [1.10] |

Frame 3


BL52-205P5-H3-E20, BL52-207P5-H3-E20



| Dimensions in mm [inch] | | | | | | | |
|-------------------------|-------|-----------|-----------|------------|-----------|-----------|-----------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 3 | 225[8.86] | 202[7.95] | 260[10.24] | 242[9.52] | 198[7.80] | 190[7.48] |
| | | S1 | Φ | $\Phi1$ | $\Phi2$ | $\Phi3$ | |
| | | 6.5[0.26] | 6.5[0.26] | 22[0.87] | 35[1.38] | 44[1.73] | |

Frame 4

BL52-2011P-H3-E20, BL52-2015P-H3-E20



| Dimensions in mm [inch] | | | | | | | |
|-------------------------|-------|-----------|---------------|----------------|----------------|----------------|-----------|
| Series | Frame | W | W1 | H | H1 | D | D1 |
| BL52 | 4 | 235[9.25] | 212[8.35] | 340[13.38] | 322[12.68] | 218.2[8.59] | 210[8.27] |
| | | S1 | \varnothing | $\varnothing1$ | $\varnothing2$ | $\varnothing3$ | |
| | | 6.5[0.26] | 6.5[0.26] | 22[0.87] | 28[1.10] | 35[1.38] | |

2.8 Options

2.8.1 Options

| BL50 & BL52 Series Common Accessories | | |
|---------------------------------------|--------------|--|
| Name | Model Number | Description |
| Copy Unit | BL52-CU | Allows parameter uploads / downloads and comparison |
| Remote Keypad | BL52-RK□ | Connects remote keypad for remote setting and monitoring □ indicates S : Frame 1-2, L : Frame 3-7 |
| Plastic Keypad Tray | BL52-PT□ | Plastic Tray for keypad cabinet installation □ indicates S : Frame 1-2, B : Frame 3-7 |
| Iron Keypad Tray | BL52-KM | Iron Tray for frame 1 & 2 keypad cabinet installation |

2.8.2 Braking Unit

400V

| Applicable Motor | | 125% Braking Torque 10%ED | | | * 2 Max. Braking Torque Limit | | |
|------------------|------|---------------------------|--------------------|---------------------|-------------------------------|--------------------------|----------------------|
| HP | kW | Braking Torque (Kg-m) | Braking Resistance | Braking Current (A) | Min. Resistance (Ω) | Max. Braking Current (A) | Max. Peak Power (kW) |
| 0.5 | 0.4 | 0.1 | 50W/1500Ω | 0.5 | 200 | 4 | 3.1 |
| 1 | 0.75 | 0.5 | 100W/750Ω | 1.1 | 200 | 4 | 3.1 |
| 2 | 1.5 | 1.0 | 200W/360Ω | 2.4 | 200 | 3.9 | 3 |
| 3 | 2.2 | 1.5 | 300W/250Ω | 3.5 | 130 | 5.8 | 4.4 |
| 5 | 3.7 | 2.5 | 500W/150Ω | 5.9 | 80 | 9.7 | 7.4 |
| 7.5 | 5.5 | 2.7 | 800W/100Ω | 8.8 | 56 | 14.5 | 11 |
| 10 | 7.5 | 5.1 | 1000W/75Ω | 10.5 | 45.1 | 17.5 | 13.8 |
| 15 | 11 | 7.5 | 1600W/50Ω | 15.8 | 45.1 | 17.5 | 13.8 |
| 20 | 15 | 10.2 | 2000W/40Ω | 19.8 | 22.6 | 35 | 27.7 |
| 25 | 18.5 | 12.2 | 2500W/32Ω | 24.7 | 22.6 | 35 | 27.7 |
| 30 | 22 | 14.9 | 3000W/26Ω | 30.4 | 22.6 | 35 | 27.7 |
| 40 | 30 | 20.3 | 4000W/20Ω | 39.5 | 14.1 | 56 | 44.2 |

200V

| Applicable Motor | | 125% Braking Torque 10%ED | | | * 2 Max. Braking Torque Limit | | |
|------------------|-----|---------------------------|--------------------|---------------------|-------------------------------|--------------------------|----------------------|
| HP | kW | Braking Torque (Kg-m) | Braking Resistance | Braking Current (A) | Min. Resistance (Ω) | Max. Braking Current (A) | Max. Peak Power (kW) |
| 0.5 | 0.4 | 0.1 | 50W/400a | 1 | 190 | 4 | 1.6 |
| 1 | 0.7 | 0.5 | 100W/200k | 1.98 | 63.3 | 6 | 2.4 |
| 2 | 1.5 | 1.0 | 200W/100k | 4 | 47.5 | 8 | 3.2 |
| 3 | 2.2 | 1.5 | 300W/650 | 6.1 | 38 | 12 | 4.7 |
| 5 | 3.7 | 2.5 | 500W/400 | 9.9 | 19 | 20 | 7.6 |
| 7.5 | 5.5 | 3.7 | 800W/250 | 15.8 | 10.5 | 37.5 | 14.8 |
| 10 | 7.5 | 5.1 | 1000W/20k | 19.8 | 10.5 | 37.5 | 14.8 |
| 15 | 11 | 7.5 | 1500W/13k | 29 | 10.5 | 37.5 | 14.8 |
| 20 | 15 | 10.2 | 2000W/10k | 39.5 | 7.9 | 50 | 19.8 |

Chapter 3 | Drive Installation

3.1 Installation Environment

To ensure the optimum drive performance, install the AC drive in a proper environment specified below.

| Environment | Conditions |
|---------------------|--|
| Area of Use | Indoors |
| Ambient Temperature | <ul style="list-style-type: none">● -10°C to +50°C (IP20, for open type)● Do not install the drive in environments with wide temperature fluctuations so as to ensure the drive reliability.● When the drive is installed in an enclosure cabinet, make sure the cooling works properly to keep the temperature within the specified levels.● Do not allow the drive to freeze.● When drives are installed side-by-side in a cabinet, follow the instruction illustrated in Figure 3.2 to ensure the air flow. |
| Humidity | <ul style="list-style-type: none">● Under 90% RH● Free of condensation |
| Storage Temperature | -20°C to +60°C |
| Surrounding Area | <ul style="list-style-type: none">● Free from water, oil, metal shavings or other foreign materials.● Free from flammable materials (e.g., wood)● Free from harmful gases and liquids● Free from direct sunlight● Free from oil mist, corrosive gas, flammable gas or dust.● Free from radioactive material● Green Class 2 or above |
| Altitude | Up to 1000 m without derating. Up to 2000 meters with 1% rated current derated for every 100 m counted from 1000 m. |
| Vibration | <ul style="list-style-type: none">● 10 to 20 Hz at 9.8 m/s²● 20 to 55 Hz at 5.9 m/s² (2A0004 to 2A0211, 4A0002 to 4A0165) or 2.0 m/s² (2A0250 to 2A0415, 4A0208 to 4A1200) |
| Enclosure | IP20 |

3.2 Installation Direction and Spacing

3.2.1 Installation Direction

Install the AC drive upright for better cooling.

OK




A. Upright installation

NG



B. Horizontal installation

NG




C. Transverse installation

Figure 3.2.1 Installation Direction


3.2.2 Installation Spacing

3.2.2.1 Single Drive Installation


Install the AC drive as illustrated below to ensure the required space for airflow and wiring



A Minimum 50 mm



B Minimum 30 mm




C Minimum 150 mm

Figure 3.2.2.1 Installation Spacing for Single Drive

3.2.2.2 Side-by-Side Installation

Install the AC drives as illustrated below to ensure the required space for airflow and wiring.



A - Minimum 50 mm B - Minimum 30 mm C - Minimum 10 mm D - Minimum 150 mm


Figure 3.2.2.2 Installation Space for Side-by-Side Installation

Note: When installing drives of different sizes, align the tops of the drives for easier cooling fan replacement.


3.3 Keypad and Terminal Cover Installation

It is not necessary to remove the keypad before wiring. You just need to loosen the terminal cover screw and remove the terminal cover.


440V 0.4kW to 30kW model enclosure are non-metal. Loosen terminal cover screw and remove terminal cover for wiring. After wiring, affix the terminal cover back in position and tighten the screw. For wiring instructions and screw tightening torque please refer to Chapter 4.




Step1 : Loosen front screw




Step2 : Take out the keypad



Step3 : Remove the terminal cover



Step4 : Loosen screws of the wiring cover and remove the wiring cover



Step5 : Locking screw, replace the controller and wiring cover

3.4 Wiring Protection

3.4.1 Drive and Input Cable Protection for Short-Circuit Situations

Protect the drive and input power cable by using fuse in case potential short-circuit situations cause overheat. Please refer to the following figure for proper wiring




Figure 3.4 Fuse Installation

3.4.2 Motors and Output Cable Protection for Short-Circuit Situations

If the output cables are properly selected according to the drive rated current, the drive itself is fully capable of protecting the motor and output cables in case of short-circuit situations.

Note: If a single drive runs more than 1 motor, a separate thermal overload switch or a circuit breaker is required.

3.4.3 Keypad Mounted on Panel Door


The keypad of BL52 series can be removed and connected to the drive using an extension cable. The remote keypad can be mounted on control panels with screws thread M4 X P0.7 and the screw length longer than the thickness of panel door.

3.5 Keypad Remote Usage


Keypad mounted on the drive can be removed and connected to the drive using an extension cable to facilitate operation when the drive is installed in a location where it cannot be easily accessed. It can also be permanently mounted remote locations such as panel doors using an extension cable and an installation support set.

3.5.1 Remote Operation


3.5.1.1 Remote Operation (<5.5kW models)




3.5.1.2 Remote Operation (>7.5kW models)



3.5.1.3 Keypad Dimensions (<5.5kW models)




3.5.1.4 Keypad Dimensions (>7.5kW models)




3.5.2 External/Face-Mount


3.5.2.1 External/Face-Mount (<5.5kW models)




3.5.2.2 External/Face-Mount (>7.5kW models)



3.5.2.3 Panel Cut-Out Dimensions (<5.5kW models)



3.5.2.4 Panel Cut-Out Dimensions (>7.5kW models)



Chapter 4 | Wiring

4.1 Wiring Safety


Caution

- Turn off all the power to the equipment before wiring. Wiring during power on could cause electrical shocks to personnel.
- Allow only qualified personnel for installation, wiring, repairing and parts replacement.
- Capacitors in the drive may still be charged for a short time after shutting off the power. Wait for the amount of time specified on the drive before any maintenance.
- Never touch input or output power cables. Do not connect any circuit to drive enclosure.

Warning

- Properly connect the motor ground terminal. Contacts between the motor ground terminal and motor enclosure could cause electrical shocks or a fire.
- Ensure terminal screws are all tightened. Loose connection to the main circuit could cause overheat or a fire.
- Verify if the rated voltage of the drive matches the voltage of the incoming power supply before applying power.
- Perform all wiring as specified in the wiring diagrams provided when installing braking unit. Failure to comply could result in drive, braking unit or resistor damage on fire.
- Do not disconnect the motor from the drive while the drive is outputting voltage.
- Do not use unshielded cable for control circuit wiring. Failure to comply could cause abnormal operation of drive.
- Use shielded twisted-pair cables and connect the shield to ground terminal of the drive.
- Do not modify the drive circuits. Failure to comply could cause drive damage.
- Ensure all connections are correct after connecting the drive with other devices.

4.2 Main Circuit




Notes :


- *1 Please remove DC+(+1/+2) jumper when installing DC reactor.
- *2 When using braking resistor, please ensure stall prevention function is off.
- *3 J5 is port of optional communication card. Please refer to user manual when installing it.
- *4 Multi-function analog input S1~S7 can be switched between Sink(NPN) or Source(PNP) mode. Default : NPN mode.
- *5 Switch A2 is used to set analog input as voltage input or current input.
- *6 AC is common terminal of analog signal (Analog Common).
- *7 Pulse input and digital inputs share the same terminal (5.5kW or less shared S4, 7.5kW more common S7).
- *8 RJ45 is the communication port of RS-485.
- *9 Analog output is used to connect frequency meter, current meter, voltage meter and power meter.

4.2.1 Main Circuit Terminal

Frame 1 & 2



Frame 3 & 4 & 5



Frame 6 & 7




Table 4.2.1 Main Circuit Terminals

| Terminal Name | Terminal Description |
|------------------|---|
| R/L1, S/L2, T/L3 | Power input terminal |
| U/T1, V/T2, W/T3 | Power output terminal |
| +1, +2(DC+) | DC reactor terminal. Please remove the jumper before installation |
| B1, B2 | Braking resistor terminal. Select option as per the specifications. (Please refer to Chapter 7.1) |
| E | Ground terminal |

4.2.2 Main Circuit Wiring

4.2.2.1 Power Input Terminal

- Install a molded case circuit breaker (MCCB) between three phase AC input power and main circuit terminals R/L1, S/L2 and T/L3. A magnetic contactor (MC) in series connection is also suggested so as to shut off the power by drive protection functions. Install a R-C varistor on both ends of the MC.
- Ensure main circuit terminal screws are tightened to avoid vibration loosening the screws which could cause electric sparks.

4.2.2.2 Power Output Terminal


- When connecting a noise filter at AC drive output terminals U/T1, V/T2 and W/T3, always use an inductive L-filter. Do not install any power capacitor, L-C or R-C filter.
- Connect AC drive output terminals U/T1, V/T2 and W/T3 to motor input terminals U, V and W respectively. Ensure the motor and drive terminals are in same phase sequence or the motor will rotate reversely.

- Do not connect power cable to output terminals of the drive. Failure to comply could cause drive damage and a fire.

4.2.2.3 DC Reactor and Braking Resistor Terminal :


- The terminal is to connect a DC reactor so as to improve power factor. The drive is shipped from the factory with a short-circuit jumper. Remove the jumper before connecting a DC reactor.

DC Reactor (option)



- If the drive is used in a high-frequency or heavy duty application which requires frequent braking or shorter deceleration time, install an optional braking resistor to increase the braking torque.

Braking Resistor (option)




- Please refer to the wiring diagram when installing braking options.

4.2.2.4 Ground Terminal

- Use grounding cables of dimensions regulated by electrical equipment standard. Shrink wiring distance to prevent leakage current resulting unstable electrical potential at the terminal distant from grounding terminal.
- Do not use share the same grounding cable with welding machines or any device requiring large current. Failure to comply could cause drive or equipment malfunction.
- Do not wind the grounding cable when multiple drives are installed. Failure to comply could cause drive or equipment malfunction.
- Ensure the neutral of the input side and drive terminal "⊕" are grounded according to the local electrician regulations. 3WYE (e.g. TN and TT) system are suggested for the drive primary side.

4.2.2.5 Jumper :

- BL52 complies with the European LVD standard EN 61800-5-1 (2007) reducing the touch current to below 10mA DC under testing condition regulated by IEC 60990 (1999).
- Follow the instructions below to remove the jumper if an even lower current leakage to a even lower level.
- Removing the jumper may increase the signal interference



4.2.2.6 Ring Terminal

- Main circuit terminal should be used with crimp ring terminal wiring
- Please refer to the diagram about ring terminal size, where the 8 AWG and 10 AWG bare recommend using W size must be less than 10.5 mm, d2 size must be greater than 5.0
- Ring terminal shall be insulated cover of the terminal block wiring, which can form a reference KST RVBS8-5 & KST RVB5-5 or similar size ring terminals to facilitate wiring and other operations

| Diameter | Terminal Type | Terminal Specifications | | | | | | | |
|----------|---------------|-------------------------|-----|-----|-----|------|------|------|-----|
| | | W | d2 | d1 | D | F | E | L | T |
| AWG 8 | RVBS8-5 | 8.8 | 5.3 | 4.5 | 8.5 | 10.5 | 16.7 | 31.6 | 1.2 |
| AWG 10 | RVB5-5 | 9.5 | 5.3 | 3.4 | 6.4 | 8.3 | 13 | 26 | 1 |

4.2.3 Main Circuit Cable Size and Tightening Torque

Select the cables and crimp terminals according to Table 4.2.2.

1. The recommended cables (copper conductors) are 600 V vinyl-sheathed cables which have continuous temperature tolerance up to 75°C with ambient temperature tolerance up to 40°C, wiring distance up to 100 meters and conditions suitable for on Normal Duty mode.
2. Terminal +1, +2, B1 and B2 are only for connecting DC reactor and braking resistor options. Do not connect it to other devices.
3. Consider the amount of voltage drop when selecting cable sizes. Increase the cable size when the voltage drop exceeds 2% of the motor rated voltage. The amount of voltage drop can be calculated using the following formula :

$$\text{Line drop voltage (V)} = 3 \times \text{cable resistance } (\Omega/\text{km}) \times \text{cable length (m)} \times \text{current (A)} \times 10^{-3}$$

Table 4.2.2 Cable Size and Tightening Torque (Three-phase 400 V)

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|---------------|---------------------------------------|--------------------------------------|---------------------------------------|---------------------------------|----------------------------------|--------------------------------------|---------------------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm ² | Applicable Cable Size mm ² | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm ² | Applicable Cable Size mm ² | | |
| 1.5kW ~ 2.2kW | B1,B2,-,R/L1,S/L2,T/L3,U/T1,V/T2,W/T3 | 1.3 | 1.3~ 3.3 | 16 | 16 ~ 12 | 1.3 | 1.3~ 3.3 | M4 | 1.36 |

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|---------------|---------------------|--------------------------------------|---------------------------------------|---------------------------------|----------------------------------|--------------------------------------|---------------------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm ² | Applicable Cable Size mm ² | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm ² | Applicable Cable Size mm ² | | |
| 3.7kW ~ 5.5kW | B1,B2,-,R,S,T,U,V,W | 3.309 | 3.309~8.368 | 8 | 12 ~ 8 | 3.309 | 3.309 ~ 8.368 | M4 | 1.8 (15.9) |

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|--------------|---|--------------------------------------|---------------------------------------|---------------------------------|----------------------------------|--------------------------------------|---------------------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm ² | Applicable Cable Size mm ² | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm ² | Applicable Cable Size mm ² | | |
| 7.5kW ~ 11kW | DC+1,B1/DC+2,B2,-,R/L1,S/L2,T/L3,U/T1,V/T2,W/T3 | 8.3 | 5.3 ~ 8.3 | 8 | 10 ~ 8 | 8.3 | 5.3 ~ 8.3 | M5 | 2.26 (20) |


| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|---------------|---|--------------------------|---------------------------|---------------------------------|----------------------------------|--------------------------|---------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm2 | Applicable Cable Size mm2 | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm2 | Applicable Cable Size mm2 | | |
| 15kW ~ 18.5kW | DC+1,B1/DC+2, B2,-,R/L1,S/L2,T/L3, U/T1,V/T2,W/T3 | 21.2 | 13.3 ~ 21.2 | 4 | 6 ~ 4 | 21.2 | 13.3 ~ 21.2 | M6 | 2.45 (21.7) |

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|--------------|---|--------------------------|---------------------------|---------------------------------|----------------------------------|--------------------------|---------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm2 | Applicable Cable Size mm2 | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm2 | Applicable Cable Size mm2 | | |
| 22kW ~ 30kW | DC+1,B1/DC+2, B2,-,R/L1,S/L2,T/L3, U/T1,V/T2,W/T3 | 33.6 | 21.2 ~ 33.6 | 2 | 4 ~ 2 | 33.6 | 21.2 ~ 33.6 | M8 | 6.37 (56.42) |

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|--------------|---|--------------------------|---------------------------|---------------------------------|----------------------------------|--------------------------|---------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm2 | Applicable Cable Size mm2 | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm2 | Applicable Cable Size mm2 | | |
| 37kW ~ 55kW | R/L1,S/L2,T/L3,P, DC+,DC-, U/T1,V/T2,W/T3 | 85 | 33.6 ~ 85 | 3/0 | 2 ~ 3/0 | 85 | 33.6 ~ 85 | M8 | 7.8 (69) |

| Drive Rating | Terminal | Asia | | USA | | Europe & China | | Terminal Screw Thread | Tightening Torque Nm (lb.in.) |
|--------------|---|--------------------------|---------------------------|---------------------------------|----------------------------------|--------------------------|---------------------------|-----------------------|-------------------------------|
| | | Suggested Cable Size mm2 | Applicable Cable Size mm2 | Suggested Cable Size AWG, kcmil | Applicable Cable Size AWG, kcmil | Suggested Cable Size mm2 | Applicable Cable Size mm2 | | |
| 75kW ~ 110kW | R/L1,S/L2,T/L3,P, DC+,DC-, U/T1,V/T2,W/T3 | 177 | 107.2 ~ 177 | 350MCM | 4/0 ~ 350MCM | 177 | 107.2 ~ 177 | M8 | 7.8 (69) |

4.3 Control Circuit



Notes :

- *1 Please remove DC+(+1/+2) jumper when installing DC reactor.
- *2 When using braking resistor, please ensure stall prevention function is off.
- *3 J5 is port of optional communication card. Please refer to user manual when installing it.
- *4 Multi-function analog input S1~S7 can be switched between Sink(NPN) or Source(PNP) mode. Default : NPN mode.
- *5 Switch A2 is used to set analog input as voltage input or current input.
- *6 AC is common terminal of analog signal (Analog Common).
- *7 Pulse input and digital inputs share the same terminal (5.5kW or less shared S4, 7.5kW more common S7).
- *8 RJ45 is the communication port of RS-485.
- *9 Analog output is used to connect frequency meter, current meter, voltage meter and power meter.

4.3.1 Control Circuit Terminals

4.3.1.1 Control circuit input and output terminal (<5.5kW (more) models)




Table 4.3.1.1 Control Circuit Input Terminal

| Terminal Type | Terminal Code | Terminal Name | Terminal Description |
|-------------------------------|---------------|--|--|
| Multi-Function Digital Inputs | S1 | Digital input terminal 1 (forward/stop) | Photocoupler, 24 V / 8 mA. |
| | S2 | Digital input terminal 2 (reverse/stop) | Use Sink / Source switch to select multi-function digital input type. |
| | S3 | Digital input terminal 3 (external fault signal 1) | The default is Sink mode. |
| | S4 | Digital input terminal 4 (Jog command) | In addition to the characteristic S1 ~ S3, but also for the high-speed pulse input channel. Maximum input frequency : 50KHz High voltage: 10 ~ 24V Low voltage: 0 ~ 0.5V For digital inputs, switch Sink / Source mode must be external connection |
| | S4C | High-speed pulse signal common terminal | |


| | | | |
|------------------------------|-----|---|--|
| Multi-Function Analog Inputs | +V | Auxiliary power terminal +10V | Analog input power +10V / 20mA |
| | A2 | Analog input terminal 1 (auxiliary frequency command) | Voltage or current input (Selectable). 0 or 4 to 20mA, 0 to 10V |
| | PE | Ground terminal | The ground terminal for control signals to avoid interference. Use shielded cables only. |
| | AC | Common terminal for analog signals | |
| | COM | Digital control signal common terminal | |
| | 24V | +24V auxiliary power terminal for analog input | Digital control signal power + 24V / 50mA |

Table 4.3.1.2 Control Circuit Output Terminals


| Terminal Type | Terminal Code | Terminal Name | Terminal Description |
|------------------------------------|---------------|---|--|
| Multi-Function Photocoupler Output | D1 | Photocoupler Output terminal 1 | Photocoupler Output 30 V, 2 to 15 mA |
| | DC | Digital Output terminal | |
| | AM | Multi-function analog output terminal (output current) | Voltage or current output (Selectable) 0 or 4 to 20mA, 0 to 10V |
| | AC | Analog common terminal | |
| Multi-Function Relay Output | R1A | Relay1 normal open | Relay output DC 30V, 3A AC 250V, 5A |
| | R1B | Relay1 normal closed | |
| | R1C | Relay1 common | |

4.3.1.2 <5.5kW models, NPN and PNP wiring

NPN models (S1~S3)




PNP models (S1~S3)




Due to multi-function input terminal S4 common pulse function, wiring and S1 ~ S3 different way, way below refer to the wiring

NPN models (S4)



PNP models (S4)



4.3.1.3 Control circuit input and output terminal (>7.5kW (more) models)




Table 4.3.1.3 Control Circuit Input Terminal

| Terminal Type | Terminal Code | Terminal Name | Terminal Description |
|-------------------------------|---------------|---|--|
| Multi-Function Digital Inputs | S1 | Digital input terminal 1 (forward/stop) | Photocoupler, 24 V, 8 mA. Use NPN/PNP switch to select multi-function digital input type. The default is NPN mode. |
| | S2 | Digital input terminal 2 (reverse/stop) | |
| | S3 | Digital input terminal 3 (external fault 1) | |
| | S4 | Digital input terminal 4 (fault reset) | |
| | S5 | Digital input terminal 5 (multi-step speed 1) | |
| | S6 | Digital input terminal 6 (multi-step speed 2) | |
| | S7 | Digital input terminal 7 (Jog command) | In addition to the characteristic S1 ~ S6, but also for the high-speed pulse input channel. Maximum input frequency : 50KHz High voltage: 10 ~ 24V Low voltage: 0 ~ 0.5V For digital inputs, switch Sink / Source mode must be external connection |


| Terminal Type | Terminal Code | Terminal Name | Terminal Description |
|------------------------------|---------------|---|--|
| Multi-Function Analog Inputs | S7C | High-speed pulse signal common terminal | |
| | COM | Digital control signal common terminal | |
| | +V | Auxiliary power terminal +10V | Analog input power+10V |
| | A1 | Analog input terminal 1 (main frequency command) | Voltage input 0 to 10V / -10V to +10V |
| | A2 | Analog input terminal 2 (auxiliary frequency command) | Voltage or current input (Selectable). 0 or 4 to 20mA, 0 to 10V, 0 to 5V |
| | PE | Ground terminal | The ground terminal for control signals to avoid interference. Use shielded cables only. |
| | 24V | +24V auxiliary power terminal for analog input | Digital control signal power + 24V (INT port selection by short-circuiting) INT: short circuit, internal offer + 24V / 200mA: open, externally supplied + 24V |

Table 4.3.1.4 Control Circuit Output Terminals

| Terminal Type | Terminal Code | Terminal Name | Terminal Description |
|------------------------------------|---------------|---|--|
| Multi-Function Photocoupler Output | D1 | Photocoupler Output terminal 1 (zero speed) | Photocoupler Output 48 V, 2 to 50 mA |
| | DC | Digital Output terminal | |
| | D+ | RS485 communication terminal, standard RS485 interface, use twisted pair or shielded wire | |
| | D- | | |
| Multi-Function Analog Output | FM | Programmable analog output terminal (output frequency) | Voltage Output 0 to 10V, -10 to +10V |
| | AM | Multi-function analog output terminal (output current) | Voltage or current output (Selectable) 0 or 4 to 20mA, 0 to 10V |
| | AC | Analog common terminal | |
| Multi-function pulse train output | MP | Multi-function pulse train output (output frequency) | 32KHz Max |
| Multi-function Relay output | R1A | Relay1 normal open | Relay output DC 30V, 3A AC 250V, 5A |
| | R1B | Relay1 normal closed | |
| | R1C | Relay1 common | |
| | R2A | Relay2 normal open | |
| | R2C | Relay2 normal closed | |

<1> Do not assign frequent switching functions such as ON/OFF to terminals R1 and R2, which may shorten the relay terminal life.

4.3.1.4 >7.5kW models, NPN and PNP wiring



4.3.2 Control Circuit Cable Size and Tightening Torque

Select the cable according to Table 4.3.2.1 and 4.3.3.2. Use crimp ferrules on the cable ends for simpler and more reliable wiring.

Table 4.3.2.1 Cable Size and Tightening Torque (<5.5kW models)

| Terminal | Screw Size | Tightening Torque Nm (lb.in.) | Bare Cable | | Ferrule-Type Terminal | | Cable Type |
|---|------------|-------------------------------------|--|---|--|---|----------------------|
| | | | Applicable Size mm ² (AWG) | Suggested Size mm ² (AWG) | Applicable Size mm ² (AWG) | Suggested Size mm ² (AWG) | |
| +V, A2, AC, AM, D1, DC, S4C, 24V, COM, S1, S2, S3, S4, PE | M2.5 | 0.4 (3.52) | 0.13 ~ 2.08 (26 ~ 14) | 0.13 (26) | 0.41 ~ 1 (17 ~ 21) | 0.41 (17) | Shielded cable, etc. |
| R1A, R1B, R1C | M2.5 | 0.57 (5) | 0.13 ~ 3.31 (26 ~ 12) | 0.13 (26) | 3.31 ~ 5.26 (12 ~ 10) | 3.31 (12) | Shielded cable, etc. |

Table 4.3.2.2 Cable Size and Tightening Torque (>7.5kW models)

| Terminal | Screw Size | Tightening Torque Nm (lb.in.) | Bare Cable | | Ferrule-Type Terminal | | Cable Type |
|--|------------|--------------------------------|----------------------------|---------------------------|----------------------------|---------------------------|----------------------|
| | | | Applicable Size mm2 (AWG) | Suggested Size mm2 (AWG) | Applicable Size mm2 (AWG) | Suggested Size mm2 (AWG) | |
| AC,V+,FM,A1,AM, A2,24V,S1, S2,S3,S4,S5,S6,S7, COM,S7C, | M2.5 | 0.59 (5.2) | 0.13 ~ 1.31 (26 ~ 16) | 0.13 (26) | 0.13 ~ 0.33 (26 ~ 22) | 0.13 (26) | Shielded cable, etc. |
| R1A,R1B,R1C,R2A, R2C | M2.5 | 0.59 (5.2) | 0.2 ~ 3.31 (24 ~ 12) | 0.2 (24) | 0.2 ~ 0.33 (24 ~ 22) | 0.2 (24) | Shielded cable, etc. |

4.3.3 Ferrule-Type Terminals

Always use ferrule-type terminals with insulated sleeves. Refer to Table 4.3.3.2. for dimensions. In addition, crimping tool CRIMPFOX ZA-3 manufactured by Phoenix Contact is recommended.




Table 4.3.3.2 Ferrule-Type Terminal Models and Sizes

| Cable Size mm2 (AWG) | Type | L (mm) | d1 (mm) | d2 (mm) | Manufacturer |
|----------------------|-------------|--------|---------|---------|-----------------|
| 0.25 (24) | AI 0.25-6YE | 10.5 | 0.8 | 2 | Phoenix Contact |
| 0.34 (22) | AI 0.34-6TQ | 10.5 | 0.8 | 2 | Phoenix Contact |
| 0.5 (20) | AI 0.56-WH | 14 | 1.1 | 2.5 | Phoenix Contact |

4.4 I/O Connections

4.4.1 NPN and PNP Mode Selection

Use Sink/Source DIP switch on the control board to set NPN/PNP mode for multi-function digital inputs S1 to S7. (Default: NPN mode)




Figure 4.4.1.1 <5.5Kw series Sink/Source DIP Switch




Figure 4.4.1.2 >7.5Kw series Sink/Source DIP Switch

4.4.2 Terminal A2 Voltage/Current Input Selection

Select voltage or current input at terminal A2

- To select current as the input type, set DIP switch A2 to I and set parameter E3-06 to 0 (0 to 20 mA) or 1 (4 to 20 mA).
- To select voltage as the input type, set DIP switch A2 to V and set parameter E3-06 to 2 (0 to 10 V) or 3 (0 to 5 V).




Figure 4.4.2.1 <5.5kW DIP Switch A2




Figure 4.4.2.2 >7.5kW DIP Switch A2

Table 4.4.1 DIP Switch A2 Settings (Terminal A2)

| Setting | Description |
|---------|--|
| V | Voltage input (0 to 10 V or 0 to 5 V) |
| I | Current input (4 to 20 mA or 0 to 20 mA) (default) |

Table 4.4.2 Parameter E3-06

| No. | Parameter Name | Description | Setting Range | Default |
|-------|------------------------------------|--|---------------|---------|
| E3-06 | Terminal A2 Signal Level Selection | Selects the signal level for terminal A2. 0 : 0 ~ 20 mA 1 : 4 ~ 20 mA 2 : 0 ~ 10 V 3 : 0 ~ 5 V | 0, 1, 2, 3 | 1 |

4.4.3 Terminal AM Voltage/Current Output Selection

Select voltage or current output type for terminal AM

- To select voltage as the output type, set DIP switch AM to V and set parameter E4-04 to 0 (0 to 10V).
- To select current as the output type, set DIP switch AM to I and set parameter E4-04 to 1 (0 to 20 mA) or 2 (4 to 20 mA).


**Figure 4.4.3 DIP Switch AM**

Table 4.4.3 DIP Switch AM Setting (Terminal AM)


| Setting | Description |
|---------|---|
| V | Voltage output (0 to 10 V) |
| I | Current output (4 to 20 mA or 0 to 20 mA) (default) |

Table 4.4.4 Parameter 4-04

| No. | Parameter Name | Description | Setting Range | Default |
|-------|------------------------------------|---|---------------|---------|
| E4-04 | Terminal AM Signal Level Selection | Selects the signal level for terminal AM 0 : 0 to 10 V 1 : 0 to 20 mA 2 : 4 to 20 mA | 0, 1, 2 | 2 |

4.4.4 RS-485 Communication Termination ON / OFF Switch

The default of termination resistor for RS-485 communication is OFF. Switch it to ON when the drive is the last in a series of slave drives. Set this termination resistor on DIP switch RS485 illustrated in Figure 4.4.4.

**Figure 4.4.4 DIP Switch RS-485 Termination Resistor**

4.5 Connection to PC

The drive is equipped with a RJ45 port. The drive can connect to a PC through RJ45 cable to manage parameter settings using BL52 PC software.




Figure 4.5 Connection to PC

4.6 Wiring Checklist

Table 4.6 Wiring Checklist

| <input type="checkbox"/> | No. | Item | Page |
|--|-----|--|------|
| Power Supply Voltage and Output Voltage | | | |
| <input type="checkbox"/> | 1 | Power supply voltage is within the voltage range of specified drive input. | |
| <input type="checkbox"/> | 2 | The motor voltage matches the drive output specifications. | |
| <input type="checkbox"/> | 3 | The drive rating matches the motor rating. | |
| Main Circuit Wiring | | | |
| <input type="checkbox"/> | 4 | An MCCB of proper specifications is connected between the drive and motor. | |
| <input type="checkbox"/> | 5 | Power cables are correctly connected to drive input terminals R/L1, S/L2 and T/L3. | |
| <input type="checkbox"/> | 6 | Motor terminals and drive terminals U/T1, V/T2 and W/T3 are in same phase sequence. (Otherwise the motor will rotate reversely) | |
| <input type="checkbox"/> | 7 | Power supply and motor power cable complies with electrician regulations. | |
| <input type="checkbox"/> | 8 | The drive is properly grounded. | |
| <input type="checkbox"/> | 9 | Drive terminal screws of the main circuit and ground are tightened. | |
| <input type="checkbox"/> | 10 | An MC is installed for each motor if a single drive runs more than on motor. | |
| <input type="checkbox"/> | 10 | <p>An MC is installed for each motor if a single drive runs more than on motor.</p> <p style="text-align: center;">MC1~MCn Magnetic Contactor</p> <p>Note: Set MC1 to MCn OFF before operating the drive. Do not switch MC1 to MCn ON or OFF during run.</p> | |
| <input type="checkbox"/> | 11 | When using a braking resistor or braking unit, an MC is installed on the drive input side and able to shut off the power to drive when overloaded. | |
| Control Circuit Wiring | | | |
| <input type="checkbox"/> | 12 | Twisted-pair cables are used for all drive control circuit wiring. | |
| <input type="checkbox"/> | 13 | Shielded cables are connected to the terminals. | |
| <input type="checkbox"/> | 14 | Options (if any) are properly installed. | |
| <input type="checkbox"/> | 15 | No wiring mistakes. | |
| <input type="checkbox"/> | 16 | Do not use a buzzer to check wiring. | |
| <input type="checkbox"/> | 17 | The control circuit terminal screws are tightened. | |
| <input type="checkbox"/> | 18 | No cable clippings or screws are left inside the drive enclosure. | |
| <input type="checkbox"/> | 19 | Control circuit wiring and main circuit wiring are separated. | |

Chapter 5 | Keypad

5.1 Keypad

Use the keypad to enter RUN and STOP commands, display data, fault, alarm and set parameters.

5.1.1 Keys and Displays


















Figure 5.3.1 Keypad

Table 5.1.1 Keypad Keys and Displays






























| No. | Button | Name | Function |
|-----|---|-------------|---|
| 1 |  | FN1 Key | User-defined function key for Quick Setting Mode |
| 2 |  | FWD/REV Key | Forward/reverse selection |
| 3 |  | RESET Key | <ul style="list-style-type: none"> ● Moves the cursor to the right ● Resets the drive to clear a fault situation |
| 4 |  | RUN Key | Runs the drive |
| 5 |  | MENU Key | <ul style="list-style-type: none"> ● Enters or exits the parameter group ● Switches the displayed menu |
| 6 |  | UP/DOWN Key | Selects parameter numbers, increments and decrements setting value and frequency |
| 7 |  | | |
| 8 |  | STOP Key | Stops the drive |
| 9 |  | ENTER Key | <ul style="list-style-type: none"> ● Enters parameter value, parameter and setting ● Enters parameter setting menu. |

| | | | |
|----|---|-----------------------|--|
| 10 |  | LO/RE | Switches drive control between the keypad (LOCAL) and an external source (REMOTE) |
| 11 |  | Non-Slip Setting Dial | <p>ENTER Key:</p> <ul style="list-style-type: none"> ● Enters parameter value, parameter and setting ● Enters parameter setting menu. <p>Dial: Increases or decreases parameter numbers, setting value and frequency</p> |
| 12 |  | RUN Light | Refer to Table 5.1.2.2 |
| 13 |  | RPM Light | Refer to Table 5.1.2.2 |
| 14 |  | Hz Light | Refer to Table 5.1.2.2 |

5.1.2 Keypad Display




5.1.2.1 LED Display

Table 5.1.2.1 LED Display

| Number /Letter | LED Display | Number /Letter | LED Display | Number /Letter | LED Display | Number /Letter | LED Display |
|----------------|--|----------------|--|----------------|---|----------------|---|
| 0 |  | 9 |  | i |  | r |  |
| 1 |  | A |  | J |  | S |  |
| 2 |  | b |  | K | Nil | t |  |
| 3 |  | c |  | L |  | U |  |
| 4 |  | d |  | M | Nil | v |  |
| 5 |  | E |  | n |  | W | Nil |
| 6 |  | F |  | o |  | X | Nil |
| 7 |  | G |  | P |  | y | Nil |
| 8 |  | H |  | q | Nil | Z | Nil |

5.1.2.2 LED Indication

Table 5.1.2.2 LED Indication

| Indicator Light | Lit | Blinking | Off |
|--|-----------------------------|--|--------------------|
|  | Drive in operation | <ul style="list-style-type: none"> ● Drive in deceleration ● Out frequency below the minimum frequency | Drive in operation |
|  | Displaying output speed | Nil | Nil |
|  | Displaying output frequency | Nil | Nil |


5.1.2.3 LO/RE · EXT LED Light display

| | EXT | LO/RE | Lights |
|--------|--|-------|--------|
| Local | OFF (Only Control On Keypad) | ON | Green |
| Remote | OFF (When the source is set to Keypad operation) | OFF | OFF |
| | ON | OFF | Red |


5.1.3 Keypad Programming

■ Keypad Display Menu Structure

- A. Standard setting mode: Press MENU to enter or exit the parameter group. Press ENTER, MENU, UP, DOWN and RESET to monitor and edit settings.
- B. Quick monitoring parameters mode : FN2 function keys for using quickly most of the parameters monitored, and use the up and down keys to switch parameters want to monitor.



- C. Quick setting mode : User must assign the function to the FN1 key in advance so as to quickly set the parameter by pressing FN1 key.



5.2 Parameter List

| Parameter | Name | Description | Setting Range |
|--------------------------------|--------------------------|---|--|
| Group A, Initialization | | | |
| A1: Basic Settings | | | |
| A1-00 | Retain | | |
| A1-01 <4> | Access Level Selection | Selects access level (edit/view) 0: View Only Access to only parameter A1-01 1: User-Defined Parameter Access Access to only parameter A1-01 and A2-00 to A2-31 2: All Parameter Access All parameters can be edited and viewed | Default : 2 Min.: 0 Max.: 2 |
| A1-02 | Control Method Selection | 0: V/F Control 1: Sensorless Voltage Vector Control | Default: 0 Range: 0 to 1 |
| A1-03 | Reset | Resets parameter settings to defaults. After resetting parameters, the value will become 0. 2538: Resets 2-Wire Sequence / 50Hz / 380V 2541: Resets 2-Wire Sequence / 50Hz / 415V 2544: Resets 2-Wire Sequence / 50Hz / 440V 2546: Resets 2-Wire Sequence / 50Hz / 460V 2638: Resets 2-Wire Sequence / 60Hz / 380V 2641: Resets 2-Wire Sequence / 60Hz / 415V 2644: Resets 2-Wire Sequence / 60Hz / 440V 2646: Resets 2-Wire Sequence / 60Hz / 460V 3538: Resets 3-Wire Sequence / 50Hz / 380V 3541: Resets 3-Wire Sequence / 50Hz / 415V 3544: Resets 3-Wire Sequence / 50Hz / 440V 3546: Resets 3-Wire Sequence / 50Hz / 460V 3638: Resets 3-Wire Sequence / 60Hz / 380V 3641: Resets 3-Wire Sequence / 60Hz / 415V 3644: Resets 3-Wire Sequence / 60Hz / 440V 3646: Resets 3-Wire Sequence / 60Hz / 460V | Default: 0 Range: 9999 |
| A1-04 | Password | Set password to parameter A1-05 and enter the password to parameter A1-04 to unlock it. | Default : 0000 Min.: 0000 Max.: 9999 |
| A1-05 | Password Setting | Parameters A1-01 to A1-03, A1-06, A2-01 to A2-32 cannot be edited until correct password is entered to A1-04 | |
| A1-06 | ND/HD Selection | 0 : Heavy Duty (HD) 1 : Normal Duty (ND) | Default: 0 Range: 0, 1 |

| Parameter | Name | Description | Setting Range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------|---------------------------------------|--|--|---------|--------------------------------|-----------|---------|------|-------|-------|-----------------------------|-------|-------|--------------------------------|-------|-------|-----------------------|-------|--|--|-------|-------|-------------------|-------|--|--|-------|-------|-------------------|-------|--|--|-------|-------|--------------------------|-------|--|--|-------|-------|--------------------------|-------|--|--|-------|-------|-----------------|-------|--|--|-------|-------|----------------|-------|--|--|-------|-------|--------------|-------|--|--|-------|-------|---|-------|--|--|-------|-------|-------------------------|-------|--|--|-------|-------|----------------------------|-------|--|--|-------|-------|----------------------------|-------|--|--|-------|-------|------------------------------------|-------|--|--|-------|-------|--------------------------------|-------|--|--|-------|-------|------------------------------------|-------|--|--|--|
| A2: User-Defined Parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-00 to A2-31 | User-Defined Parameters 1 to 32 | Selects up to 32 parameters and assigns them to parameter A2-00 to A2-31. Saved parameters can be viewed in User-Defined Parameter Access. To assign specific parameters to A2-00 to A2-31, set parameter A1-01 to 2. The saved parameters A2-00 to A2-31 can only be viewed if A1-01 is set to 1 | Range: A1-00 to U4-08 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Parameter</th> <th>Default</th> <th>Name</th> <th>Parameter</th> <th>Default</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>A2-00</td> <td>b1-00</td> <td>Frequency Command Selection</td> <td>A2-16</td> <td>E3-07</td> <td>Terminal A2 Function Selection</td> </tr> <tr> <td>A2-01</td> <td>b1-01</td> <td>Run Command Selection</td> <td>A2-17</td> <td></td> <td></td> </tr> <tr> <td>A2-02</td> <td>C1-00</td> <td>Acceleration Time</td> <td>A2-18</td> <td></td> <td></td> </tr> <tr> <td>A2-03</td> <td>C1-01</td> <td>Deceleration Time</td> <td>A2-19</td> <td></td> <td></td> </tr> <tr> <td>A2-04</td> <td>C3-00</td> <td>Torque Compensation Gain</td> <td>A2-20</td> <td></td> <td></td> </tr> <tr> <td>A2-05</td> <td>d1-02</td> <td>Maximum Output Frequency</td> <td>A2-21</td> <td></td> <td></td> </tr> <tr> <td>A2-06</td> <td>d1-03</td> <td>Maximum Voltage</td> <td>A2-22</td> <td></td> <td></td> </tr> <tr> <td>A2-07</td> <td>d1-04</td> <td>Base Frequency</td> <td>A2-23</td> <td></td> <td></td> </tr> <tr> <td>A2-08</td> <td>d1-05</td> <td>Base Voltage</td> <td>A2-24</td> <td></td> <td></td> </tr> <tr> <td>A2-09</td> <td>o2-06</td> <td>Operation Direction at Power Up when using Keypad</td> <td>A2-25</td> <td></td> <td></td> </tr> <tr> <td>A2-10</td> <td>b1-10</td> <td>Run Command at Power Up</td> <td>A2-26</td> <td></td> <td></td> </tr> <tr> <td>A2-11</td> <td>E2-00</td> <td>Relay 1 Function selection</td> <td>A2-27</td> <td></td> <td></td> </tr> <tr> <td>A2-12</td> <td>E2-01</td> <td>Relay 2 Function selection</td> <td>A2-28</td> <td></td> <td></td> </tr> <tr> <td>A2-13</td> <td>E3-00</td> <td>Terminal A1 Signal Level Selection</td> <td>A2-29</td> <td></td> <td></td> </tr> <tr> <td>A2-14</td> <td>E3-01</td> <td>Terminal A1 Function Selection</td> <td>A2-30</td> <td></td> <td></td> </tr> <tr> <td>A2-15</td> <td>E3-06</td> <td>Terminal A2 Signal Level Selection</td> <td>A2-31</td> <td></td> <td></td> </tr> </tbody> </table> | Parameter | Default | Name | Parameter | Default | Name | A2-00 | b1-00 | Frequency Command Selection | A2-16 | E3-07 | Terminal A2 Function Selection | A2-01 | b1-01 | Run Command Selection | A2-17 | | | A2-02 | C1-00 | Acceleration Time | A2-18 | | | A2-03 | C1-01 | Deceleration Time | A2-19 | | | A2-04 | C3-00 | Torque Compensation Gain | A2-20 | | | A2-05 | d1-02 | Maximum Output Frequency | A2-21 | | | A2-06 | d1-03 | Maximum Voltage | A2-22 | | | A2-07 | d1-04 | Base Frequency | A2-23 | | | A2-08 | d1-05 | Base Voltage | A2-24 | | | A2-09 | o2-06 | Operation Direction at Power Up when using Keypad | A2-25 | | | A2-10 | b1-10 | Run Command at Power Up | A2-26 | | | A2-11 | E2-00 | Relay 1 Function selection | A2-27 | | | A2-12 | E2-01 | Relay 2 Function selection | A2-28 | | | A2-13 | E3-00 | Terminal A1 Signal Level Selection | A2-29 | | | A2-14 | E3-01 | Terminal A1 Function Selection | A2-30 | | | A2-15 | E3-06 | Terminal A2 Signal Level Selection | A2-31 | | | |
| Parameter | Default | Name | Parameter | Default | Name | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-00 | b1-00 | Frequency Command Selection | A2-16 | E3-07 | Terminal A2 Function Selection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-01 | b1-01 | Run Command Selection | A2-17 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-02 | C1-00 | Acceleration Time | A2-18 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-03 | C1-01 | Deceleration Time | A2-19 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-04 | C3-00 | Torque Compensation Gain | A2-20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-05 | d1-02 | Maximum Output Frequency | A2-21 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-06 | d1-03 | Maximum Voltage | A2-22 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-07 | d1-04 | Base Frequency | A2-23 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-08 | d1-05 | Base Voltage | A2-24 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-09 | o2-06 | Operation Direction at Power Up when using Keypad | A2-25 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-10 | b1-10 | Run Command at Power Up | A2-26 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-11 | E2-00 | Relay 1 Function selection | A2-27 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-12 | E2-01 | Relay 2 Function selection | A2-28 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-13 | E3-00 | Terminal A1 Signal Level Selection | A2-29 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-14 | E3-01 | Terminal A1 Function Selection | A2-30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-15 | E3-06 | Terminal A2 Signal Level Selection | A2-31 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A2-32 | User-Defined Parameter Automatic Save | Saves the most recently edited parameters. 0 : Do not save list of recently edited parameters 1: Save list of recently edited parameters | Default: 0 Range: 0, 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Group b, Application | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| b1: Operation Mode Selection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| b1-00 <8> | Frequency Command Selection1 | 0 : Keypad 1 : Control Circuit Terminal (Analog Input) 2 : Terminal Up/Down 3 : Modbus Communication 4 : Pulse Train Input (Including PWM signal input) 5 : Automatic operation 6: Expansion card | Default: 0 Min.: 0 Max.: 5 Remarks: The maximum number of models above F3: 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Parameter | Name | Description | Setting Range |
|-----------|--|--|--|
| b1-01 | Run Command Selection 1 | 0: Keypad 1: Control Circuit Terminal (Sequence Control Input) 2: Modbus Communication 3: Expansion card | Default: 0 Min.: 0 Max.: 2 Remarks: The Max. value for F3 and above is 3 |
| b1-02 | Stopping Method Selection | 0: Ramp to Stop 1: Coast to Stop 2: DC Braking to Stop 3: Coast to Stop with Timer | Default: 0 Min.: 0 Max.: 3 |
| b1-03 | Reverse Rotation Selection | 0: Reverse Rotation Enabled Drive accepts a run command of both forward and reverse directions 1: Reverse Rotation disabled Drive can accept only run command of forward direction | Default: 0 Range: 0, 1 |
| b1-04 | Retain | | |
| b1-05 | Run Command Action after Switch | 0: Ignore Active Run Command at the New Source If a Run command at the new source is active, the drive will not start or the drive will stop operation if it was running when switching from the old source to the new source. The drive can start only when the Run command is removed and given again. 1: Accept Active Run Command at the New Source If a run command at the new source is active, the drive will accept it and run the motor immediately right after switching from the old source to the new source. | Default: 0 Min.: 0 Max.: 1 |
| b1-06 | Run Command Selection during Programming | 0: Run command disabled during Programming 1: Run command enabled during Programming 2: Prohibit programming during run The programming mode cannot be displayed during run except for monitoring parameter Group U. | Default: 0 Min.: 0 Max.: 2 |

| Parameter | Name | Description | Setting Range |
|------------------------|---|---|--|
| b1-07 <8> | Frequency Command Selection 2 | Enabled while E1-00 to E1-07 is set to 4 and the DIP switch is set to OFF 0 : Keypad 1 : Control Circuit Terminal (Analog Input) 2 : Terminal Up/Down 3 : Modbus Communication 4 : Pulse Train Input (Including PWM signal input) 5 : Automatic operation 6 : Expansion card | Default : 0 Min. : 0 Max. : 5 Remarks : The maximum number of models above F3: 6 |
| b1-08 | Run Command Selection 2 | Enabled while E1-00 to E1-07 is set to 4 and the DIP switch is set to OFF 0 : Keypad 1 : Control Circuit Terminal (Sequence Control Input) 2 : Modbus Communication 3 : Expansion card | Default : 0 Min. : 0 Max. : 2 Remarks : The Max. value for F3 and above is 3 |
| b1-09 | Frequency superposition Selection | 0 : Disabled 1 : Enabled | Default : 0 Min. : 0 Max. : 1 |
| b1-10 | Run Command at Power up | Determines to accept or ignore an active Run command from Remote during power up. 0 : Ignore Drive ignores an active run command during power up 1 : Accept Drive accepts an active run command at power up and runs the motor immediately. | Default : 0 Min. : 0 Max. : 1 |
| b1-12 | Local/ Remote switching Enable during Operating | 0 : Disabled 1 : Enabled | Default : 0 Min. : 0 Max. : 1 |
| b2 : DC Braking | | | |
| b2-00 | Zero Speed Holding (DC Braking) Start Level | Sets the start frequency for Zero Speed Holding (DC braking). Enabled when b1-02 (Stopping Method Selection) is set to 0 (Ramp to Stop) | Default : 0.5Hz Min. : 0.0Hz Max. : 400.0Hz |
| b2-01 | DC Braking Current | Sets the DC braking current as a percentage of the drive rated current | Default : 0% Min. : 0% Max. : 100% |

| Parameter | Name | Description | Setting Range |
|-------------------------|--------------------------------|---|---|
| b2-02 | DC Braking Time at Start | Sets the DC braking time at start to stop a coasting motor before restarting it or to apply braking torque at start when high starting torque is needed. Disabled when set to 0.00. | Default : 0.00 s Min. : 0.00 s Max. : 99.99 s |
| b2-03 | DC Braking Time at Stop | Sets the DC braking time at stop to stop a motor rotating with high inertia. Disabled when set to 0.00. | Default : 0.00s Min. : 0.00s Max. : 99.99s |
| b3: Speed Search | | | |
| b3-00 | Speed Search Setting | 0 : Disabled 1 : Enabled and searched from the highest frequency 2 : Enabled and searched from the frequency command 3 : Retain 4 : Retain | Default : 0 Min. : 0 Max. : 2 |
| b3-01 | Speed Search Operating Current | Sets the current level as a percentage of the drive rated current below which Speed Search is deactivated. | Default : 120% Min. : 30 % Max. : 140% |
| b3-02 | Voltage Recovery Time | Sets the search speed in the output voltage restoring to the time set v / f voltage curve required | Default : 0.6s Min. : 0.3s Max. : 5.0s Remarks: Default setting of 60HP (included) or above : 1.0 s |
| b3-03 | Retain | | |
| b3-04 | Speed search deceleration time | Sets the search speed in the deceleration time (The maximum output frequency to the minimum output frequency deceleration time) | Default : 2.0s Min. : 0.1s Max. : 10.0s Remarks : Default setting of 40HP (included) or above : 3.5 s |
| b3-05 <9> | Search speed in V / f | In order to reduce the speed of search output current by the V / f curve calculated by multiplying the voltage set value b3-05 by adjusting the setting, the speed can be suppressed search output current. | Default : 100% Min. : 10 % Max. : 100% Remarks : Default setting of 60HP (included) or above : 80% |

| Parameter | Name | Description | Setting Range |
|---------------------------|---------------------------------|---|---|
| b4: Timer Function | | | |
| b4-00 | Timer Function On-Delay Time | Sets the on-delay and off-delay time to switch on/off the timer output. | Default : 0.1 s Min. : 0.1 s Max. : 3000.0 s |
| b4-01 | Timer Function Off-Delay Time | | Default : 0.1 s Min. : 0.1 s Max. : 3000.0 s |
| b5: PID Control | | | |
| b5-00<8> | PID Control Setting | 0 : PID Control Disabled 1 : PID Control Enabled (D Control for Deviation Signal U4-01) 2 : PID Control Enabled (D Control for Feedback Signal U4-05) 3 : PID Control Enabled (Frequency Command + PID Output from D Controlled Deviation) 4 : PID Control Enabled (Frequency Command + PID Output from D Controlled Feedback) 5 : PID Control Disabled · but b5-14/b5-15 (PID Sleep) and b5-29/b5-30(PID Wake-up) Enabled | Default : 0 Min. : 0 Max. : 5 |
| b5-01 <4> | Proportional Gain Setting (P) | Sets the P gain for PID input. | Default : 1.00 Min. : 0.00 Max. : 25.00 |
| b5-02 <4> | Integral Time Setting (I) | Deviation appears between PID target value and feedback value when using only proportional control. To reduce the deviation, set integral time (I). | Default : 1.0 s Min. : 0.0 s Max. : 360.0 s |
| b5-03 <4> | Integral Time (I) Limit Setting | Sets the maximum output from the I (integral) control as a percentage of the maximum frequency (d1-02) | Default : 100.0% Min. : 0.0% Max. : 100.0% |
| b5-04 <4> | Derivative Time (D) | Sets derivative time for D control. | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |
| b5-05 <4> | PID Output Limit | Sets the maximum output from PID control as a percentage of the maximum frequency. | Default : 100.0% Min. : 0.0% Max. : 100.0% |

| Parameter | Name | Description | Setting Range |
|-----------|--|---|---|
| b5-06 <4> | PID Bias Voltage Adjustment | Sets the PID bias voltage adjustment as a percentage of the maximum frequency to add to the PID control output. | Default : 0.0% Min. : -100.0% Max. : 100.0% |
| b5-07 <4> | PID Primary Delay Time | Sets the delay time for the PID output filter. | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |
| b5-08 | PID Output Selection | 0 : Normal PID Output 1 : Reverse PID Output Reverses the +/- sign of the PID output | Default : 0 Min. : 0 Max. : 1 |
| b5-09 | PID Output Gain | Sets a PID output gain | Default : 1.00 Min. : 0.00 Max. : 25.00 |
| b5-10 | PID Output Reverse Selection | Determines whether or not a negative PID output reverses the drive rotating direction. 0 : Reverse Disabled 1 : Reverse Enabled | Default : 0 Min. : 0 Max. : 1 |
| b5-11 | PID Feedback Low /High Detection Selection | 0 : Multi-Function Output Only 1 : Feedback Low /High Alarm The drive continues operation when an alarm is displayed) 2 : Feedback Low /High Fault A fault will cause the drive to stop the motor. 3 : Multi-Function Output only when PID is Disabled Same action as b5-11=0. 4 : Feedback Low /High Alarm (detection disabled when PID is disabled) 5 : Feedback Low /High Fault (detection disabled when PID is disabled) 6 : Multi-Function Output (Keep running without an alarm displayed) 7 : Multi-Function Output Only (detection working when drive running or not) | Default : 0 Min. : 0 Max. : 7 |
| b5-12 | PID Feedback Low Detection Level | Sets the PID feedback level used for detection. When the PID feedback falls below this level for longer than the time set to b5-13, PID feedback loss will be detected. | Default : 0% Min. : 0% Max. : 100% |

| Parameter | Name | Description | Setting Range |
|-----------|-----------------------------------|--|---|
| b5-13 | PID Feedback Low Detection Time | Sets the PID feedback time used for detection. When the PID feedback falls below the level set to b5-12 for longer than this time, PID feedback loss will be detected. | Default : 1.0 s Min. : 0.0 s Max. : 25.5 s |
| b5-14 | PID Sleep Start Level | Sets the PID level to trigger the drive to sleep. | Default : 0.0Hz Min. : 0.0 Hz Max. : <5> |
| b5-15 | PID Sleep Delay Time | Sets the delay time used to activate / deactivate the PID Sleep function. When this parameter is set to 0.0, PID Sleep function will be stopped. | Default : 0.0 s Min. : 0.0 s Max. : 25.5 s |
| b5-16 | PID Command Acc./Dec. Time | Sets the PID command acceleration /deceleration time used for PID target soft-start function. | Default : 0.0 s Min. : 0.0 s Max. : 20.0 s |
| b5-17 | PID Target Selection | 0 : PID Target Disabled 1 : PID Target Enabled | Default : 0 Min. : 0 Max. : 1 |
| b5-18 | PID Target Value | Sets the PID target value as a percentage of the maximum output frequency when b5-17=1 and no other analog input sets the PID Target. | Default : 0.00% Min. : 0.00% Max. : 100.00% |
| b5-19 | PID Target Value Units | 0 : 0.01Hz 1 : 0.01% (Maximum Frequency is 100%) 2 : r/min. (Number of Motor Poles must be set) 3 : User Defined (Defined by b5-24 and b5-25) | Default : 1 Min. : 0 Max. : 3 |
| b5-20 | PID Output Lower Limit | Sets the lower limit as a percentage of the maximum output frequency set in d1-02 for PID output. | Default : 0.0% Min. : -100.0% Max. : 100.0% |
| b5-21 | PID Input Limit | The higher PID Input value is, the higher PID output value will be. Sets this parameter to limit the PID input value. | Default : 1000.0% Min.: 0.0% Max.: 1000.0% |
| b5-22 | PID Feedback High Detection Level | Sets the level for PID feedback high detection as a percentage of the maximum output frequency. PID feedback high will be detected when the feedback exceeds the level set in b5-22 for longer than the time set in b5-23. | Default : 100% Min. : 0% Max. : 100% |

| Parameter | Name | Description | Setting Range |
|----------------------------|--------------------------------------|---|--|
| b5-23 | PID Feedback High Detection Time | Sets the time for PID feedback high detection. PID feedback high will be detected when the feedback exceeds the level set in b5-22 for longer than the time set in b5-23. | Default : 1.0 s Min. : 0.0 s Max. : 25.5 s |
| b5-24 | PID Target Display Value | Sets a value to display to U4-00 and U4-03 when the drive runs at the maximum output frequency | Determined by b5-19 Min. : 1 Max. : 60000 |
| b5-25 | PID Target Display Digits | Sets the number of decimal places to display. 0 : No Decimal Places 1 : 1 Decimal Place 2 : 2 Decimal Places 3 : 3 Decimal Places | Determined by b5-19 Min. : 0 Max. : 3 |
| b5-26 | Frequency Command Display During PID | 0 : Displays frequency command after the PID compensation. 1 : Displays frequency command before the PID compensation. | Default : 0 Min. : 0 Max. : 1 |
| b5-27 | PID Output Direction 2 | Sets the direction when PID output value is minus. 0 : Reverse is not allowed. 1 : Reverse is allowed. | Default : 1 Min. : 0 Max. : 1 |
| b5-28 | PID Disconnection Output Frequency | When a PID feedback disconnection alarm occurs, the drive will run at the frequency set to b5-28, and return to PID control when disconnection alarm is reset. | Default : 30.0 Hz Min. : 0.0Hz Max. : <5> |
| b5-29 <8> | PID Wake-up Level | Sets the PID Wake-up level | Default : 0.0 Hz Min. : 0.0 Hz Max. : <5> |
| b5-30 <8> | PID Wake-up delay time | Sets the PID Wake-up delay time | Default : 0.0 s Min. : 0.0 s Max. : 25.5 s |
| b6 : Dwell Function | | | |
| b6-00 | Dwell Frequency at Start | Sets the frequency to b6-00 used to be held for the time set in b6-01 during acceleration. | Default : 0.0 Hz Min. : 0.0 Hz Max. : <5> |
| b6-01 | Dwell Time at Start | | Default : 0.0 s Min. : 0.0 s Max. : 10.0 s |

| Parameter | Name | Description | Setting Range |
|---|--|--|---|
| b6-02 | Dwell Frequency at Stop | Sets the frequency to b6-02 used to be held for the time set in b6-03 during deceleration. | Default : 0.0Hz Min. : 0.0 Hz Max. : <5> |
| b6-03 | Dwell Time at Stop | | Default : 0.0 s Min. : 0.0 s Max. : 10.0 s |
| b9 : Position Control / Zero Speed Holding | | | |
| b9-02 | Zero Speed Holding On/ Off | 0 : Zero Speed Holding Disabled. Drive coasts to stop when the frequency is zero. 1 : Zero Speed Holding Enabled. Zero Speed Holding starts when the frequency is zero. The holding current is set in b2-01 and it will be limited to below 20% of the drive rated current. | Default : 0 Min. : 0 Max. : 1 |
| b9-03 | Zero Speed Holding Time | Sets the Zero Speed Holding time. Drive will coast to stop when the Zero Speed Holding time is longer than this setting. Set 00.00 to disable Zero Speed Holding or set 99.99 to enable this function continuously. | Default : 0.10sec Min. : 00.00sec Max. : 99.99sec |
| Group C, Tuning | | | |
| C1 : Acc./Dec. Time | | | |
| C1-00 <4> | Acceleration Time 1 | Sets the time that the drive accelerates from 0Hz to the maximum output. | Default : depends on the kW 7.5kW and below:10s 11kW and 15kW: 15s 18.5kW and above:20s Min. : 0.0 s Max. : 6000.0 s |
| C1-01 <4> | Deceleration Time 1 | Sets the time that the drive decelerates from the maximum output to 0Hz. | |
| C1-02 <4> | Acceleration Time 2 | Sets the time that the drive accelerates from 0Hz to the maximum output. | |
| C1-03 <4> | Deceleration Time 2 | Sets the time that the drive decelerates from the maximum output to 0Hz. | |
| C1-04 <4> | Acceleration Time 3 (Acceleration Time 1 for Motor 2) | Sets the time that the drive accelerates from 0Hz to the maximum output. | |
| C1-05 <4> | Deceleration Time 3 (Deceleration Time 1 for Motor 2) | Sets the time that the drive decelerates from the maximum output to 0Hz. | |

| Parameter | Name | Description | Setting Range |
|------------------------------------|--|--|---|
| C1-06 <4> | Acceleration Time 4 (Acceleration Time 2 for Motor 2) | Sets the time that the drive accelerates from 0Hz to the maximum output. | |
| C1-07 <4> | Deceleration Time 4 (Deceleration Time 2 for Motor 2) | Sets the time that the drive decelerates from the maximum output to 0Hz. | |
| C1-08 | Fast Stop Time | Sets the time to stop the drive faster. | |
| C1-09 | Acc./Dec. Time Unit Selection | Set the units of time for C1-00 to C1-08. 0 : 0.01 s (0.00 to 600.00 s) 1 : 0.1 s (0.00 to 6000.0 s) | Default : 1 Min. : 0 Max. : 1 |
| C1-10 | Acc./Dec. Time Switch Frequency | Sets the frequency level. The drive will switch the acceleration and deceleration time at this level. | Default : 0.0 Hz Min. : 0.0 Hz Max. : <5> |
| C1-11 | Jog Acc. Time | Sets the time to accelerate from 0 Hz to Jog Frequency Command (L1-16). | Default : depends on the kW 7.5kW and below:10s 11kW and 15kW: 15s 18.5kW and above:20s Min. : 0.0 s Max. : 6000.0 s |
| C1-12 | Jog Dec. Time | Sets the time to decelerate from Jog Frequency Command (L1-16) to 0 Hz. | Default : depends on the kW 7.5kW and below:10s 11kW and 15kW: 15s 18.5kW and above:20s Min. : 0.0 s Max. : 6000.0 s |
| C2: S-Curve Characteristics | | | |
| C2-00 | S-Curve Characteristic at Acc. Start | Sets S-curve times for each acceleration or deceleration. Actual Acceleration Time = Determined Acc. Time+(C2-00+C2-01)/ 2 Actual Deceleration Time = Determined Dec. Time+(C2-02+C2-03) / 2 | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |
| C2-01 | S-Curve Characteristic at Acc. End | | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |
| C2-02 | S-Curve Characteristic at Dec. Start | | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |

| Parameter | Name | Description | Setting Range |
|---------------------------------|--|--|---|
| C2-03 | S-Curve Characteristic at Dec. End | | Default : 0.00 s Min. : 0.00 s Max. : 10.00 s |
| C3 : Torque Compensation | | | |
| C3-00 <4> | Torque Compensation Gain | Sets the gain for the motor 1 Torque compensation | Default : 0.50 Min. : 0.00 Max. : 2.50 |
| C3-02 <4> | Torque Compensation Primary Delay Time | Sets the Torque compensation primary delay time. | Default : 10 ms Min. : 0 ms Max. : 10000 ms |
| C5 : Slip Compensation | | | |
| C5-00 <4> | Slip Compensation Gain | Sets the slip compensation gain to improve the speed accuracy for heavy loads. | Default : The default value is 0.7 for A1-02 = 1 & D1-01 = F Others : 0 Min. : 0.0 Max. : 2.5 |
| C5-01 <4> | Slip Compensation Primary Delay Time | Sets the slip compensation primary delay time to stabilize the motor speed or to improve the speed response. | Default : 100 ms Min. : 0 ms Max. : 10000ms |
| C5-02 | Slip Compensation Limit | Sets the maximum slip compensation as percentage of the rated slip for motor 1. | Default : 200% Min. : 0 % Max. : 250 % |
| C6 : Carrier Frequency | | | |
| C6-00 | Carrier Frequency Selection | Sets the switching frequency of the drive output transistors. Adjust this setting to reduce audible noise and leakage current. 0 : Err 1 : Retain 2 : 2.0 kHz 3 : 3.0 kHz 4 : 4.0 kHz 5 : 5.0 kHz 6 : 6.0 kHz 7 : 7.0 kHz 8 : 8.0 kHz 9 : 9.0 kHz 10 : 10.0 kHz | Default: Determined by A1-02 and o2-03. Once A1-06 is redefined, the default will be changed accordingly Range: 0 to 15 |

| Parameter | Name | Description | Setting Range |
|-----------------------------------|---------------------------|--|--|
| | | 11 : 11.0 kHz 12 : 12.0 kHz 13 : 13.0 kHz 14 : 14.0 kHz 15 : 15.0 kHz | |
| C7 : SVVC Command | | | |
| C7-00 | Proportional Gain | This gain adjustment depending on the application field, if the load is heavy increase this value, otherwise reduce this value | Default : 100% Factory setting when D1-01 is not equal to F : 0 Minimum : 0% Maximum : 250% |
| C7-01 | SVVC mode slip adjustment | If the slip compensation is not obvious or the current is too large at low speed, the parameter can be adjusted to improve (low speed SVVC compensation constant correction) | Default : 100 Min. : 0 Max. : 250 |
| Group L, Frequency Command | | | |
| L1: Frequency Command | | | |
| L1-00 <4> | Frequency Command 1 | To use speed commands for each multi-step speed, set E1-□□ to 5, 6, 7 and 8 (multi-step speed command 1, 2, 3, 4). Sets E1-□□ to 9 for Jog frequency command. The upper limit is determined by d1-02 and L2-00. In PM Closed-Loop Vector Control, o1-00 will be automatically set to 1 with the unit set to %. When L2-00 (Frequency Upper Limit) is adjusted, the exceeded frequency in L1-00 to L1-15 will be automatically set to the upper limit determined in L2-00. | Default : 5.00Hz Min. : 0.00Hz Max. : <5> |
| L1-01 <4> | Frequency Command 2 | | Default : 8.00Hz Min. : 0.00Hz Max. : <5> |
| L1-02 <4> | Frequency Command 3 | | Default : 10.00Hz Min. : 0.00 Hz Max. : <5> |
| L1-03 <4> | Frequency Command 4 | | Default : 12.00Hz Min. : 0.00Hz Max. : <5> |
| L1-04 <4> | Frequency Command 5 | | Default : 15.00Hz Min. : 0.00Hz Max. : <5> |
| L1-05 <4> | Frequency Command 6 | | Default : 20.00Hz Min. : 0.00Hz Max. : <5> |
| L1-06 <4> | Frequency Command 7 | | Default : 25.00Hz Min. : 0.00Hz Max. : <5> |

| Parameter | Name | Description | Setting Range |
|--|-------------------------------|--|---|
| L1-07 <4> | Frequency Command 8 | To use speed commands for each multi-step speed, set E1-□□ to 5, 6, 7 and 8 (multi-step speed command 1, 2, 3, 4). Sets E1-□□ to 9 for Jog frequency command. The upper limit is determined by d1-02 and L2-00. In PM Closed-Loop Vector Control, o1-00 will be automatically set to 1 with the unit set to %. When L2-00 (Frequency Upper Limit) is adjusted, the exceeded frequency in L1-00 to L1-15 will be automatically set to the upper limit determined in L2-00. | Default : 30.00Hz Min. : 0.00Hz Max. : <5> |
| L1-08 <4> | Frequency Command 9 | | Default : 35.00Hz Min. : 0.00Hz Max. : <5> |
| L1-09 <4> | Frequency Command 10 | | Default : 40.00Hz Min. : 0.00Hz Max. : <5> |
| L1-10 <4> | Frequency Command 11 | | Default: 42.00Hz Min.: 0.00Hz Max.: <5> |
| L1-11 <4> | Frequency Command 12 | | Default : 45.00Hz Min. : 0.00Hz Max. : <5> |
| L1-12 <4> | Frequency Command 13 | | Default : 50.00Hz Min. : 0.00Hz Max. : <5> |
| L1-13 <4> | Frequency Command 14 | | Default : 50.00Hz Min. : 0.00Hz Max. : <5> |
| L1-14 <4> | Frequency Command 15 | | Default : 50.00Hz Min. : 0.00Hz Max. : <5> |
| L1-15 <4> | Frequency Command 16 | | Default : 50.00Hz Min. : 0.00Hz Max. : <5> |
| L1-16 <4> | Jog Frequency Command | | Sets the Jog frequency command. |
| L2 : Frequency Upper/ Lower Limit | | | |
| L2-00 | Frequency Command Upper Limit | Sets the upper limit | Default : d1-02 Min. : 0.0 Hz Max. : d1-02*110% |
| L2-01 | Frequency Command Lower Limit | Sets the lower limit as a percentage of the maximum output frequency | Default : 0.0Hz Min. : 0.0 Max. : d1-02*110% |

| Parameter | Name | Description | Setting Range |
|--|---|--|--|
| L3 : Jump Frequency | | | |
| L3-00 | Jump Frequency 1 | Sets the Jump frequency range to avoid operation at the speed causing resonance in the machinery. Set L3-00 to L3-03 to 0.0 Hz to disable Jump frequency. When setting more than 1 Jump frequency, follow the condition below. $L3-00 \leq L3-01 \leq L3-02$ | Default : 0.0 Hz Min. : 0.0 Max. : L2-00 |
| L3-01 | Jump Frequency 2 | | |
| L3-02 | Jump Frequency 3 | | |
| L3-03 | Jump Frequency Range | Sets the Jump frequency range to avoid. | Default : 1.00 Hz Min. : 0.00 Hz Max. : 20.0 Hz |
| L4 : Frequency Command Hold and Up/Down 2 Command | | | |
| L4-00 | Up/ Down Frequency Command Hold | Determines whether or not to save the frequency command or the frequency bias (Up/Down 2) value when the Stop command is entered or the power supply is shut off. 0 : Clear the Up/Down frequency at stop 1 : Save the Up/Down frequency at stop 2 : Accept the Up/Down frequency at stop | Default : 0 Range : 0, 1, 2 |
| L4-01 <4> | Frequency Command Bias (Up/Down 2) | Sets the bias used to add to or subtract from the frequency command by Up/Down 2. | Default : 0.00 Hz Min. : 0.00 Hz Max. : 99.99 Hz |
| L4-02 <4> | Frequency Command Acc./Dec Setting (Up/Down 2) | Sets the acceleration/deceleration times to increase or decrease the frequency command bias for Up/Down 2. 0 : Current Acc./Dec. Time 1 : Acc./Dec. Time 4 set in C1-06 and C1-07 | Default : 0 Range : 0, 1 |
| L4-03 <4> | Up/Down Frequency Command Save | Saves the frequency command from Up/Down 1 or Up/Down 2 | Default : 0.00Hz Min. : 0.00 Hz Max. : <5> |
| L4-04 | Frequency Command Hold | 0 : Disabled 1 : Enabled | Default : 0 Range : 0, 1 |
| L6 : Offset Frequency | | | |
| L6-00 <4> | Offset Frequency 1 | Sets the offset value as a percentage of the maximum output frequency to add to or subtract from the frequency command. Select the offset frequency in E1-□□= 53, 54 and 55 (Offset Frequency 1 to 3). | Default : 0.0% Min. : -100.0% Max. : 100.0% |

| Parameter | Name | Description | Setting Range |
|---------------------------------|------------------------------------|--|---|
| L6-01 <4> | Offset Frequency 2 | Sets the offset value as a percentage of the maximum output frequency to add to or subtract from the frequency command. Select the offset frequency in E1-□□= 53, 54 and 55 (Offset Frequency 1 to 3). | Default : 0.0% Min. : -100.0% Max. : 100.0% |
| L6-02 <4> | Offset Frequency 3 | Sets the offset value as a percentage of the maximum output frequency to add to or subtract from the frequency command. Select the offset frequency in E1-□□= 53, 54 and 55 (Offset Frequency 1 to 3). | Default : 0.0% Min. : -100.0% Max. : 100.0% |
| L7 : Automatic operation | | | |
| L7-00 <8> | Automatic operation mode selection | 0 : Disabled 1 : One cycle mode, when the mode is end, the motor is stop, and then reset to restart 2 : One cycle mode, when the mode is end, the motor is stop, and then restart from final program 3 : One cycle mode, the mode is operating to end according to last frequency of program, and then reset to restart 4 : One cycle mode, the mode is running to end according to last frequency of program, and then restart from final program 5 : Continuous cycle mode, reset to restart 6 : Continuous cycle mode, restart from final program | Default : 0 Min. : 0 Max. : 6 |
| L7-01<8> | 1 st operating time | Automatic operation of each segment time | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-02<8> | 2 nd operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-03<8> | 3 rd operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-04<8> | 4 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |

| Parameter | Name | Description | Setting Range |
|-----------|---------------------------------|--|--|
| L7-05<8> | 5 th operating time | Automatic operation of each segment time | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-06<8> | 6 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-07<8> | 7 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-08<8> | 8 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-09<8> | 9 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-10<8> | 10 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-11<8> | 11 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-12<8> | 12 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-13<8> | 13 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-14<8> | 14 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-15<8> | 15 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |
| L7-16<8> | 16 th operating time | | Default : 0.0 Min. : 0.0 Max. : 6000.0 |

| Parameter | Name | Description | Setting Range |
|-----------|--------------------------------------|---|-------------------------------------|
| L7-17<8> | 1 st operating direction | Automatic operation of each segment direction 0 : Stop 1 : Forward 2 : Reverse | Default : 0 Min. : 0 Max. : 2 |
| L7-18<8> | 2 nd operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-19<8> | 3 rd operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-20<8> | 4 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-21<8> | 5 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-22<8> | 6 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-23<8> | 7 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-24<8> | 8 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-25<8> | 9 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-26<8> | 10 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-27<8> | 11 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-28<8> | 12 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-29<8> | 13 th operating direction | | Default : 0 Min. : 0 Max. : 2 |

| Parameter | Name | Description | Setting Range |
|----------------------------------|--------------------------------------|--|---|
| L7-30<8> | 14 th operating direction | Automatic operation of each segment direction 0 : Stop 1 : Forward 2 : Reverse | Default : 0 Min. : 0 Max. : 2 |
| L7-31<8> | 15 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-32<8> | 16 th operating direction | | Default : 0 Min. : 0 Max. : 2 |
| L7-33<8> | The unit of operating time selection | 0 : sec 1 : hr | Default : 0 Min. : 0 Max. : 1 |
| Group d, Motor Parameters | | | |
| d1 : V/F Characteristics | | | |
| d1-00 | Input Voltage Setting | Sets the input voltage of the drive. Always set the input voltage of the drive (not motor) to this parameter. | Default : depends on A1-03 Min. : 155 V Max. : 255V <3> |
| d1-01 | V/F Pattern Selection | 0 : 50 Hz (Constant Torque Characteristic 1) 1 : 60 Hz (Constant Torque Characteristic 2) 2 : 60 Hz (Constant Torque Characteristic 3), 50 Hz base 3 : 72 Hz (Constant Torque Characteristic 4), 60 Hz base 4 : 50 Hz (Derated Torque Characteristic 1) 5 : 50 Hz (Derated Torque Characteristic 2) 6 : 60 Hz (Derated Torque Characteristic 3) 7 : 60 Hz (Derated Torque Characteristic 4) 8 : 50 Hz (High Starting Torque Characteristic 1) 9 : 50 Hz (High Starting Torque Characteristic 2) A : 60 Hz (High Starting Torque Characteristic 3) B : 60 Hz (High Starting Torque Characteristic 4) C : 90 Hz, 60 Hz base D : 120 Hz, 60 Hz base E : 180 Hz, 60 Hz base F : 60Hz (Constant Torque Characteristic) (Default) | Default : F Range: 0 to 9; A to F |

| Parameter | Name | Description | Setting Range |
|-----------|-----------------------------------|--|---|
| d1-02 | Maximum Output Frequency | When d1-01 \leq E, parameters d1-02 to d1-11 can be used to monitor the V/F pattern. When d1-01 = F, parameters d1-02 to d1-11 can be used to create a V/F pattern. | Default : <1> Min. : 25.0 Hz Max. : 400.0 Hz |
| d1-03 | Maximum Voltage | | Default : <1> Min. : 0.0 V Max. : 255.0 V <3> |
| d1-04 | Base Frequency | | Default: <1> Min.: 0.0 Hz Max.: Defined by d1-02 |
| d1-05 | Base Voltage | | Default : <1> Min. : 0.0 V Max. : 255.0 V <3> |
| d1-06 | Middle Output Frequency | | Default: <1> Min.: 0.0 Hz Max.: Defined by d1-02 |
| d1-07 | Middle Output Frequency Voltage | | Default : <1> Min. : 0.0 V Max. : 255.0 V <3> |
| d1-08 | Minimum Output Frequency | | Default: <1> Min.: 0.0 Hz Max.: Defined by d1-02 |
| d1-09 | Minimum Output Frequency Voltage | | Default : <1> Min. : 0.0 V Max. : 255.0 V <3> |
| d1-10 | Middle Output Frequency 2 | | Default: 0.0 Hz Min.: 0.0 Hz Max.: Defined by d1-02 |
| d1-11 | Middle Output Frequency Voltage 2 | | Default: 0.0 V Min.: 0.0 V Max.: 255.0 V <3> |
| d1-23 | Mode setting for V/F separation | | 0 : V/F 1 : V/F complete separation 2 : V/F half separation |
| d1-24 | Voltage source for V/F separation | 0 : Setting by d1-25 1 : Analog setting corresponds to the E3-01 or E3-07 = 20 | Default : 0 Min. : 0 Max. : 1 |

| Parameter | Name | Description | Setting Range |
|------------------------------|--|--|---|
| d1-25 | Voltage digital setting for V/F separation | Setting voltage digital for V/F separation | Default : A1-03 Min. : 0V Max.:Defined to the rated motor voltage |
| d1-26 | Voltage rise time of V/F separation | Setting voltage rise time for V/F separation | Default : depends on the HP 10HP and below : 10s 15HP and 20HP : 15s 25HP and above : 20s Min. : 0.1 s Max. : 1000.0 s |
| d1-27 | Voltage decline time of V/F separation | Setting voltage decline time for V/F separation | Default : depends on the HP 10HP and below : 10s 15HP and 20HP : 15s 25HP and above : 20s Min. : 0.1 s Max. : 1000.0 s |
| d1-28 | Stop mode selection upon V/F separation | 0: Frequency and voltage declining to 0 independently 1: Frequency declining to 0 after voltage declines to 0 | Default : 0 Min. : 0 Max. : 1 |
| d2 : Motor Parameters | | | |
| d2-00 | Motor Rated Current | Sets the motor rated current. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 10% of drive rated current Max. : 200% of drive rated current |
| d2-01 | Motor Rated Speed (For Slip Compensation) | Sets the motor rated speed used for slip compensation. This will be set automatically during Auto-Tuning. Alarm OPE17 will be detected when this value is set incorrectly. | Default : o2-03, A1-06 Min. : 0 rpm Max. : 60000 rpm |
| d2-02 | Motor No-Load Current | Sets the motor no-load current. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 0.0 A Max. : d2-00 (excluding d2-00) |
| d2-03 | Number of Motor Poles | Sets the number of motor poles. This will be set automatically during Auto-Tuning. | Default : 4 Min. : 2 Max. : 48 |

| Parameter | Name | Description | Setting Range |
|-----------|-------------------------------|--|--|
| d2-04 | Motor Line-to-Line Resistance | Sets the line-to-line resistance. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 0.000 Ω Max. : 65.000 Ω |
| d2-05 | Motor Leakage Inductance | Sets the voltage drop caused by the motor leakage inductance relative to the motor rated frequency and current. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 0.00 mH Max. : 650.00 mH |
| d2-06 | Motor Rotor Resistance | Sets the motor rotor resistance. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 0.000 Ω Max. : 65.000 Ω |
| d2-07 | Motor Mutual Inductance | Sets the motor mutual inductance. This will be set automatically during Auto-Tuning. | Default : o2-03, A1-06 Min. : 0.0 mH Max. : 6500.0 mH |
| d2-10 | Motor Rated Capacity | Sets the motor rated capacity. This will be set automatically during Auto-Tuning. (1HP = 0.746 kW) | Default : o2-03 Min. : 0.00 kW Max. : 650.00kW |

Group E, Multi-Function Terminals

E1 : Multi-Function Digital Inputs

| | | | |
|-------|--------------------------------|---|---|
| E1-00 | Terminal S1 Function Selection | 0 : 2-Wire Sequence Control (Forward/Stop) / 3-Wire Sequence Control (Stop) | Default : 0 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-01 | Terminal S2 Function Selection | 1 : 2-Wire Sequence Control (Reverse/Stop) / 3-Wire Sequence Control (Stop) | Default : 1 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-02 | Terminal S3 Function Selection | 2 : 3-Wire Sequence 3 : Local/Remote Selection 4 : Command Source 1/2 Selection | Default : 23 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-03 | Terminal S4 Function Selection | 5 to 8 : Multi-Step Speed Command 1 to 4 9 : Jog Frequency 10 : Up Command 11 : Down Command 12 : Up 2 Command 13 : Down 2 Command 14, 15 : FJOG/RJOG Command | Default : 39 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-04 | Terminal S5 Function Selection | 16 : Acc./Dec. Time Selection 1 17 : Acc./Dec. Time Selection 2 18 : Acc./Dec. Ramp Hold 19 : Base Block | Default : 5 Min. : 0 Max. : 0 to 75 / 100 to 175 |

| Parameter | Name | Description | Setting Range |
|---|--------------------------------|--|--|
| E1-05 | Terminal S6 Function Selection | 21 : Fast Stop (Normal Open) 23 to 38 : External Fault 39 : Fault Reset 40 : oH2 (AC drive Overheat Alarm) | Default : 6 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-06 | Terminal S7 Function Selection | 41 : Multi-Function Analog Input Selection 45 : Communication Mode 46 : PID Disable 47 : PID Integral Reset 48 : PID Integral Hold 49 : PID Soft-Start On/Off 50 : PID Input Characteristics Switch 51 : Motor 1/2 Switch 52 : Timer Input 53, 54, 55 : Offset Frequency 1/ 2/ 3 57 : KEB Command 1 (Normal Open) 60 : Program Lockout 61 : Analog Frequency Command Hold 63 : External Speed Search Command 65 : DC Braking 69 : Drive Enabled 74 : S7 is set to pulse input or PWM 75 : Reset automatic operation program | Default : 9 Min. : 0 Max. : 0 to 75 / 100 to 175 |
| E1-08 | Terminal command mode | 0 : Two-line / Three-line mode 1 1 : Two-line / Three-line mode 2 | Default : 0 Range : 0 to 1 |
| E1-09 | DI Digital Filtering Time | Digital Filtering Time | Default : 5 ms Range : 0 to 500ms |
| E2 : Multi-Function Digital Output | | | |
| E2-00 | Relay 1 Function Selection | 0 : During Run 1 : Zero Speed Holding 2 : Frequency (Speed) Agree 3 : User-Defined Frequency (Speed) Agree 4 : Drive Ready 5 : Uv (Undervoltage) Detection | Default : 11 Range : 0 to 52 / 100 to 152 |
| E2-01 | Relay 2 Function Selection | 6 : During Baseblock 7 : Retain 8 : Frequency Command Source 9 : Frequency Command Loss 10 : Run Command Source 11 : Fault | Default : 0 Range : 0 to 52 / 100 to 152 |

| Parameter | Name | Description | Setting Range |
|-----------|---|---|--|
| E2-02 | D1-DC Function Selection (Open Collector) | 12 : Communication Mode 13 : Alarm 14 : Fault Restart 15 : Timer Output 16 : Frequency (FOUT) Detection 1 17 : Frequency (FOUT) Detection 2 18 : Overvoltage/ Undervoltage Detection 1 (normal open) 20 : Overvoltage/ Undervoltage Detection 2 (normal open) 22 : During Reverse 23 : Motor 1/ 2 Selection 24 : During Regeneration 25 : During Restart 26 : Motor Overload Pre-Alarm (oL1) 27 : Drive Overheat Pre-Alarm (oH) 28 : Retain 29 : Mechanical Weakening Detection (Normal Open) 31 : During Torque Limit (Current Control) 32 : During Speed Limit 33 : During Speed Limit Circuit Operation (For Torque Control) 34 : Zero Speed Holding Stop 35 : During Frequency Output 36 : Drive Enabled 37 : Watt Hour Pulse Output 38 : Local/Remote Mode 39 : During Speed Search 40 : PID Feedback Low 41 : PID Feedback High 42 : During KEB Operation 43 : Retain 44 : During Fast Stop 45 : Internal Cooling Fan Alarm 49 : Brake control (Desired frequency attained) 50 : Set D1 as pulse output 51 : Automatic operation cycle is completed <8> 52 : Automatic operation phase is completed <8> 100 to 152 : 0 to 52 with Inverse Output | Default : 1 Range : 0 to 52 / 100 to 152 |

| Parameter | Name | Description | Setting Range |
|---|------------------------------------|--|---|
| E2-05 | Watt Hour Output Unit | Selects the output unit for the terminal assigned to E2-00 or E2-03=37 for one pulse signal. 0 : 0.1 kWh units 1 : 1 kWh units 2 : 10 kWh units 3 : 100 kWh units 4 : 1000 kWh units | Default : 0 Range : 0 to 4 |
| E2-06 | Relay 1 On Delay | The definition of a relay1 on delay time. | Default : 0.0s Min. : 0.0s Max. : 3600.0s |
| E2-07 | Relay 1 Off Delay | The definition of a relay1 off delay time. | Default : 0.0s Min. : 0.0s Max. : 3600.0s |
| E2-08 | Relay 2 On Delay | The definition of a relay2 on delay time. | Default : 0.0s Min. : 0.0s Max. : 3600.0s |
| E2-09 | Relay 2 Off Delay | The definition of a relay2 off delay time. | Default : 0.0s Min. : 0.0s Max. : 3600.0s |
| E3 : Multi-Function Analog Input | | | |
| E3-00 | Terminal A1 Signal Level Selection | 0 : 0 to 10V 1 : -10 to 10V | Default : 0 Range : 0, 1 |
| E3-01 | Terminal A1 Function Selection | 0 : Main Frequency Command 1 : Frequency Gain 2 : Output Frequency Lower Limit 3 : Auxiliary Frequency Command 4 : Output Voltage Bias 5 : Acc./Dec. Time Gain (Decrease Only) 6 : DC Braking (DB) Current 7 : Stall Prevention Level During Run 8 : PID Feedback 9 : PID Target 10 : Differential PID Feedback 11 : Overtorque/ Undertorque Detection 18 : Communication Mode 1 19 : Communication Mode 2 20 : V/F separation voltage | Default : 0 Range : 0 to 20 |

| Parameter | Name | Description | Setting Range |
|-----------|---|---|--|
| E3-02<4> | Terminal A1 Input Gain | Sets the terminal A1 input gain as a percentage when inputting 10V | Default : 100.0 % Min. : -999.9 % Max. : 999.9 % |
| E3-03<4> | Terminal A1 Input Voltage Bias | Sets the terminal A1 input voltage bias as a percentage when inputting 0V | Default : 0.0 % Min. : -999.9 % Max. : 999.9 % |
| E3-05 | Terminal A1 Input Filter Time | Sets the terminal A1 primary delay filter time, which can eliminate the interference | Default : 0.05 s Min. : 0.00 s Max. : 2.00 s |
| E3-06 | Terminal A2 Signal Level Selection | 0 : 0 to 20 mA 1 : 4 to 20 mA 2 : 0 to 10 V 3 : 0 to 5 V | Default : 1 Range : 0 to 3 |
| E3-07 | Terminal A2 Function Selection | 0 : Main Frequency Command 1 : Frequency Gain 2 : Output Frequency Lower Limit 3 : Auxiliary Frequency Command 4 : Output Voltage Bias 5 : Acc./Dec. Time Gain (Decrease Only) 6 : DC Braking (DB) Current 7 : Stall Prevention Level During Run 8 : PID Feedback 9 : PID Target Value 10: Differential PID Feedback 11 : Overtorque/ Undertorque Detection 18: Communication Mode 1 19 : Communication Mode 2 20 : V/F separation voltage | Default: 8 Range: 0 to 20 |
| E3-08<4> | Terminal A2 Input Gain | Sets the terminal A2 input gain as a percentage when inputting 10V | Default : 100.0 % Min. : -999.9 % Max. : 999.9 % |
| E3-09<4> | Terminal A2 Input Voltage Bias | Sets the terminal A2 input voltage bias as a percentage when inputting 0V. | Default : 0.0% Min. : -999.9 % Max. : 999.9 % |
| E3-10 | Terminal A2 (4- 20mA) Loss Action Selection | 0 : Disabled 1 : Run According to P4-03 Setting and Display ANL 2 : Disacceleration to 0Hz and Display ANL 3 : Drive Stop and Display ACE | Default : 0 Min. : 0 Max. : 3 |

| Parameter | Name | Description | Setting Range |
|--|--|--|--|
| E3-11 | Terminal A2 Input Filter Time | Sets the terminal A2 primary delay filter time, which can eliminate the interference. | Default : 0.05 s Min. : 0.00 s Max. : 2.00 s |
| E3-12 | Analog Input Terminal Enable/Disable Selection | Enables the analog inputs when Multi-Function Terminal Input E1-□□ = 41 (Multi-Function Analog Input Selection). 0 : Both Terminal A1 and A2 Disabled 1 : Only Analog Input Terminal A1 Enabled 2 : Only Analog Input Terminal A2 Enabled 3 : Both Terminal A1 and A2 Enabled | Default : 3 Range : 0 to 3 |
| E3-13 | Input lower limit of terminal A1 | Terminal A1 input lower limit (valid when A1 is not 4-20mA) | Default : 0.0 V Range : 0.0 V to 9.9V |
| E3-14 | Input lower limit of terminal A2 | Terminal A2 input lower limit (valid when A2 is not 4-20mA) | Default : 0.0 V Range : 0.0 V to 9.9V |
| E4 : Multi-Function Analog Output | | | |
| E4-00 | Terminal FM Signal Level Selection | 0 : 0 to 10 V 1 : -10 to 10 V | Default : 0 Range : 0, 1 |
| E4-01 | Terminal FM Monitor Selection | Selects the terminal FM monitor. 0 : Frequency Command 1 : Output Frequency 2 : Output Current 3 : Motor Speed 4 : Output Voltage 5 : DC Voltage 6 : Output Power 7 : Torque Command 8 : AI1 Input 9 : AI2 Input 10 : Soft Starter Output Frequency 11 : Pulse Train Input | Default : 1 Range : 0 to 11 |
| E4-02<4> | Terminal FM Monitor Gain | Sets the terminal FM monitor gain. | Default : 100.0 % Min. : -999.9 % Max. : 999.9 % |
| E4-03<4> | Terminal FM Monitor Voltage Bias | Sets the terminal FM voltage bias. | Default : 0.0 % Min. : -999.9 % Max. : 999.9 % |
| E4-04 | Terminal AM Signal Level Selection | 0 : 0 to 10 V 1 : 0 to 20 mA 2 : 4 to 20 mA | Default : 0 Range : 0, 1, 2 |

| Parameter | Name | Description | Setting Range |
|---------------------------------------|--------------------------------------|--|--|
| E4-05 | Terminal AM Monitor Selection | Selects the terminal AM monitor. 0 : Frequency Command 1 : Output Frequency 2 : Output Current 3 : Motor Speed 4 : Output Voltage 5 : DC Voltage 6 : Output Power 7 : Torque Command 8 : AI1Input 9 : AI2Input 10: Soft Starter Output Frequency 11 :Pulse Train Input | Default : 2 Range : 0 to 11 |
| E4-06<4> | Terminal AM Monitor Gain | Sets the terminal AM gain. | Default : 100.0 % Min. : -999.9 % Max. : 999.9 % |
| E4-07<4> | Terminal AM Monitor Voltage Bias | Sets the terminal AM voltage bias. | Default : 0.0 % Min. : -999.9 % Max. : 999.9 % |
| E5 : Pulse Train Input/ Output | | | |
| E5-00<7> | Pulse Train Input Function Selection | Selects the function for terminal RP. 0 : Frequency Command 1 : PID Feedback 2 : PID Target | Default : 0 Range : 0, 1, 2 |
| E5-01<4> <7> | Pulse Train Input Scaling | Sets the frequency equal to 100% frequency in Hz. | Default: 1440 Hz Min.: 100 Hz Max.: 50000 Hz |
| E5-02<4> <7> | Pulse Train Input Gain | Sets the level of the input gain to terminal RP. | Default : 100.0% Min. : 0.0 % Max. : 1000.0 % |
| E5-03<4> <7> | Pulse Train Input Voltage Bias | Sets the level of the input voltage bias when no signal (0Hz) is input to terminal RP. | Default : 0.0% Min. : -100.0 Max. : 100.0 |
| E5-04<4> <7> | Pulse Train Input Filter Time | Sets the pulse train input primary filter time in seconds. | Default : 0.10 s Min. : 0.00 s Max. : 2.00 s |
| E5-05 <7> | Pulse Train Input Minimum Frequency | Sets the minimum frequency detected by the pulse train input. Enabled when E5-00 = 0, 1, 2. | Default : 0.5 Hz Min. : 0.1 Hz Max. : 1000.0 Hz |

| Parameter | Name | Description | Setting Range |
|--|--|---|---|
| E5-06<4> <7> | Pulse Train Monitor Selection | Sets the function of pulse train output terminal MP 0 : Frequency Command 1 : Output Frequency 2 : Soft Starter Output Frequency 3 : PID Feedback Value 4 : PID Target Value | Default : 0 Range : 0 to 4 |
| E5-07<4> <7> | Pulse Train Monitor Scaling | Sets the pulse train output frequency when the specified monitor item is at 100%. | Default : 1440 Hz Min. : 100 Hz Max. : 50000 Hz |
| E5-08 <7> | Terminal RP Function Selection | 0: Pulse train input 1: PWM signal input | Default : 0 Min. : 0 Max. : 1 |
| E5-09<4> <7> | Average PWM Signal Times | 1 to 100 times | Default : 1 Min. : 1 Max. : 100 |
| E5-10 <7> | PWM Signal Cycle | 1 to 999 ms | Default : 100 ms Min. : 1 ms Max. : 999 ms |
| E6 : Optional Communication Card Settings | | | |
| E6-06 | Drive Station Address | Sets the drive station address. | Default: 1 Range: 1 to 31 |
| E6-07 | RS-485 Communication Baud Rate Setting | Sets the baud rate for terminals SG(+) and SG(-) of RS-485 communication. 0 : 1200 bps (bit/sec) 1 : 2400 bps 2 : 4800 bps 3 : 9600 bps 4 : 19200 bps 5 : 38400 bps 6 : 57600 bps 7 : 76800 bps 8 : 115200 bps | Default: 3 Range: 0 to 8 |
| E6-08 | RS-485 Communication Parity Selection | Selects the communication parity for terminals SG(+) and SG(-) of RS-485 communication. 0: 8, N, 2 (Modbus RTU) 1: 8, N, 1 (Modbus RTU) 2: 8, E, 1 (Modbus RTU) 3: 8, O, 1 (Modbus RTU) | Default : 1 Range : 0 to 11 |

| Parameter | Name | Description | Setting Range |
|---------------------------------------|---|---|--|
| | | 4: 8, N, 2 (Modbus ASCII) 5: 8, N, 1 (Modbus ASCII) 6: 8, E, 1 (Modbus ASCII) 7: 8, O, 1 (Modbus ASCII) 8: 7, N, 2 (Modbus ASCII) 9: 7, N, 1 (Modbus ASCII) 10: 7, E, 1 (Modbus ASCII) 11: 7, O, 1 (Modbus ASCII) | |
| E6-09 | Communication Error Detection Time | Determines the detection time to trigger the communication error. (This function is disabled when set to 0) | Default : 0.0 s Range : 0.0 to 10.0 s |
| E6-10 | Transmit Wait Time | Sets the wait time between sending and receiving data. | Default: 5ms Range: 5 to 65 ms |
| E6-11 | Drive Operation During Communication Error | 0 : Display CE Alarm Only. Drive continues operation. 1 : Display CE Fault. Drive coasts to stop. | Default : 0 Min. : 0 Max. : 1 |
| E6-12 | Communication Frequency Command Store Selection | 0 : No save 1 : Save | Default : 1 Min. : 0 Max. : 1 |
| E6-13 | Communication Frequency Command | MODBUS Communication Frequency Command Store value | Default : 0.00Hz Min : 0.00 to 400.00Hz |
| Group P, Protections | | | |
| P1 : Motor Protection Function | | | |
| P1-00 | Motor Protection Function Selection | 0 : Disabled (Motor Overload Protection Disabled) 1 : General-Purpose Motor (Standard Motor) 2 : Drive Dedicated Motor (Constant Torque Range 1 : 10) 3 : Vector Motor (Constant Torque Range 1 : 100) Sets 0 (disabled) when using one drive to run more than one motor. Install an overload relay between the drive and each motor. | Default : 0 Range : 0 to 3 |
| P1-01 | Motor Overload Protection Time | Sets the time for the drive to shut down on motor overload. | Default : 1.0 minute Min. : 0.1 minutes Max. : 5.0 minutes |

| Parameter | Name | Description | Setting Range |
|----------------------------------|--|---|--|
| P2 : Momentary Power Loss | | | |
| P2-00 | Momentary Power Loss Operation Selection | 0 : Disabled (Default) 1 : Recover if CPU Has Power 2 : KEB function if CPU Has Power 3 : Ramp to Stop with KEB Deceleration | Default: 0 Range: 0, 1, 2, 3 |
| P2-01 | Minimum Baseblock (bb) Time | Sets the minimum baseblock time when power is restored right after a momentary power loss. This determines the time the drive waits for the residual voltage in the motor to dissipate. Increase this value if overcurrent or overvoltage occurs at the beginning of Speed Search and DC Braking. | Default: Determined by o2-03, A1-06 Min.: 0.1 s Max.: 5.0 s |
| P2-02 | Uv (Undervoltage) Detection Delay Time | Sets the Delay time of undervoltage detection. | Default : depends on the voltage and HP 200V series : 1 400V series : Frame 1-4 : 0 Frame 5 and above : 1 Range : 0 to 1200ms |
| P2-03 | Uv (Undervoltage) Detection Delay Time | Sets the Delay time of undervoltage detection. | Default :Determined by d1-00, o2-03 Min. : 150V Max. : 210V <3> |
| P2-04 | KEB Deceleration Time | Sets the time to decelerate during KEB function. | Default: 0.0 s Min.: 0.0 s Max.: 6000.0 s |
| P2-05 | Acceleration Time after KEB | Sets the time to reaccelerate from the speed when KEB function was deactivated to the set frequency command (operation frequency before power loss). When set to 0.0 s, the drive will accelerate to the previously active frequency according to the active acceleration time set by any of C1-00, C1-02, C1-04 or C1-06. | Default: 0.0 s Min.: 0.0 s Max.: 6000.0 s |
| P2-07 | KEB Detection Time | Sets the minimum duration of KEB operation after activation. KEB function will operate according to this detection time even if power recovers within this duration. | Default : 50 ms Min. : 0 ms Max. : 2000 ms |

| Parameter | Name | Description | Setting Range |
|------------------------------|--|--|---|
| P2-08 | Voltage Target During KEB | Sets the target value for the main circuit DC voltage or to deactivate KEB. | Default : 0 Range : 0, 1, 2 |
| P2-09 | KEB Method Selection | 0 : KEB Operation Method 1 1 : KEB Operation Method 2 2 : KEB Operation Method 3 | Default : <2> Min. : 150V Max. : 400V <3> |
| P2-10 | Automatic voltage regulation (AVR) | 0 : AVR is disabled 1 : AVR is enabled | Default : 1 Range : 0, 1 |
| P3 : Stall Prevention | | | |
| P3-00 | Stall Prevention during Acceleration | 0 : Disabled 1 : Enabled the value set in P3-01. Acceleration stops when the output current exceeds the value set in P3-01. Acceleration continues when the output current drops 15% below the value set in P3-01. | Default: 1 Range: 0, 1 |
| P3-01 | Stall Prevention Level during Acceleration | Sets the output current level to activate the Stall Prevention function during acceleration. | Default: Determined by A1-06 Min. : 0% Max. : 180% |
| P3-02 | Stall Prevention Limit during Acceleration | Sets the lower limit of Stall Prevention in the constant power range as a percentage of the drive rated output current. | Default : 50% Min. : 0 % Max. : 100 % |
| P3-03 | Stall Prevention during Deceleration | 0: Disabled The drive decelerates according to the set deceleration time 1: Enabled (Without Braking Resistor) 2: Over excitation deceleration but no stall prevention 3: Over excitation deceleration includes stall prevention | Default : 1 Range : 0 to 3 |
| P3-04 | Stall Prevention Level during Deceleration | Sets the voltage level to activate the Stall Prevention function during deceleration. | Default : 200V Series : 395 V 400V Series : 10HP or less 790V 15HP or more 750V Min. : 330V Max. : 410V <3> |

| Parameter | Name | Description | Setting Range |
|---------------------------------|---|--|---|
| P3-05 | Stall Prevention during Run | 0 : Disabled 1 : Enabled (Deceleration Time 1) 2 : Enabled (Deceleration Time 2) | Default : 1 Range : 0, 1, 2 |
| P3-06 | Stall Prevention Level during Run | Sets the current level to activate the Stall Prevention function during run. | Default: Determined by A1-06 Min.: 30% Max.: 180% |
| P4 : Frequency Detection | | | |
| P4-00 | Frequency Detection Level | Sets the detection level and width for the multi-function output terminal. | Default: 30.0 Hz Min.: 0.0 Hz Max.: <5> |
| P4-01 | Frequency Detection Width | | Default: 2.0 Hz Min.: 0.1 Hz Max.: 25.5 Hz |
| P4-02 | Frequency Command Loss Detection Selection | Sets the drive operation when a frequency command loss is detected. 0 : Drive Stop 1 : Continue operation according to the setting in P4-03. | Default : 0 Range : 0, 1 |
| P4-03 | Frequency Command at Frequency Command Loss | Sets the frequency command level at which the drive runs when detecting a frequency command loss and when L4-02 is set to 1. Sets the value as a percentage of the maximum output frequency set in d1-02. (Sets the value as a percentage of the motor 2 maximum output frequency set in d1-13.) | Default: 80 % Min.: 0.0 % Max.: 100.0 % |
| P4-04 | Frequency Command Loss Detection Time | When the frequency command falls below 90% of the command within this detection time, the frequency command loss will be detected. | Default : 20 ms Min. : 20 ms Max.: 400 ms |
| P4-05 | Brake control release frequency | Setting brake control release frequency range | Default : 0.00Hz Min. : 0.00Hz Max. : 20.00Hz |
| P4-06 | Brake control action frequency | Setting Brake control action frequency range | Default : 0.00Hz Min. : 0.00Hz Max. : 20.00Hz |

| Parameter | Name | Description | Setting Range |
|--|--|--|--|
| P5 : Fault Restart | | | |
| P5-00 | Number of Auto Restart Attempts | Sets the number of times to automatically attempt to restart the drive when detecting GF, OVA, OVD, OVC, OCA, OCD, OCC, OH, OL1, OL2, OT1, OT2, PF and LF1. | Default : 0 Min. : 0 Max. : 10 |
| P5-01 | Auto Restart Fault Output Operation | 0 : Fault Output Disabled 1 : Fault Output Enabled | Default : 0 Range : 0, 1 |
| P5-02 | Fault Restart Interval Time | Sets the amount of time between restart attempts. | Default : 10.0 s Min. : 0.5 s Max. : 600.0 s |
| P6 : Overtorque / Undertorque Detection | | | |
| P6-00 | Overtorque / Undertorque Detection Selection 1 | Sets the operation when the motor current or torque exceeds the P6-01 level for longer than the time set to P6-02. 0 : Disabled 1 : Overtorque Alarm at Speed Agree 2 : Overtorque Alarm at Run 3 : Overtorque Fault at Speed Agree 4 : Overtorque Fault at Run 5 : Undertorque Alarm at Speed Agree 6 : Undertorque Alarm at Run 7 : Undertorque Fault at Speed Agree 8 : Undertorque Fault at Run | Default : 0 Range : 0 to 8 |
| P6-01 | Overtorque / Undertorque Detection Level 1 | Sets the level for overtorque / undertorque detection 1. | Default : 150% Min. : 0 % Max. : 300 % |
| P6-02 | Overtorque / Undertorque Detection Time 1 | Sets the time for overtorque / undertorque detection 1. | Default : 0.1 s Min. : 0.0 s Max. : 10.0 s |
| P6-06 | Mechanical Weakening Detection Operation | Sets the speed range to detect mechanical weakening and the operation when detected. 0 : Disabled 1 : Continue Operation if the Speed (Signed) is above P6-07 2 : Continue Operation if the Speed (Unsigned) is above P6-07 3 : Stop Operation if the Speed (Signed) is above P6-07 | Default: 0 Range: 0 to 8 |

| Parameter | Name | Description | Setting Range |
|------------------------------|--|---|---|
| | | 4 : Stop Operation if the Speed (Unsigned) is above P6-07 5 : Continue Operation if the Speed (Signed) is below P6-07 6 : Continue Operation if the Speed (Unsigned) is below P6-07 7 : Stop Operation if the Speed (Signed) is below P6-07 8 : Stop Operation if the Speed (Unsigned) is below P6-07 | |
| P6-07 | Mechanical Weakening Detection Speed Level | Sets the speed level for Mechanical Weakening Detection as a percentage of the maximum output frequency. | Default : 110.0% Min. : -110.0% Max. : 110.0% |
| P6-08 | Mechanical Weakening Detection Time | If the condition set in P6-06 lasts the time set in this parameter, Mechanical Weakening is detected. | Default : 0.1 s Min. : 0.0 s Max. : 10.0 s |
| P6-09 | Mechanical Weakening Detection Start Time | Sets the cumulative drive operation time to activate Mechanical Weakening Detection. If U3-00 reaches the value set in this parameter, Mechanical Weakening is detected. | Default : 0 Min. : 0 Max. : 65535 |
| P7 : Drive Protection | | | |
| P7-00 | Input Phase Loss Protection | Enables or disables the input phase loss detection. 0 : Disabled 1 : Enabled | Default: 1 Range: 0, 1 |
| P7-01 | Output Phase Loss Protection | Sets the output phase loss detection. 0 : Disabled 1 : Enabled when One Phase is Lost | Default : 0 200V series : 1 400V series : Frame 1-4 : 0 Frame5 (inclusive) or more models : 1 Range : 0~1 |
| P7-02 | Output Ground Fault Detection | Enables or disables the output ground fault detection. 0 : Disabled 1 : Enabled | Default : 0 Range : 0, 1 Remarks : 200V series: 1 400V Series : Frame 5 (inclusive) or more models 1 |

| Parameter | Name | Description | Setting Range |
|-------------------------------------|-------------------------------------|--|---|
| P7-03 | Heatsink Cooling Fan Operation <6> | Sets the heatsink cooling fan operation. 0 : Enabled when drive is running 1 : Enabled when power supply is On | Default: 0 Range: 0 to 3 |
| P7-04 | Heatsink Cooling Fan Off-Delay Time | When P7-04=0, sets the cooling fan off-delay time that the drive waits to disabled the cooling fan after run command is released. | Default : 60 s Min. : 0 s Max. : 300 s |
| P7-09 | oL2 Decline Curve | Sets the oL2 decline curve. 0 : oL2 decay from 100% to 0% in 4mins 1 : for HD and ND mode, 100% loading, oL2 decay from 100% to 0% in 4mins and 1 mins respectively. | Default : 0 Range : 0, 1 Remarks : 400V Frame 4 (included) the following models, factory settings: 1 |
| P7-11 | High Current Alarm Setting | Sets the High Current Alarm (HCA) when the output current is too high 0 : Disabled (No Alarm) 1 : Enabled (Alarm) | Default : 0 Range : 0, 1 |
| P7-13 | DC Braking Level Setting | Sets the DC braking transistor level. | Default: Determined by d1-00 <3> Range: 330 to 400V <3> |
| P7-14 | CHARGE mode selection | 0: First to run 1: Regularly when the inverter is stopped | Default:0 Min.:0 Max.:1 |
| Group n, Special Adjustments | | | |
| n1 : Hunting Prevention | | | |
| n1-00 | Hunting Prevention Setting | 0 : Disabled 1 : Enabled | Default : 1 Range : 0, 1 |
| n1-01<4> | Hunting Prevention Gain | If the motor oscillates during light load, gradually increase this value by units of 0.1. If the motor stalls, gradually decrease this value by units of 0.1. | Default : 2 Min. : 2 Max. : 5 |
| n3-04 | Overexcitation deceleration gain | Adjusting the V/f characteristics during overexcitation deceleration | Default: 1.10 Range:1.00~2.50 |
| n3-06 | High slip elimination current level | If OC (overcurrent), OL1 (motor overload), and OL2 (overload of the inverter) occur during overexcitation, reduce the current level and the rated current of the inverter is 100%. | Default : 100% Min. : 0% Max. : 150% |

| Parameter | Name | Description | Setting Range |
|--|--|---|--|
| Group o, Keypad Function Settings | | | |
| o1 : Display Setting | | | |
| o1-00 | Frequency Command Setting/Display Unit | 0 : Use units of 0.01 Hz 1 : Use units of 0.01% (100% as maximum output frequency) 2 : Use units of min-1 (automatically calculated by maximum output frequency and number of motor poles) 3 : Use user-defined units (defined by o1-02 and o1-03) | Default : 0 Range : 0 to 3 |
| o1-01 | Retain | | |
| o1-02 | User-Defined Frequency Command Setting/Display | 1 to 60000 | Default: Determined by o1-00 Min.: 1 Max.: 60000 |
| o1-03 | Frequency Command Setting/Display Decimal Places | 0 to 3 | Default: Determined by o1-00 Min. : 0 Max. : 3 |
| o2 : Multi-Function Selection | | | |
| o2-00 | LO/RE (LOCAL/REMOTE) Key Function Selection | Enables or disables LO/RE key on the keypad. 0 : Disabled 1 : Enabled Switches between Local and Remote Operation | Default : 1 Range : 0, 1 |
| o2-01 | STOP Key Function Selection | Enables or disables the STOP key on the keypad when the drive is controlled from a remote source. 0 : Disabled 1 : Enabled The STOP key always stops drive operation even if the command source is not set to the keypad. | Default : 1 Range : 0, 1 |
| o2-03 | Drive Capacity Selection | Set this parameter after replacing the terminal block or drive modules. | Default : <2> Determined by drive capacity |

| Parameter | Name | Description | Setting Range |
|----------------------------------|---|---|---|
| o2-04<8> | ENTER Key Function During Frequency Command Setting | 0 : ENTER Key Required 1 : ENTER Key Not Required After 5 second, the frequency is automatically setting. When entering a frequency command, the output frequency changes immediately by UP or DOWN key 2 : ENTER Key Not Required After 1 second, the frequency is automatically setting | Default : 0 Range : 0, 1,2 |
| o2-05 | Action Select When LCM Keypad Disconnection | 0 : Disabled 1 : Enabled | Default : 0 Range : 0, 1 |
| o2-06 | Operation Direction at Power Up when Using Keypad | 0 : Forward 1 : Reverse This parameter is enabled only when the keypad is selected as the Run command source. | Default : 0 Range : 0, 1 |
| o4 : Maintenance Settings | | | |
| o4-00 | Cumulative Operation Time Setting | Sets the initial value by 10 hours to start keeping track of cumulative operation time. | Default: 0 h Min.: 0 h Max.: 6000 h |
| o4-01 | Retain | | |
| o4-02 | Cooling Fan Operation Time Setting | Sets the initial value to start keeping track of cumulative fan operation time. View the cumulative fan operation time in U3-01. | Default: 0 h Min.: 0 h Max.: 6000 h |
| o4-06 | U2 Reset Setting | Resets the data for U2-□□ (Fault Information) as these data will not be reset by A1-03 (Reset). 0 : Disabled 1 : Enabled | Default: 0 Range: 0, 1 |
| o4-07 | kWh Monitor Initialization | 0 : U3-08 and U3-09 monitor data is not reset when the drive is initialized. 1 : U3-08 and U3-09 monitor data is reset when the drive is initialized. | Default : 0 Range : 0, 1 |

| Parameter | Name | Description | Setting Range |
|----------------------------------|--|--|--|
| Group t, Auto-Tuning | | | |
| t1 : IM Motor Auto-Tuning | | | |
| t1-01 | Auto-Tuning Method Selection | 0 : Rotational Auto-Tuning 1 : Stationary Auto-Tuning 2 : Stationary Auto-Tuning for Line-to-Line Resistance | Default : 0 Min. : 0 Max. : 2 |
| t1-02 | Motor Output Power | Sets the motor rated output power in kW units. Note: 1HP (Horse Power) = 0.746kW | Default: depend on o2-03' A1-06 Min.: 0.00 kW Max.: 650.00 kW |
| t1-03 | Motor Rated Voltage | Sets the motor rated voltage according to the motor nameplate. | Default : depend on A1-06 Min. : 0.0 V Max. : 255.0 V <3> |
| t1-04 | Motor Rated Current | Sets the motor rated current according to the motor nameplate. | Default : <2>according to different power inverters Minimum value : Inverter rating Min. : 10% of drive rated current Max. :200% of drive rated current |
| t1-05 | Motor Base Frequency | Sets the motor base frequency according to the motor nameplate. | Default : depend on A1-03 Min. : 0.0 Hz Max. : 400.0 Hz |
| t1-06 | Number of Motor Poles | Sets the number of motor poles according to the motor nameplate. | Default : 4 Min. : 2 Max. : 48 |
| t1-07 | Motor Base Speed | Sets the motor base speed according to the motor nameplate. | Default : depend on A1-03 Min. : 0 rpm Max. : 24000 rpm |
| t1-09 | Motor No-Load Current (Stationary Auto-Tuning) | Sets the no-load current for the motor. After the motor output power and rated current are set in t1-02 and t1-04, this parameter will automatically display the no-load current of a standard motor. The no- | Default : depend on A1-03 Min. : 0 rpm Max. : 24000 rpm |

| Parameter | Name | Description | Setting Range |
|---|---|---|---------------------------------------|
| | | load current must be entered according to the motor test report. | |
| t1-12 | Motor Auto-Tuning Setting | Enables or disables Auto-Tuning when A1-02=0 to 3 0 : Disabled 1 : Enabled | Default : 0 Min.: 0 Max.: 1 |
| Group F, Optional Function Group | | | |
| F2 : Canopen Card | | | |
| F2-01 | CANopen communication station | Set the slave station of the CANopen communication of the inverter | Default : 1 Min. : 1 Max. : 127 |
| F2-02 | CANopen communication baud rate setting | Select the communication speed of CANopen communication 0 : 1Mbps 1 : 800Kbps 2 : 500kbps 3 : 250 kbps 4 : 125 kbps 5 : 100 kbps 6 : 50 kbps 7 : 20 kbps 8 : 10 kbps | Default : 0 Min. : 0 Max. : 8 |
| Group U, Monitor Settings | | | |
| U1 : Status Monitors | | | |
| U1-00 | Control Method | 0 : V/F Control 1 : Senserless Voltage Vector Control | - |
| U1-01 | Frequency Command | Displays the frequency command. (Display units are defined by o1-00) | - |
| U1-02 | Output Frequency | Displays the output frequency. (Display units are defined by o1-00) | - |
| U1-03 | Output Current | Displays output current. | 0.01A |
| U1-04 | Motor Speed | Displays the motor speed. | - |
| U1-05 | Output Voltage Command | Displays the drive output voltage command. | 0.1V |
| U1-06 | Main circuit DC Voltage | Displays the main circuit DC voltage. | 0.1V |
| U1-07 | Output Power | Displays the internal output power calculated by the drive. | <50HP : 0.001kW >50HP : 0.01kW |

| Parameter | Name | Description | Setting Range |
|-----------|-----------------------------------|---|---------------|
| U1-09 | Input Terminal Status | Displays the status of the input terminal. U1-09=C 1111111 The following indicate each digit from right to left. 1:Digital Input 1 (S1 enabled) 1:Digital Input 2 (S2 enabled) 1:Digital Input 3 (S3 enabled) 1:Digital Input 4 (S4 enabled) 1:Digital Input 5 (S5 enabled) 1:Digital Input 6 (S6 enabled) 1:Digital Input 7 (S7 enabled) | - |
| U1-10 | Output Terminal Status | Displays the status of the output terminal. U1-10= o 111 The following indicate each digit from right to left. Multi-Function Terminal Output (terminal R1A/R1B-R1C) Multi-Function Terminal Output (terminal R2A-R2C) Multi-Function Photocoupler Output 1 (terminal D1) | - |
| U1-11 | Drive Operation Status | Displays the status of the drive operation. U1-11=11111111 The following indicate each digit from right to left. 1:During Run 1:During Zero Speed Holding 1:During Reverse 1:During Fault Reset Signal Input 1:During Speed Agree 1:Drive Ready 1:During Alarm Detection 1:During Fault Detection | - |
| U1-12 | Terminal A1 Input Voltage | Displays the terminal A1 input voltage. | 0.1% |
| U1-13 | Terminal A2 Input Voltage | Displays the terminal A2 input voltage. | 0.1% |
| U1-14<7> | Output Frequency After Soft Start | Display the output frequency after soft start | 0.01Hz |

| Parameter | Name | Description | Setting Range |
|-------------------------------|--|--|---------------|
| U1-15 | Input Pulse Monitor | Displays the frequency to pulse input. | 1Hz |
| U1-16 | Software Version | Displays the software version. | - |
| U1-17 | Date code | Display software date code | |
| U1-19 | Communication card software version | Display the software version of the communication card | |
| U2 : Fault Information | | | |
| U2-00 | Current Fault | Displays the current fault. | - |
| U2-01 | 1 st Most Recent Fault | Displays the first most recent fault. | - |
| U2-02 | 2 nd Most Recent Fault | Displays the second most recent fault. | - |
| U2-03 | 3 rd Most Recent Fault | Displays the third most recent fault. | - |
| U2-04 | 4 th Most Recent Fault | Displays the fourth most recent fault. | - |
| U2-05 | Frequency Command at 1 st Most Recent Fault | Displays the frequency command at the first most recent fault. | - |
| U2-06 | Output Frequency at 1 st Most Recent Fault | Displays the output frequency at the first most recent fault. | - |
| U2-07 | Output Current at 1 st Most Recent Fault | Displays the output current at the first most recent fault. | 0.01A |
| U2-08 | Motor Speed at 1 st Most Recent Fault | Displays the motor speed at the first most recent fault. | - |
| U2-09 | Output Voltage command at 1 st Most Recent Fault | Displays the output voltage command at the first most recent fault. | 0.1V |
| U2-10 | Main Circuit DC Voltage at 1 st Most Recent Fault | Displays the main circuit DC voltage at the first most recent fault. | 0.1V |

| Parameter | Name | Description | Setting Range |
|-----------|---|--|---------------|
| U2-11 | Retain | | |
| U2-13 | Input Terminal Status at 1 st Most Recent Fault | Displays the input terminal status at the first most recent fault. (Same status display as U1-09) | - |
| U2-14 | Output Terminal Status at 1 st Most Recent Fault | Displays the output terminal status at the first most recent fault. (Same status display as U1-10) | - |
| U2-15 | Operation Status at 1 st Most Recent Fault | Displays the operation status at the first most recent fault. (Same status display as U1-11) | - |
| U2-17<7> | Cumulative Power-on Time at 1 st Most Recent Fault | Displays the cumulative power-on time at the first most recent fault | 1h |
| U2-18 | Cumulative Operation Time at 1 st Most Recent Fault | Displays the cumulative operation time at the first most recent fault | 1h |
| U2-19 | Frequency Command at 2 nd Most Recent Fault | Displays the frequency command at the second most recent fault. | - |
| U2-20 | Output Frequency at 2 nd Most Recent Fault | Displays the output frequency at the second most recent fault. | - |
| U2-21 | Output Current at 2 nd Most Recent Fault 2 nd | Displays the output current at the second most recent fault. | 0.01A |
| U2-22 | Motor Speed at 2 nd Most Recent Fault | Displays the motor speed at the second most recent fault. | - |
| U2-23 | Output Voltage command at 2 nd Most Recent Fault | Displays the output voltage command at the second most recent fault. | 0.1V |
| U2-24 | Main Circuit DC Voltage at 2 nd Most Recent Fault | Displays the main circuit DC voltage at the second most recent fault. | 0.1V |

| Parameter | Name | Description | Setting Range |
|----------------------------------|--|--|---------------|
| U2-25 | Retain | | |
| U2-27 | Input Terminal Status at 2 nd Most Recent Fault | Displays the input terminal status at the second most recent fault. (Same status display as U1-09) | - |
| U2-28 | Output Terminal Status at 2 nd Most Recent Fault | Displays the output terminal status at the second most recent fault. (Same status display as U1-10) | - |
| U2-29 | Operation Status at 2 nd Most Recent Fault | Displays the operation status at the second most recent fault. (Same status display as U1-11) | - |
| U2-31 <7> | Cumulative Power-on Time at 2 nd Most Recent Fault | Displays the cumulative power-on time at the second most recent fault | 1h |
| U2-32 | Cumulative Operation Time at 2 nd Most Recent Fault | Displays the cumulative operation time at the second most recent fault | 1h |
| U2-33 | Current Alarm | Displays the current alarm. | - |
| U2-34 | 1 st Most Recent Alarm | Displays the first most recent alarm. | - |
| U2-35 | 2 nd Most Recent Alarm | Displays the second most recent alarm. | - |
| U2-36 | 3 rd Most Recent Alarm | Displays the third most recent alarm. | - |
| U2-37 | 4 th Most Recent Alarm | Displays the fourth most recent alarm. | - |
| U3 : Maintenance Monitors | | | |
| U3-00 | Cumulative Drive Power-on Time | Displays the cumulative power-on time for the drive. The maximum number displayed is 60000, after which the value will be counted from 0. | 1h |
| U3-01 | Cumulative Cooling Fan Operation Time | Displays the cumulative operation time for the cooling fan. The initial value is determined by o4-02. The maximum number displayed is 60000, after which the value will be counted from 0. | 1h |

| Parameter | Name | Description | Setting Range |
|--------------|---------------------------------------|--|---------------|
| U3-02 | Cumulative Drive Operation Time | Displays the cumulative operation time for the drive. The initial value is determined by o4-00. The maximum number displayed is 60000, after which the value will be counted from 0. | 1h |
| U3-06 | Heatsink Temperature | Displays the heatsink temperature. | 1°C |
| U3-07 <7> | LED Detection | Detects LED keypad working properly. | - |
| U3-08 | 4 digits after kWh (cumulative power) | The output power of the inverter is displayed on the monitor. It is displayed separately according to the high and low positions. (Display example) The monitor at 12345678.9kWh is displayed as: U3-08: 678.9kWh U3-09: 12345MWh | |
| U3-09 | 5 digits after kWh (cumulative power) | The output power of the inverter is displayed on the monitor. It is displayed separately according to the high and low positions. (Display example) The monitor at 12345678.9kWh is displayed as: U3-08: 678.9kWh U3-09: 12345MWh | |
| U3-10 | Peak Hold Current | Displays the peak current value during operation | 0.01A |
| U3-11 | Peak Hold Output Frequency | Displays the output frequency when the peak current displayed in U3-10 occurred. | - |
| U3-12 | Motor Overload Estimate (oL1) | Displays the value of the motor overload detection accumulator. An oL1 will be triggered when reaching 100%. | 1% |
| U3-13 | Frequency Command Source Selection | Displays the source for the frequency command as XY-nn. X: Command Used 1 : Command 1 2 : Command 2 Y-nn: Frequency Command Source 0-01: Keypad 1-01: Analog input (Terminal AI 1) 1-02: Analog input (Terminal AI 2) 2-02 to 2-16: Multi-step speed command 2-17: Jog frequency command 3-01: PID frequency command 4-01: Terminal UP/DOWN | 1% |

| Parameter | Name | Description | Setting Range |
|--------------------------|-------------------------------|---|---------------|
| | | 5-01: Modbus communication 6-01: Pulse train command 7-00~7-16 : Automatic operation command | |
| U3-14 | Run Command Source Selection | Displays the source for the frequency command as XY-nn. XY-nn=00-00: Local X: Command Used 1: Command 1 2: Command 2 Y-nn: Command Source 0-00: Keypad 0-01: Control Circuit Terminal (Sequence Control Input) 0-02: Modbus communication | - |
| U3-17 | Drive Overload Estimate (oL2) | Displays the value of the drive overload detection accumulator. An oL2 will be triggered when reaching 100%. | 1% |
| U4 : PID Monitors | | | |
| U4-00 | PID Feedback | Displays the PID feedback value as a percentage of the maximum output frequency. | 0.01% |
| U4-01 | PID Input | Displays the PID input value as a percentage of the maximum output frequency. | 0.01% |
| U4-02 | PID Output | Displays the PID output value as a percentage of the maximum output frequency. | 0.01% |
| U4-03 | PID Target | Displays the PID target value as a percentage of the maximum output frequency. | 0.01% |
| U4-04 | PID Differential Feedback | Displays the difference of both feedback values when 10 is set to both E3-01 and E3-07. | 0.01% |
| U4-05 | PID Feedback 2 | Displays the adjusted feedback value if differential feedback is used (U4-00 to U4-04) The value in U4-00 and U4-05 will be the same if differential feedback is not used. | 0.01% |
| U4-08 <7> | PID Output 2 | Displays the PID output 2 value as a percentage of the maximum output frequency. | 0.01% |

- <1> The default is determined by the drive capacity, control method and ND/HD mode.
 - <2> Refer to user manual for details.
 - <3> Double the value for 440V class AC drives.
 - <4> The parameter can be set during run.
 - <5> The maximum of parameter setting by d1-02 (maximum output frequency) and L2-00 (frequency command limit) will be changed
 - <6> Contact the Bharat Bijlee / Drives Sales Partner for any malfunction.
 - <7> Digital input terminal S7 is set to 74
 - <8> This functional software version V1.10 open.
- * The content of parameters will make some adjustments. Please refer to the manual on the website. <https://www.bharatbijlee.com/drives-automation/>

Chapter 6 | Troubleshooting

6.1 Alarm and Fault Displays

Table 6.1 Alarm and Fault Displays, Causes, and Possible Solutions

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|---|--|--|
| EFO | Retain | | |
| EF1 to EF | External Fault (Input Terminal S1 to S7) | <ol style="list-style-type: none"> 1. An external device tripped an alarm 2. Incorrect wiring 3. Multi-function input wiring is not correct | <ol style="list-style-type: none"> 1. Remove the cause of the external fault then reset the multi-function input. 2. Confirm if the signal lines is properly connected to the terminals assigned for external fault detection (E1-□ □ = 23 to 38) 3. Confirm if E1-□ □ = 23 to 38 is set to the unused terminals. |
| FbH | PID Feedback High PID feedback input is greater than the detection level set to b5-22 for longer than the detection time set to b5-23 | <ol style="list-style-type: none"> 1. b5-22 and b5-23 inappropriate setting 2. PID feedback wiring incorrect 3. Feedback sensor malfunction 4. Feedback input circuit malfunction | <ol style="list-style-type: none"> 1. Confirm b5-22 and b5-23 settings 2. Correct the wiring 3. Replace the sensor if it is damaged 4. Replace the PCB or drive. Contact the local distributor. |
| FbL | PID Feedback Low When the PID feedback detection is enabled in b5-11, a FbL will be triggered while the PID feedback falls below the level set to b5-12 for longer than the time set to b5-13. | <ol style="list-style-type: none"> 1. Inappropriate setting in b5-12 and b5-13 2. Incorrect PID feedback wiring 3. Feedback sensor malfunction 4. Incorrect feedback input circuit | <ol style="list-style-type: none"> 1. Correct b5-12 and b5-13 settings 2. Correct the wiring 3. Replace the sensor if it is damaged 4. Contact the local distributor to replace the board or the drive. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|---|--|
| oH | Heatsink Overheat Heatsink temperature over 90 to 100°C (Overheat level is determined by rating of the drive) | 1. Ambient temperature is too high 2. Internal cooling fan stopped operating 3. Bad air flow due to insufficient room. | 1. Check the temperature surrounding the drive a. Improve the air flow inside the enclosure panel b. Install an air conditioner or fan to cool the environment c. Remove any possible source of heat 2. Measure the output current a. Reduce the load b. Lower setting in C6-00 (Carrier Frequency Option) 3. Replace the cooling fan |
| oH1 | Motor Overheat The temperature signal from motor temperature sensor via the terminal MT exceeded the overheat detection level of the drive. | 1. Incorrect motor temperature input (terminal MT) wiring 2. Fault on the machinery (e.g., machinery is locked up) 3. Motor overheat | 1. Correct the wiring for terminal MT. 2. Check the machinery status 3. Check the load, acceleration / deceleration time and cycle time a. Reduce the load. b. Increase the C1-00 to C1-07 (Acc./Dec. Time) settings c. Adjust d1-02 to d1-11 (V/F Characteristics) |
| ot1 | Overtorque Detection 1 The current has exceeded the torque level set to P6-01 for longer than the time set to P6-02 | 1. Incorrect parameter settings 2. Malfunction on machinery | 1. Reset P6-01 and P6-02 2. Check machinery and load status |
| ov | Overvoltage Voltage in the DC bus exceeded the overvoltage detection level 1. 200 V class: 410 V 2. 400 V class: 820 V | 1. Drive input power has surge voltage entering 2. Machinery output short circuit 3. Ground fault in the output circuit causes the DC bus capacitor to overcharge 4. Electrical signal interference causes drive | 1. Install a DC link choke Voltage surge can result from a thyristor convertor and phase advancing capacitor using the same input power supply 2. Check the motor power cable, relay terminals and motor terminal box 3. Correct grounding shorts and reapply power |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|--|--|
| | | malfunction 5. PG cable is disconnected 6. Incorrect PG cable wiring 7. PG encoder wiring is interference by electrical signal | 4. Check the solutions for interference suppression »Check the control circuit lines, main circuit lines and grounding wiring. »If the MC is the source of interference, connect a suppressor to it. 5. Reconnect the cable 6. Correct the wiring 7. Separate the wiring from the source of the electrical signal interference. It is usually the output lines from the drive |
| Uv | Undervoltage 1. Voltage in the DC bus fell below the undervoltage detection level (P2-03) 2. 200 V class: 190 V 3. 400 V class: 380 V | 1. Input power phase loss 2. Loose wiring terminals of drive input power 3. Problem with the voltage from the drive input power 4. The drive main circuit capacitors are weakened. 5. The contactor or relay on the soft-charge by pass circuit is damaged | 1. Correct the drive input power wiring 2. Tighten the terminals 3. Check the voltage a. Adjust the voltage according to the drive input power specifications b. Check the main circuit magnetic contactor if there is no problem with the power supply 4&5. Turn on and turn off the power to see if any problem occurs Replace either the entire drive or the control board if the problem continues to occur. Contact the local distributor for more information. |
| Ut1 | Undertorque Detection 1 The current has dropped below the torque detection level set to P6-01 for longer than the time set to P6-02 | 1. Incorrect parameter settings 2. Malfunction on machinery side | 1. Reset P6-01 and P6-02 2. Ensure there is no problem on the machinery side. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|---|---|---|
| UL | Mechanical Weakening Detection for Undertorque Undertorque in the conditions set to P6-06 | Undertorque in the conditions set to P6-06 | Check the condition of mechanical weakening |
| oL | Mechanical Weakening Detection for Overtorque Overtorque in the conditions set to P6-06 | Overtorque in the conditions set to P6-06 | Check the condition of mechanical weakening |
| bb | Baseblock Drive output interrupted by an external baseblock signal | An external baseblock signal was input via one of the multi-function input terminals (S1 to S7) | Check baseblock signal input timing and external sequence |
| oH2 | Drive Overheat Warning Drive Overheat Warning input via a multi-function input terminal(S1to S7) when E1-□□= 40 | An overheat warning in the drive was triggered by an external device | 1. Search the device which caused the overheat warning. Remove the cause of the problem. 2. Reset Drive Overheat Warning input at the assigned multi-function input terminal (S1to S7) |
| HCA | Current Alarm Drive current exceeded the level of over current warning (150% of the rated current) | 1. The load is too heavy 2. Deceleration and acceleration times are too short 3. The drive is attempting to run a motor greater than the maximum allowable capacity, or a special-purpose motor is being used 4. The current level went up because of Speed Search while attempting to perform a fault restart or after a momentary power loss | 1. Reduce the load or use a drive of higher rating 2. Calculate the torque required during acceleration and the inertia »Take the following steps if the torque level is not right for the load · Increase the settings for acceleration and deceleration time (C1-00 to C1-07) · Use a drive of higher rating 3. Check the motor capacity ·Make sure the motor capacity is right for the drive rating. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|------------------------------------|--|---|
| | | | 4. During a momentary power loss or an attempt to reset a fault, the alarm is displayed. However, there is no need to take any action because the fault display will disappear shortly |
| DNE | Driver Enable | <ol style="list-style-type: none"> 1. Multi-function contact input is set to 69/169, but the contact input status is incorrect 2. The multi-function contact input is incorrect | <ol style="list-style-type: none"> 1. Multi-function contact input is set to 69 and switched on. 2. Multi-function contact input is set to 169 and switched off |
| AnL | Simulation A2 input signal is lost | <ol style="list-style-type: none"> 1. Simulation A2 input signal is lost | <ol style="list-style-type: none"> 1. Check the simulation signal wiring 2. Check the E3-10 parameter settings |
| ES | Emergency Stop | <ol style="list-style-type: none"> 1. Emergency stop is turned on (P2-11) before the power off, when the DC bus voltage is lower than P2-06 2. Multi-function contact input is set to 21/121, but the contact input is switched on | <ol style="list-style-type: none"> 1. Turn off the emergency stop function P2-11, or adjust P2-06 settings Level 2. Confirm the multi-function contact input function set and terminal status |

6.2 Fault Detection

Table 6.2 Fault Displays, Causes, and Possible Solutions

| Keypad Display | Fault Name | Cause | Possible Solution |
|---|---|--|---|
| GF | Ground Fault | Output power cable is damaged | Check and replace output power cable |
| oVA, oVd, oVC oVAH oVdH ovCH | Overvoltage (Acceleration, Deceleration and Constant Speed) The main circuit DC voltage exceeded the overvoltage detection level 200V class: 410V 400 V class: 820 V | <ol style="list-style-type: none"> 1. Regenerative energy is flowing from the motor into the drive because the deceleration time is too short 2. The motor overshoot the speed reference because the acceleration time is too short 3. Excessive braking load 4. Surge voltage entering from the drive input power 5. Motor short-circuited Ground fault current charges the drive main circuit capacitor. 6. Improper parameter settings for Speed Search (including Speed Search after a fault restart and after a momentary power loss) 7. Drive input voltage is too high 8. The braking transistor or braking resistor are wired incorrectly 9. PG cable is disconnected 10. PG cable wiring is incorrect 11. PG encoder wiring has interference of electrical signal | <ol style="list-style-type: none"> 1. Increase the deceleration time settings(C1-01, C1-03, C1-05, C1-07) »Install a braking unit or a dynamic braking resistor »Set P3-03 (Stall Prevention during Deceleration) to 1 (Enabled)(default is 1) 2. Confirm if overvoltage alarm oVA or oVCwas triggered during sudden drive acceleration. »Increase the acceleration time »Use S-curve deceleration and acceleration times and increase the value set to C2-01 (S-curve at acceleration end) 3. Install a braking unit or a braking resistor 4. Install a DC reactor »Thyristor convertor and phase advancing capacitor using the same input power supply might cause a voltage surge 5. Check the motor power cable, relay terminals and motor terminal box » Correct grounding shorts and reapply power 6. Adjust parameter settings for Speed Search (group b3) »Proceed Auto-Tuning for line-to-line resistance 7. Check the voltage »Lower drive input power voltage within the range listed in the drive specifications |

| Keypad Display | Fault Name | Cause | Possible Solution |
|---------------------|---|--|--|
| | | 12. Electrical signal interference causes the drive malfunction 13. Incorrect inertia setting of the load 14. Motor hunting occurs | 8. Check the wiring of the braking resistor and braking unit »Correct the wiring 9. Tighten the terminal or replace the damaged cable 10. Correct the wiring 11. Separate the PG wiring from the source of the electrical signal interference (drive output cable) 12. Check the solutions for interference suppression »Check the wiring of control circuit I, main circuit and grounding. 13. Check the load inertia settings when using KEB, or Stall Prevention during deceleration 14. Adjust the parameters to suppress hunting »Adjust n1-01 (Hunting Prevention Gain) |
| oCA, oCd, oCC | Overcurrent (Acceleration, Deceleration and Constant Speed) | 1. The motor insulation is damaged or the motor is overheated 2. Grounding problem caused by damaged motor cable 3. The drive is damaged 4. The load is too heavy 5. Settings for acceleration or deceleration time is too short 6. The drive is running a special purpose motor or a motor larger than the drive rated capacity 7. A magnetic contactor (MC) on the output side of the drive has turned on or off | 1. Check the insulation resistance 2. Check the motor power cable 3. Check the resistance between the cable and the terminal. 4. Short circuit on drive output side or grounding causes register damage. 5. Measure the current flowing into the motor 6. Check the motor capacity 7. Calculate the torque required during acceleration according to the load inertia and acceleration time. If the required torque is insufficient, check the motor capacity. 8. Install a sequence controller to ensure the MC does not open or |

| Keypad Display | Fault Name | Cause | Possible Solution |
|-------------------------------|--|---|--|
| | | 8. V/Fset incorrectly 9. Excessive torque compensation 10. Electrical signal interference causes drive malfunction 11. Overexcitation gain is set too high 12. Run command was applied while motor was coasting 13. Incorrect motor code 14. The motor does not match the drive control method 15. The motor cable is too long | close when the drive is outputting voltage. 9. Check the ratios between the frequency and voltage set by V/F. 10. Adjust d1-02 to d1-11 (or d1-13 to d1-22 for motor 2) 11. Check the amount of torque compensation 12. Find out possible solutions to suppress the electrical signal interference 13. Check if the fault occurs frequently with overexcitation function operation 14. Enable Speed Search via multi-function input terminal 15. Check the control method (A1-02) 16. Use a larger drive |
| SC ∙ SC1 ∙ SC2 ∙ SC3 | IGBT Fault or Output Short Circuit | 1. Motor has been damaged due to the motor insulation weakened or overheat 2. The cable is damaged 3. Hardware fault 4. The drive is damaged | 1. Replace the motor or check the motor insulation resistance 2. Repair any short circuits and check the motor power cable |
| EFO | Retain | | |
| EF1to EF7 | External Fault (Input Terminal S1 to S7) | 1. An external device tripped an alarm 2. Incorrect wiring 3. Multi-function input wiring is not correct | 1. Remove the cause of the external fault then reset the multi-function input. 2. Confirm if the signal lines is properly connected to the terminals assigned for external fault detection (E1-□□= 23 to 38) 3. Confirm if E1-□□=23 to 38 is set to the unused terminals. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|---|--|
| oH | Heatsink Overheat Heatsink temperature over 90 to 100°C (Overheat level is determined by rating of the drive) | 1. Ambient temperature is too high 2. Internal cooling fan stopped operating 3. Bad air flow due to insufficient room. | 1. Check the temperature surrounding the drive a. Improve the air flow inside the enclosure panel b. Install an air conditioner or fan to cool the environment c. Remove any possible source of heat 2. Measure the output current a. Reduce the load b. Lower setting in C6-00 (Carrier Frequency Option) 3. Replace the cooling fan |
| oH1 | Motor Overheat The temperature signal from motor temperature sensor via the terminal MT exceeded the overheat detection level of the drive. | 1. Incorrect motor temperature input (terminal MT) wiring 2. Fault on the machinery (e.g., machinery is locked up) 3. Motor overheat | 1. Correct the wiring for terminal MT. 2. Check the machinery status 3. Check the load, acceleration / deceleration time and cycle time a. Reduce the load. b. Increase C1-00to C1-07 (Acc./Dec. Time) settings c. Adjust d1-02to d1-11 (V/FCharacteristics) |
| oL | Mechanical Weakening Detection for Overtorque Overtorque in the conditions set to P6-06 | Overtorque in the conditions set to P6-06 | Check the condition of mechanical weakening |
| oL1 | Motor Overload | 1. The load is too heavy 2. The acceleration and deceleration times are too short 3. The motor is driven below the rated speed with a high load 4. Incorrect setting in P1-00 (Motor Protection Function Selection) when running a special motor | 1. Check loading capacity » Reduce the load 2. Confirm acceleration and deceleration times » Increase C1-00to C1-07 parameter settings 3. » Reduce the load » Increase the speed » Either increase the motor capacity or use a special-purpose motor if the motor needs to |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|----------------|---|--|
| | | 5. The voltage determined by the V/F is too high 6. d2-00 (Motor Rated Current) setting incorrect 7. The base frequency is set too low 8. Use one drive to run multiple motors 9. The electrical thermal protection characteristics do not match the motor overload characteristics. 10. The electrical thermal relay operates at the wrong level 11. Motor overheated by overexcitation operations 12. Speed Search related parameters are set incorrectly 13. Power supply phase loss causes output current oscillation. | operate at low speeds 4. Set P1-00 to 2. 5. Adjust d1-02to d1-11 settings (V/FCharacteristics) Note: If d1-02 to d1-11 settings are too low, load tolerance at low speeds will be reduced 6. Confirm the motor rated current » Set d2-00 (Motor Rated Current) according to the motor nameplate 7. Confirm the rated frequency showed on the motor nameplate »Set d1-04 (Base Frequency) according to the motor nameplate 8. Set P1-00 (Motor Protection Function Selection) to 0 (Disabled) and install a thermal relay to each motor 9. Confirm characteristics of the motor »Set P1-00 (Motor Protection Function Selection) correctly »Install an external thermal relay 10. Overexcitation increases the motor loss 11. Adjust parameters related to Speed Search »Adjust the b3-01 (Speed Search Operation Current) setting 12. Check the power supply for phase loss |
| oL2 | Drive Overload | 1. The load is too heavy 2. The acceleration and deceleration times are too short 3. The voltage determined by the V/F is too high 4. The drive capacity is too small | 1. Check loading capacity » Reduce the load 2. Confirm acceleration and deceleration times » Increase C1-00to C1-07 parameter settings 3. Adjust d1-02to d1-11 settings (V/F Characteristics) Note : If d1-02 to d1-11 settings |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|---|--|
| | | 5. The motor is driven below the rated speed with a high load 6. Torque compensation is too high 7. Speed Search related parameters are set incorrectly 8. Power supply phase loss causes output current oscillation | are too low, load tolerance at low speeds will be reduced 4. Use a larger drive 5. »Reduce the load at low speed »Use a larger drive » Set a lower value to C6-00 (Carrier Frequency) 6. Check the torque compensation » Set a lower value to C3-00 (Torque Compensation Gain) until the current is decreased and the motor does not stall. 7. Adjust parameters related to Speed Search » Adjust b3-01 (Speed Search Operation Current) 8. Check the power supply for phase loss |
| ot1 | Overtorque Detection 1 The current has exceeded the torque level set to P6-01 for longer than the time set to P6-02 | 1. Incorrect parameter settings 2. Malfunction on the machinery side | 1. Reset P6-01 and P6-02 2. Check machinery and load status |
| Ut1 | Undertorque Detection 1 The current has dropped below the torque detection level set to P6-01 for longer than the time set to P6-02 | 1. Incorrect parameter settings 2. Malfunction on the machinery side | 1. Reset P6-01 and P6-02 2. Ensure there is no problem on the machinery side. |
| UL | Mechanical Weakening Detection for Undertorque Undertorque in the conditions set to P6-06 | Undertorque in the conditions set to P6-06 | Check the condition of mechanical weakening |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|---|---|--|
| Uv1 | Undervoltage Detection 1 Voltage in the DC bus fell below the undervoltage detection level (P2-03) during run. · 200 V class: 190 V · 400 V class: 380 V | 1. Input power phase loss 2. Loose wiring terminals of drive input power 3. Problem with the voltage from the drive input power 4. The drive main circuit capacitors are weakened. 5. The contactor or relay on the soft-charge bypass circuit is damaged | 1. Correct the drive input power wiring 2. Tighten the terminals 3. Check the voltage a. Adjust the voltage according to the drive input power specifications b. Check the main circuit magnetic contactor if there is no problem with the power supply 4. Turn on and turn off the power to see if any problem occurs a. Replace either the entire drive or the control board if the problem continues to occur. Contact the local distributor for more information. |
| Uv2 | Retain | | |
| PF | Input Phase Loss Drive input power has a large imbalance of voltage between phases or has an open phase (Detected when P7-00=1) | 1. Phase loss in the drive input power 2. Drive input power terminals has a loose wiring 3. Drive input power voltage has an excessive fluctuation 4. The main circuit capacitors are impaired | 1. Check wiring for errors in the main circuit drive input power »Correct wiring 2. Make sure the terminals are tightened correctly »Apply the tightening torque as showed in the manual 3. Confirm the voltage from the drive input power »Apply possible solutions for drive input power stabilization 4. Check drive input power. If drive input power seems normal but the alarm continues to occur, replace either the entire drive or the control board. Contact the local distributor for more information. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|---|---|
| LF1 | Output Phase Loss Phase loss on the drive output side | <ol style="list-style-type: none"> 1. The output cable is not connected 2. The motor winding is impaired 3. The output terminal is loose 4. The rated current of the motor being used is 5% less than the drive rated current 5. An output transistor is impaired 6. A single phase motor is activating | <ol style="list-style-type: none"> 1. Check the errors for wiring then properly connect the output cable »Correct the wiring 2. Check the resistance which located between motor lines »If the winding is impaired, replace the motor 3. Use tightening torque which showed in the manual in order to fasten the terminal 4. Check motor capacities and the drive 5. The drive cannot run a single phase motor |
| LF2 | Retain | | |
| FbH | PID Feedback High | <ol style="list-style-type: none"> 1. Incorrect parameter settings 2. Incorrect PID feedback wiring 3. Feedback sensor malfunction | <ol style="list-style-type: none"> 1. Reset b5-22 and b5-23 2. Correct the wiring 3. Check the sensor |
| FbL | PID Feedback Low | <ol style="list-style-type: none"> 1. Incorrect parameter settings 2. Incorrect PID feedback wiring 3. Feedback sensor malfunction | <ol style="list-style-type: none"> 1. Reset b5-12 and b5-13 2. Correct the wiring 3. Check the sensor |
| bUS | Retain | | |
| CE | Modbus Communication Error | <ol style="list-style-type: none"> 1. Incorrect wiring 2. Communication data error caused by noise | <ol style="list-style-type: none"> 1. Correct the wiring »Check short circuits and disconnected cables, repair if necessary 2. Check possible solution to suppress the noise |
| CF | Retain | | |
| Err | Retain | | |
| Sto | Retain | | |
| JoGEr | FJOG/RJOG Input Error | A FJOG and RJOG Run commands are received at the same time | Check the Run command from the external source for Fjog/Rjog |

6.3 Operation Errors

Table 6.3 Error Displays, Causes, and Possible Solutions

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|--|--|--|
| oPE02 | Parameter Range Setting Error | Parameters are set outside of the possible setting range | 1. Set the parameters to the proper values 2. Reset the drive |
| oPE03 | Multi-Function Input Selection Error | 1. Either of Up command and Down command is not set (E1-□□= 10 or 11) 2. Either of Up command 2 and Down command 2 is not set (E1-□□=12 or 13) | Properly assign both of the UP and Down commands to the multi-function input terminal. |
| oPE04 | 3-Wire Sequence Control Setting Error | Multi-Function input terminals S1 and S2 are assigned to E1-□□=2 (3-Wire Sequence) | Do not assign multi-function input terminals S1 and S2 to E1-□□=2 (3-Wire Sequence) |
| oPE05 | Communication Error | | |
| oPE06 | Control Method Selection Error | A control method that requires a PG option card (A1-02 = 1, 3, or 5) is selected, but no PG card is installed | Install a PG option card or correct the value set to A1-02 |
| oPE07 | Multi-Function Analog Input Selection Error | E3-01 and E3-07 are set to the same value | Set different values to E3-01 and E3-07 |
| oPE08 | PID output upper / lower Selection Error | 1. b5-05 PID upper limit is less than the lower limit value of b5-20 PID | 1. Reset the PID upper / lower limit |
| oPE09 | PID Control Selection Fault (When b5-00 (PID Control Setting) = 1 to 4) | 1. Contradictory settings · b5-14 (PID Sleep Start Level) is not set to 0.0 · b1-02 (Stopping Method Selection) is set to 2 (DC Braking to Stop) or 3 (Coast to Stop with Timer) 2. L2-01 (Frequency Command Lower Limit)≠0 when b5-00 = 1 or 2 (PID Control Enabled) | 1. Correct the parameter setting. 2. Correct the parameter setting. 3. Correct the parameter setting. 4. Correct the parameter setting. |

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|---|--|---|
| | | 3. b5-10 (PID Output Reverse Selection) = 1 (Reverse Enabled) when b5-00 = 1 or 2 4. L2-01 ≠ 0 when b5-00 = 3 or 4 | |
| oPE10 | V/F Data Setting Error Incorrect d1-02, d1-04, d1-06, d1-08, d1-10 (or d1-13, d1-15, d1-17, d1-19, d1-21) settings | V/F parameters setting incorrect | Correct the setting in d1-02, d1-04, d1-06, d1-08 and d1-10 (or d1-13, d1-15, d1-17, d1-19 and d1-21). |
| oPE11 | Carrier Frequency Setting Error | 1. Contradictory settings · C6-03 (Carrier Frequency Proportional Gain) > 6 · C6-02 (Minimum Carrier Frequency) > C6-01 (Maximum Carrier Frequency) Note: If C6-03 ≤ 6, the drive operates at C6-01 2. The limit set in C6-00 to C6-03 are contradictory | Correct the parameter setting. |
| oPE12 | Analog Frequency Command Hold Error | When E1-□□=61, there is another E1-□□ is set to 10 to 13, 18 or 53 to 55. | Correct the setting. |
| oPE13 | main and Alternative Frequency Command Error | When b1-00 and b1-07 are setting the same supply source | Correct the setting. |
| oPE14 | Incorrect Jump Frequency Setting | The setting does not follow L3-00 ≤ L3-01 ≤ L3-02 | Correct the setting. |
| oPE15 | Retain | | |
| oPE16 | Retain | | |
| oPE17 | Motor Rated Speed Setting Error | 1. Motor rated speed setting over the motor synchronous speed | 1. Set the motor base frequency and the correct number of motor poles 2. Correctly set the motor rated speed Motor synchronous speed = 120 X base frequency / motor pole number |
| oPE18 | Retain | | |

6.4 Auto-Tuning Fault Detection

Table 6.4 Auto-Tuning Codes, Causes, and Possible Solution

| Keypad Display | Fault Name | Cause | Possible Solution |
|----------------|-------------------------------|--|--|
| TnF00 | Auto-Tuning Stop | User presses STOP key during Auto-Tuning | Do not press STOP key during Auto-Tuning |
| TnF01 | Line-to Line Resistance Error | The line-to-line resistance in Auto-Tuning is negative or limited by the upper the lower limit | Check and correct motor wiring |
| TnF02 | Stationary Auto-Tuning Error | The voltage or current is too large during stationary Auto-Tuning | Make sure the data entered in t1-03 to t1-05 is the same as the information showed on the motor nameplate Check and correct motor wiring |
| TnF03 | Rotational Auto-Tuning Error | The voltage or current is too large during rotational Auto-Tuning | Make sure the data entered in t1-03 to t1-05 is the same as the information showed on the motor nameplate Check and correct motor wiring Perform Auto-Tuning after disconnect the motor from the machinery |
| TnF07 | Motor Data Error | t5-05 and t1-07 setting incorrect | Make sure the data entered to t1-05 and t1-07 is the same as the information showed on the motor nameplate. Reset the parameters. |

Chapter 7 | Communications


7.1 Modbus Communication Specifications

| Item | Specifications |
|--------------------------|--------------------------|
| Interface | RS-485 |
| Communications Cycle | Asynchronous |
| Communication Parameters | Communication speeds |
| | Data length |
| | Select even, odd or none |
| | Stop bit |
| Protocol | Modbus |
| Max number of Slaves | 31 AC drives |

7.2 Connecting to Controller/PLC/HMI

7.2.1 Communication Cable Connection

1. Connect the communications cable to the drive and the controller/PLC/HMI when the power is cut off. Use the drive terminal RJ45 for Modbus communication.




Note: To prevent the interference, separate the communications cables from the main circuit cables, power cable and other wiring. Always use shielded cables for the communication cables, and shielded clamps.

2. Ensure the termination resistor is installed in the last drive of the slave series.
3. Turn the power on.
4. Set the parameters needed for the communication(E6 - 00 to E6 - 12) using the keypad.
5. Shut the power off and wait until the display goes out.
6. Turn the power on.
7. The communication between the drive and the controller/PLC/HMI is now ready.

7.2.2 Termination Resistor Setting for Multiple Connections

The default of termination resistor for RS-485 communication is OFF. Switch this DIP switch to ON when the drive is the last in a series of slave drives. In addition, make sure this DIP switch RS-485 in all other slaves is placed to OFF.



7.2.3 Termination Resistor Function

- Interference signal suppression
- impedance balance

7.2.4 When to Install Termination Resistor

Install the termination resistor in the drive on the end of the network and the master device to suppress the interference signal in the following situations. (Note: The installation must be on the both ends)

1. Multiple devices are connected by the network.
2. The communication cable is too long.
3. Multiple devices are connected via long communication cables.

7.3 Modbus Data

The following tables shows all data including command, monitor and broadcast.

- Command Data (Read and write)

| Register No. | Definitions | |
|--------------|----------------------------------|--|
| 2400H | Retain | |
| 2401H | Operation Commands | |
| | Bit 0 | Stop/Run (0:Stop, 1:Run) |
| | Bit 1 | Forward/Reverse (0:Forward, 1:Reverse) |
| | Bit 2 | External Fault EFO |
| | Bit 3 | Fault reset |
| | Bit 4 | Retain |
| | Bit 5 | Retain |
| | Bit 6 | Retain |
| | Bit 7 | Retain |
| | Bit 8 | Multi-Function Terminal 1 (1: ON) |
| | Bit 9 | Multi-Function Terminal 2 (1: ON) |
| | Bit 10 | Multi-Function Terminal 3 (1: ON) |
| | Bit 11 | Multi-Function Terminal 4 (1: ON) |
| | Bit 12 | Multi-Function Terminal 5 (1: ON) |
| | Bit 13 | Multi-Function Terminal 6 (1: ON) |
| | Bit 14 | Multi-Function Terminal 7 (1: ON) |
| Bit 15 | Retain | |
| 2402H | Frequency Command (0.01Hz Units) | |
| 2403H | Retain | |

- Monitor Data (Read Only)

| Register No. | Definitions | |
|--------------|--------------------------|------------------------------|
| 2420H | Retain | |
| 2421H | Operation Status | |
| | Bit 0 | 1: During Run |
| | Bit 1 | 1: During reverse |
| | Bit 2 | 1: During Zero Speed Holding |
| | Bit 3 | 1: During fault |
| Bit 4 | 1: During alarm detecton | |

| Register No. | Definitions | |
|--------------|--|--------------------------------------|
| | Bit 5 | 1: During speed agree |
| | Bit 6 | 1: During ready |
| | Bit 7 | 1: Frequency command provided from ? |
| | Bit 8 | 1: Run command provided from Remote |
| | Bit 9 to 15 | Retain |
| 2422H | Frequency command (0.01Hz units) | |
| 2423H | Output frequency (0.01Hz units) | |
| 2424H | Output current (0.1A units) | |
| 2425H | Output voltage (0.1V units) | |
| 2426H | DC voltage (0.1V units) | |
| 2427H | Alarm description | |
| 2428H | Fault description | |
| 2429H | Multi-Function Inputs and Outputs | |
| | Bit 0 | 1: Multi-Function Terminal 1 ON |
| | Bit 1 | 1: Multi-Function Terminal 2 ON |
| | Bit 2 | 1: Multi-Function Terminal 3 ON |
| | Bit 3 | 1: Multi-Function Terminal 4 ON |
| | Bit 4 | 1: Multi-Function Terminal 5 ON |
| | Bit 5 | 1: Multi-Function Terminal 6 ON |
| | Bit 6 | 1: Multi-Function Terminal 7 ON |
| | Bit 7 to 11 | Retain |
| | Bit 12 | 1: Relay 1 ON |
| | Bit 13 | 1: Relay 2 ON |
| | Bit 14 | 1: PH1 ON |
| | Bit 15 | Retain |
| 242AH | AI1 input (0 equals 0V or 0mA, 1000 equals 10V or 20mA) | |
| 242BH | AI2 input (0 equals 0V or 4mA, 1000 equals 10V or 20mA) | |
| 242CH | Retain | |
| 242DH | AO1 input (-1000 equals -10V, 0 equals 0V or 4mA, 1000 equals 10V or 20mA) | |
| 242EH | AO2 input (-1000 equals -10V, 0 equals 0V or 4mA, 1000 equals 10V or 20mA) | |

● Alarm Data (2427H)

| No. | Contents | No. | Contents | No. | Contents |
|-----|----------------------------------|-----|------------------------------|-----|---|
| 0 | No alarm | 13 | Retain | 26 | Ut1 (Undertorque Detection 1) |
| 1 | EF0 (Option Card External Fault) | 14 | Retain | 27 | Retain |
| 2 | EF1 (External Fault 1) | 15 | Retain | 28 | UL (Mechanical Weakening Undertorque Detection) |
| 3 | EF2 (External Fault 2) | 16 | Retain | 29 | OL (Mechanical Weakening Overtorque) |
| 4 | EF3 (External Fault 3) | 17 | Retain | 30 | Retain |
| 5 | EF4 (External Fault 4) | 18 | FbH (PID Feedback High) | 31 | BB (Output blocking) |
| 6 | EF5 (External Fault 5) | 19 | FbL (PID Feedback Low) | 32 | OH2 (Motor alarm) |
| 7 | EF6 (External Fault 6) | 20 | oH (Heatsink Overheat) | 33 | HCA (Overcurrent) |
| 8 | EF7 External Fault 7) | 21 | Retain | 34 | DNE (Invalid drive) |
| 9 | EF8 (External Fault 8) | 22 | ot1 (Overtorque Detection 1) | 35 | Retain |
| 10 | Retain | 23 | Retain | 36 | CE (MODBUS communication fail) |
| 11 | Retain | 24 | Ov (Overvoltage) | 37 | HPErr |
| 12 | Retain | 25 | Uv(Undervoltage) | 38 | ANL (Analog current input disconnection) |
| | | | | 48 | UV2 (DC power relay abnormal slow start) |

● Fault Data (2428H)

| No. | Contents | No. | Contents | No. | Contents |
|-----|--------------------------------|-----|------------------------|-----|-----------|
| 0 | No fault | 31 | Retain | 62 | opr (LCM) |
| 1 | GF (Ground Fault) | 32 | Retain | 63 | SEr |
| 2 | oVA (Acceleration Overvoltage) | 33 | oH (Heatsink Overheat) | 64 | Retain |

| No. | Contents | No. | Contents | No. | Contents |
|-----|---|-----|---|-----|-------------------------------------|
| 3 | oVd (Deceleration Overvoltage) | 34 | Retain | 65 | Retain |
| 4 | oVC (Constant Speed Overvoltage) | 35 | oL (Mechanical Weakening Overtorque Detection) | 66 | Retain |
| 5 | oVC (Acceleration Overcurrent) | 36 | oL1 (Motor Overload) | 67 | Retain |
| 6 | oCd (Deceleration Overcurrent) | 37 | oL2 (Drive Overload) | 68 | Retain |
| 7 | oCC (Constant Speed Overcurrent) | 38 | OL3 | 69 | Retain |
| 8 | EF | 39 | ot1 (Overtorque Detection 1) | 70 | Retain |
| 9 | SC (IGBT Fault or Output Short Circuit) | 40 | Retain | 71 | Retain |
| 10 | Retain | 41 | Ut1 (Undertorque Detection 1) | 72 | Retain |
| 11 | Retain | 42 | Retain | 73 | JOGER (FJOG, RJOG put in together) |
| 12 | Retain | 43 | UL (Mechanical Weakening Undertorque Detection) | 74 | -OFF- |
| 13 | Retain | 44 | Uv1(Undervoltage Detection 1) | 75 | Retain |
| 14 | Retain | 45 | Uv2 (Control Power Supply Voltage Fault) | 76 | ACE (Analog current output lines) |
| 15 | Retain | 46 | PF (Input Phase Loss) | 77 | Retain |
| 16 | Retain | 47 | LF1(Output Phase Loss) | 78 | Retain |
| 17 | EF0 (Option Card External Fault) | 48 | Retain | 79 | Retain |
| 18 | EF1 (External Fault 1) | 49 | Retain | 80 | Retain |
| 19 | EF2 (External Fault 2) | 50 | Retain | 81 | TNF00 |
| 20 | EF3 (External Fault 3) | 51 | Retain | 82 | TNF01 |
| 21 | EF4 (External Fault 4) | 52 | Retain | 83 | TNF02 |

| No. | Contents | No. | Contents | No. | Contents |
|-----|------------------------|-----|----------------------------------|-----|----------|
| 22 | EF5 (External Fault 5) | 53 | Retain | 84 | TNF03 |
| 23 | EF6 (External Fault 6) | 54 | FbH (PID Feedback High) | 85 | TNF04 |
| 24 | EF7 (External Fault 7) | 55 | FbL (PID Feedback Low) | 86 | TNF05 |
| 25 | EF8 (External Fault 8) | 56 | bUS (Option Communication Error) | 87 | TNF06 |
| 26 | Retain | 57 | CE (Modbus Communication Error) | 88 | TNF07 |
| 27 | Retain | 58 | CF (Control Fault) | 89 | TNF08 |
| 28 | Retain | 59 | Err (EEPROM Write Error) | 90 | TNF09 |
| 29 | Retain | 60 | Retain | 91 | TNF10 |
| 30 | Retain | 61 | Retain | | |

MODBUS code corresponding inverter parameters

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| A1-00 | 0x0000 | A2-00 | 0x0080 | A2-17 | 0x0091 |
| A1-01 | 0x0001 | A2-01 | 0x0081 | A2-18 | 0x0092 |
| A1-02 | 0x0002 | A2-02 | 0x0082 | A2-19 | 0x0093 |
| A1-03 | 0x0003 | A2-03 | 0x0083 | A2-20 | 0x0094 |
| A1-04 | 0x0004 | A2-04 | 0x0084 | A2-21 | 0x0095 |
| A1-05 | 0x0005 | A2-05 | 0x0085 | A2-22 | 0x0096 |
| A1-06 | 0x0006 | A2-06 | 0x0086 | A2-23 | 0x0097 |
| | | A2-07 | 0x0087 | A2-24 | 0x0098 |
| | | A2-08 | 0x0088 | A2-25 | 0x0099 |
| | | A2-09 | 0x0089 | A2-26 | 0x009A |
| | | A2-10 | 0x008A | A2-27 | 0x009B |
| | | A2-11 | 0x008B | A2-28 | 0x009C |
| | | A2-12 | 0x008C | A2-29 | 0x009D |
| | | A2-13 | 0x008D | A2-30 | 0x009E |
| | | A2-14 | 0x008E | A2-31 | 0x009F |
| | | A2-15 | 0x008F | A2-32 | 0x00A0 |
| | | A2-16 | 0x0090 | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| b1-00 | 0x0100 | b2-00 | 0x0180 | b3-00 | 0x0200 |
| b1-01 | 0x0101 | b2-01 | 0x0181 | b3-01 | 0x0201 |
| b1-02 | 0x0102 | b2-02 | 0x0182 | b3-02 | 0x0202 |
| b1-03 | 0x0103 | b2-03 | 0x0183 | b3-03 | 0x0203 |
| b1-04 | 0x0104 | b2-04 | 0x0184 | | |
| b1-05 | 0x0105 | | | b4-00 | 0x0280 |
| b1-06 | 0x0106 | | | b4-01 | 0x0281 |
| b1-07 | 0x0107 | | | | |
| b1-08 | 0x0108 | | | | |
| b1-09 | 0x0109 | | | | |
| b1-10 | 0x010A | | | | |
| b1-11 | 0x010B | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| b5-00 | 0x0300 | b5-21 | 0x0315 | b6-00 | 0x0380 |
| b5-01 | 0x0301 | b5-22 | 0x0316 | b6-01 | 0x0381 |
| b5-02 | 0x0302 | b5-23 | 0x0317 | b6-02 | 0x0382 |
| b5-03 | 0x0303 | b5-24 | 0x0318 | b6-03 | 0x0383 |
| b5-04 | 0x0304 | b5-25 | 0x0319 | | |
| b5-05 | 0x0305 | b5-26 | 0x031A | | |
| b5-06 | 0x0306 | b5-27 | 0x031B | | |
| b5-07 | 0x0307 | b5-28 | 0x031C | | |
| b5-08 | 0x0308 | b5-29 | 0x031D | | |
| b5-09 | 0x0309 | b5-30 | 0x031E | | |
| b5-10 | 0x030A | | | | |
| b5-11 | 0x030B | | | | |
| b5-12 | 0x030C | | | | |
| b5-13 | 0x030D | | | | |
| b5-14 | 0x030E | | | | |
| b5-15 | 0x030F | | | | |
| b5-16 | 0x0310 | | | | |
| b5-17 | 0x0311 | | | | |
| b5-18 | 0x0312 | | | | |
| b5-19 | 0x0313 | | | | |
| b5-20 | 0x0314 | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| C1-00 | 0x0580 | C2-00 | 0x0600 | C5-00 | 0x0780 |
| C1-01 | 0x0581 | C2-01 | 0x0601 | C5-01 | 0x0781 |
| C1-02 | 0x0582 | C2-02 | 0x0602 | C5-02 | 0x0782 |
| C1-03 | 0x0583 | C2-03 | 0x0603 | | |
| C1-04 | 0x0584 | | | | |
| C1-05 | 0x0585 | C3-00 | 0x0680 | C6-00 | 0x0800 |
| C1-06 | 0x0586 | C3-01 | 0x0681 | C6-01 | 0x0801 |
| C1-07 | 0x0587 | C3-02 | 0x0682 | C6-02 | 0x0802 |
| C1-08 | 0x0588 | C3-03 | 0x0683 | C6-03 | 0x0803 |
| C1-09 | 0x0589 | C3-04 | 0x0684 | | |
| C1-10 | 0x058A | C3-05 | 0x0685 | C7-00 | 0x2480 |
| C1-11 | 0x058B | C3-06 | 0x0686 | | |
| C1-12 | 0x058C | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| L1-00 | 0x0880 | L1-13 | 0x088D | L4-00 | 0x0A00 |
| L1-01 | 0x0881 | L1-14 | 0x088E | L4-01 | 0x0A01 |
| L1-02 | 0x0882 | L1-15 | 0x088F | L4-02 | 0x0A02 |
| L1-03 | 0x0883 | L1-16 | 0x0890 | L4-03 | 0x0A03 |
| L1-04 | 0x0884 | | | L4-04 | 0x0A04 |
| L1-05 | 0x0885 | L2-00 | 0x0900 | | |
| L1-06 | 0x0886 | L2-01 | 0x0901 | L6-00 | 0x0B00 |
| L1-07 | 0x0887 | | | L6-01 | 0x0B01 |
| L1-08 | 0x0888 | L3-00 | 0x0980 | L6-02 | 0x0B02 |
| L1-09 | 0x0889 | L3-01 | 0x0981 | | |
| L1-10 | 0x088A | L3-02 | 0x0982 | | |
| L1-11 | 0x088B | L3-03 | 0x0983 | | |
| L1-12 | 0x088C | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| L7-00 | 0x2380 | L7-11 | 0x238B | L7-22 | 0x2396 |
| L7-01 | 0x2381 | L7-12 | 0x238C | L7-23 | 0x2397 |
| L7-02 | 0x2382 | L7-13 | 0x238D | L7-24 | 0x2398 |
| L7-03 | 0x2383 | L7-14 | 0x238E | L7-25 | 0x2399 |
| L7-04 | 0x2384 | L7-15 | 0x238F | L7-26 | 0x239A |
| L7-05 | 0x2385 | L7-16 | 0x2390 | L7-27 | 0x239B |
| L7-06 | 0x2386 | L7-17 | 0x2391 | L7-28 | 0x239C |
| L7-07 | 0x2387 | L7-18 | 0x2392 | L7-29 | 0x239D |
| L7-08 | 0x2388 | L7-19 | 0x2393 | L7-30 | 0x239E |
| L7-09 | 0x2389 | L7-20 | 0x2394 | L7-31 | 0x239F |
| L7-10 | 0x238A | L7-21 | 0x2395 | L7-32 | 0x23A0 |
| | | | | L7-33 | 0x23A1 |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| d1-00 | 0x0B80 | d1-23 | 0x0B97 | d2-00 | 0x0C00 |
| d1-01 | 0x0B81 | d1-24 | 0x0B98 | d2-01 | 0x0C01 |
| d1-02 | 0x0B82 | d1-25 | 0x0B99 | d2-02 | 0x0C02 |
| d1-03 | 0x0B83 | d1-26 | 0x0B9A | d2-03 | 0x0C03 |
| d1-04 | 0x0B84 | d1-27 | 0x0B9B | d2-04 | 0x0C04 |
| d1-05 | 0x0B85 | d1-28 | 0x0B9C | d2-05 | 0x0C05 |
| d1-06 | 0x0B86 | | | d2-06 | 0x0C06 |
| d1-07 | 0x0B87 | | | d2-07 | 0x0C07 |
| d1-08 | 0x0B88 | | | d2-10 | 0x0C0A |
| d1-09 | 0x0B89 | | | | |
| d1-10 | 0x0B8A | | | | |
| d1-11 | 0x0B8B | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| E1-00 | 0x0D00 | E2-00 | 0x0D80 | E3-00 | 0x0E00 |
| E1-01 | 0x0D01 | E2-01 | 0x0D81 | E3-01 | 0x0E01 |
| E1-02 | 0x0D02 | E2-02 | 0x0D82 | E3-02 | 0x0E02 |
| E1-03 | 0x0D03 | E2-03 | 0x0D83 | E3-03 | 0x0E03 |
| E1-04 | 0x0D04 | E2-05 | 0x0D85 | E3-05 | 0x0E05 |
| E1-05 | 0x0D05 | E2-06 | 0x0D86 | E3-06 | 0x0E06 |
| E1-06 | 0x0D06 | E2-07 | 0x0D87 | E3-07 | 0x0E07 |
| E1-07 | 0x0D07 | E2-08 | 0x0D88 | E3-08 | 0x0E08 |
| | | E2-09 | 0x0D89 | E3-09 | 0x0E09 |
| | | | | E3-10 | 0x0E0A |
| | | | | E3-11 | 0x0E0B |
| | | | | E3-12 | 0x0E0C |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| E4-00 | 0x0E80 | E5-00 | 0x0F00 | E6-00 | 0x0F80 |
| E4-01 | 0x0E81 | E5-01 | 0x0F01 | E6-01 | 0x0F81 |
| E4-02 | 0x0E82 | E5-02 | 0x0F02 | E6-02 | 0x0F82 |
| E4-03 | 0x0E83 | E5-03 | 0x0F03 | E6-03 | 0x0F83 |
| E4-04 | 0x0E84 | E5-04 | 0x0F04 | E6-04 | 0x0F84 |
| E4-05 | 0x0E85 | E5-05 | 0x0F05 | E6-05 | 0x0F85 |
| E4-06 | 0x0E86 | E5-06 | 0x0F06 | E6-06 | 0x0F86 |
| E4-07 | 0x0E87 | E5-07 | 0x0F07 | E6-07 | 0x0F87 |
| | | E5-08 | 0x0F08 | E6-08 | 0x0F88 |
| | | E5-09 | 0x0F09 | E6-09 | 0x0F89 |
| | | E5-10 | 0x0FOA | E6-10 | 0x0F8A |
| | | | | E6-11 | 0x0F8B |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| P1-00 | 0x1000 | P2-00 | 0x1080 | P3-00 | 0x1100 |
| P1-01 | 0x1001 | P2-01 | 0x1081 | P3-01 | 0x1101 |
| P1-03 | 0x1003 | P2-03 | 0x1083 | P3-02 | 0x1102 |
| P1-04 | 0x1004 | P2-04 | 0x1084 | P3-03 | 0x1103 |
| P1-05 | 0x1005 | P2-05 | 0x1085 | P3-04 | 0x1104 |
| | | P2-06 | 0x1086 | P3-05 | 0x1105 |
| | | P2-07 | 0x1087 | P3-06 | 0x1106 |
| | | P2-08 | 0x1088 | P3-07 | 0x1107 |
| | | P2-09 | 0x1089 | P3-08 | 0x1108 |
| | | P2-10 | 0x108A | P3-09 | 0x1109 |
| | | P2-11 | 0x108B | P3-10 | 0x110A |
| | | | | P3-11 | 0x110B |
| | | | | P3-12 | 0x110C |
| | | | | P3-13 | 0x110D |
| | | | | P3-14 | 0x110E |
| | | | | P3-15 | 0x110F |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| P4-00 | 0x1180 | P5-00 | 0x1200 | P6-00 | 0x1280 |
| P4-01 | 0x1181 | P5-01 | 0x1201 | P6-01 | 0x1281 |
| P4-02 | 0x1182 | P5-02 | 0x1202 | P6-02 | 0x1282 |
| P4-03 | 0x1183 | | | P6-07 | 0x1287 |
| P4-04 | 0x1184 | | | P6-08 | 0x1288 |
| P4-05 | 0x1185 | | | P6-09 | 0x1289 |
| P4-06 | 0x1186 | | | P6-10 | 0x128A |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| P7-00 | 0x1300 | n1-00 | 0x1380 | n2-00 | 0x1400 |
| P7-01 | 0x1301 | n1-01 | 0x1381 | n2-01 | 0x1401 |
| P7-02 | 0x1302 | n1-02 | 0x1382 | n2-02 | 0x1402 |
| P7-03 | 0x1303 | n1-03 | 0x1383 | | |
| P7-04 | 0x1304 | | | | |
| P7-05 | 0x1305 | | | | |
| P7-06 | 0x1306 | | | | |
| P7-07 | 0x1307 | | | | |
| P7-09 | 0x1309 | | | | |
| P7-10 | 0x130A | | | | |
| P7-11 | 0x130B | | | | |
| P7-12 | 0x130C | | | | |
| P7-13 | 0x130D | | | | |
| P7-14 | 0x130E | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| o1-00 | 0x1680 | o2-00 | 0x1700 | o3-00 | 0x1780 |
| o1-01 | 0x1681 | o2-01 | 0x1701 | o3-01 | 0x1781 |
| o1-02 | 0x1682 | o2-03 | 0x1703 | o4-00 | 0x1800 |
| o1-03 | 0x1683 | o2-04 | 0x1704 | o4-01 | 0x1801 |
| | | o2-05 | 0x1705 | o4-02 | 0x1802 |
| | | o2-06 | 0x1706 | o4-06 | 0x1806 |
| | | | | o4-07 | 0x1807 |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|------|-----------|------|
| t1-01 | 0x1881 | | | | |
| t1-02 | 0x1882 | | | | |
| t1-03 | 0x1883 | | | | |
| t1-04 | 0x1884 | | | | |
| t1-05 | 0x1885 | | | | |
| t1-06 | 0x1886 | | | | |
| t1-07 | 0x1887 | | | | |
| t1-09 | 0x1889 | | | | |
| t1-12 | 0x188C | | | | |

| parameter | code | parameter | code | parameter | code |
|-----------|--------|-----------|--------|-----------|--------|
| U1-00 | 0x1D00 | U2-00 | 0x1D80 | U3-00 | 0x1E00 |
| U1-01 | 0x1D01 | U2-01 | 0x1D81 | U3-01 | 0x1E01 |
| U1-02 | 0x1D02 | U2-02 | 0x1D82 | U3-06 | 0x1E06 |
| U1-03 | 0x1D03 | U2-03 | 0x1D83 | U3-07 | 0x1E07 |
| U1-04 | 0x1D04 | U2-04 | 0x1D84 | U3-08 | 0x1E08 |
| U1-05 | 0x1D05 | U2-05 | 0x1D85 | U3-09 | 0x1E09 |
| U1-06 | 0x1D06 | U2-06 | 0x1D86 | U3-10 | 0x1E0A |
| U1-07 | 0x1D07 | U2-07 | 0x1D87 | U3-11 | 0x1E0B |
| U1-09 | 0x1D09 | U2-08 | 0x1D88 | U3-12 | 0x1E0C |
| U1-10 | 0x1D0A | U2-09 | 0x1D89 | U3-13 | 0x1E0D |
| U1-11 | 0x1D0B | U2-10 | 0x1D8A | U3-14 | 0x1E0E |
| U1-12 | 0x1D0C | U2-11 | 0x1D8B | U3-15 | 0x1E0F |
| U1-13 | 0x1D0D | U2-13 | 0x1D8D | U3-17 | 0x1E11 |
| U1-14 | 0x1D0E | U2-14 | 0x1D8E | U3-18 | 0x1E12 |
| U1-15 | 0x1D0F | U2-15 | 0x1D8F | | |
| U1-16 | 0x1D10 | U2-16 | 0x1D90 | U4-00 | 0x1E80 |
| | | U2-17 | 0x1D91 | U4-01 | 0x1E81 |
| | | U2-19 | 0x1D93 | U4-02 | 0x1E82 |
| | | U2-20 | 0x1D94 | U4-03 | 0x1E83 |
| | | U2-21 | 0x1D95 | U4-04 | 0x1E84 |
| | | U2-22 | 0x1D96 | U4-05 | 0x1E85 |
| | | U2-23 | 0x1D97 | U4-06 | 0x1E86 |
| | | U2-24 | 0x1D98 | U4-08 | 0x1E88 |
| | | U2-25 | 0x1D99 | | |
| | | U2-27 | 0x1D9B | | |
| | | U2-28 | 0x1D9C | | |
| | | U2-29 | 0x1D9D | | |
| | | U2-30 | 0x1D9E | | |
| | | U2-31 | 0x1D9F | | |
| | | U2-33 | 0x1DA1 | | |
| | | U2-34 | 0x1DA2 | | |
| | | U2-35 | 0x1DA3 | | |
| | | U2-36 | 0x1DA4 | | |
| | | U2-37 | 0x1DA5 | | |

| Edit Date Parameter | | | Edit Date Parameter | | |
|--------------------------------------|--|--|--------------------------------------|--|--|
| A1-00 | | | b1-00 | | |
| A1-01 | | | b1-01 | | |
| A1-02 | | | b1-02 | | |
| A1-03 | | | b1-03 | | |
| A1-04 | | | b1-04 | | |
| A1-05 | | | b1-05 | | |
| A1-06 | | | b1-06 | | |
| A2-00 | | | b1-07 | | |
| A2-01 | | | b1-08 | | |
| A2-02 | | | b1-09 | | |
| A2-03 | | | b1-10 | | |
| A2-04 | | | b2-00 | | |
| A2-05 | | | b2-01 | | |
| A2-06 | | | b2-02 | | |
| A2-07 | | | b2-03 | | |
| A2-08 | | | b2-04 | | |
| A2-09 | | | b3-00 | | |
| A2-10 | | | b3-01 | | |
| A2-11 | | | b3-02 | | |
| A2-12 | | | b3-03 | | |
| A2-13 | | | b3-04 | | |
| A2-14 | | | b3-05 | | |
| A2-15 | | | b4-00 | | |
| A2-16 | | | b4-01 | | |
| A2-17 | | | b5-00 | | |
| A2-18 | | | b5-01 | | |
| A2-19 | | | b5-02 | | |
| A2-20 | | | b5-03 | | |
| A2-21 | | | b5-04 | | |
| A2-22 | | | b5-05 | | |
| A2-23 | | | b5-06 | | |
| A2-24 | | | b5-07 | | |
| A2-25 | | | b5-08 | | |
| A2-26 | | | b5-09 | | |
| A2-27 | | | b5-10 | | |
| A2-28 | | | b5-11 | | |
| A2-29 | | | b5-12 | | |
| A2-30 | | | b5-13 | | |
| A2-31 | | | b5-14 | | |
| A2-32 | | | b5-15 | | |

| Edit Date Parameter | | | Edit Date Parameter | | |
|--------------------------------------|--|--|--------------------------------------|--|--|
| b5-16 | | | C4-01 | | |
| b5-17 | | | C4-02 | | |
| b5-18 | | | C4-03 | | |
| b5-19 | | | C4-04 | | |
| b5-20 | | | C4-05 | | |
| b5-21 | | | C4-06 | | |
| b5-22 | | | C4-07 | | |
| b5-23 | | | C4-08 | | |
| b5-24 | | | C4-09 | | |
| b5-25 | | | C4-10 | | |
| b5-26 | | | C4-11 | | |
| b5-27 | | | C4-12 | | |
| b5-28 | | | C4-13 | | |
| b6-00 | | | C4-14 | | |
| b6-01 | | | C4-15 | | |
| b6-02 | | | C4-16 | | |
| b6-03 | | | C4-17 | | |
| C1-00 | | | C4-18 | | |
| C1-01 | | | C4-19 | | |
| C1-02 | | | C4-20 | | |
| C1-03 | | | C4-21 | | |
| C1-04 | | | C5-00 | | |
| C1-05 | | | C5-01 | | |
| C1-06 | | | C5-02 | | |
| C1-07 | | | C5-03 | | |
| C1-08 | | | C5-04 | | |
| C1-09 | | | C5-05 | | |
| C1-10 | | | C5-06 | | |
| C2-00 | | | C5-07 | | |
| C2-01 | | | C5-08 | | |
| C2-02 | | | C5-09 | | |
| C2-03 | | | C5-10 | | |
| C3-00 | | | C6-00 | | |
| C3-01 | | | C6-01 | | |
| C3-02 | | | C6-02 | | |
| C3-03 | | | C6-03 | | |
| C3-04 | | | C6-04 | | |
| C3-05 | | | L1-00 | | |
| C3-06 | | | L1-01 | | |
| C4-00 | | | L1-02 | | |

| Edit Date Parameter | | | Edit Date Parameter | | |
|--------------------------------------|--|--|--------------------------------------|--|--|
| d3-08 | | | E5-03 | | |
| d3-09 | | | E5-04 | | |
| E1-00 | | | E5-05 | | |
| E1-01 | | | E5-06 | | |
| E1-02 | | | E5-07 | | |
| E1-03 | | | E6-00 | | |
| E1-04 | | | E6-01 | | |
| E1-05 | | | E6-02 | | |
| E1-06 | | | E6-03 | | |
| E1-07 | | | E6-04 | | |
| E2-00 | | | E6-05 | | |
| E2-01 | | | E6-06 | | |
| E2-02 | | | E6-07 | | |
| E2-03 | | | E6-08 | | |
| E2-04 | | | E6-09 | | |
| E2-05 | | | E6-10 | | |
| E3-00 | | | E6-11 | | |
| E3-01 | | | P1-00 | | |
| E3-02 | | | P1-01 | | |
| E3-03 | | | P1-02 | | |
| E3-04 | | | P1-03 | | |
| E3-05 | | | P1-04 | | |
| E3-06 | | | P1-05 | | |
| E3-07 | | | P2-00 | | |
| E3-08 | | | P2-01 | | |
| E3-09 | | | P2-02 | | |
| E3-10 | | | P2-03 | | |
| E3-11 | | | P2-04 | | |
| E3-12 | | | P2-05 | | |
| E4-00 | | | P2-06 | | |
| E4-01 | | | P2-07 | | |
| E4-02 | | | P2-08 | | |
| E4-03 | | | P2-09 | | |
| E4-04 | | | P2-10 | | |
| E4-05 | | | P3-00 | | |
| E4-06 | | | P3-01 | | |
| E4-07 | | | P3-02 | | |
| E5-00 | | | P3-03 | | |
| E5-01 | | | P3-04 | | |
| E5-02 | | | P3-05 | | |


| Edit Date Parameter | | | Edit Date Parameter | | |
|--------------------------------------|--|--|--------------------------------------|--|--|
| P3-06 | | | P7-06 | | |
| P3-07 | | | P7-07 | | |
| P3-08 | | | P7-08 | | |
| P3-09 | | | P7-09 | | |
| P3-10 | | | P7-10 | | |
| P3-11 | | | P7-11 | | |
| P3-12 | | | P7-12 | | |
| P3-13 | | | P7-13 | | |
| P3-14 | | | n1-00 | | |
| P3-15 | | | n1-01 | | |
| P3-16 | | | n1-02 | | |
| P4-00 | | | n1-03 | | |
| P4-01 | | | n6-00 | | |
| P4-02 | | | n6-01 | | |
| P4-03 | | | n6-02 | | |
| P5-00 | | | n6-03 | | |
| P5-01 | | | n6-04 | | |
| P5-02 | | | n6-05 | | |
| P6-00 | | | n6-06 | | |
| P6-01 | | | n6-07 | | |
| P6-02 | | | n6-08 | | |
| P6-03 | | | n6-09 | | |
| P6-04 | | | n6-10 | | |
| P6-05 | | | n6-11 | | |
| P6-06 | | | n6-12 | | |
| P6-07 | | | o2-00 | | |
| P6-08 | | | o2-01 | | |
| P6-09 | | | o2-02 | | |
| P6-10 | | | o2-03 | | |
| P6-11 | | | o2-04 | | |
| P6-12 | | | o2-05 | | |
| P6-13 | | | o2-06 | | |
| P6-14 | | | o4-00 | | |
| P6-15 | | | o4-01 | | |
| P7-00 | | | o4-02 | | |
| P7-01 | | | o4-03 | | |
| P7-02 | | | o4-04 | | |
| P7-03 | | | o4-05 | | |
| P7-04 | | | o4-06 | | |
| P7-05 | | | o4-07 | | |

| Edit Date Parameter | | | Edit Date Parameter | | |
|--------------------------------------|--|--|--------------------------------------|--|--|
| o4-08 | | | F1-10 | | |
| t1-00 | | | F1-11 | | |
| t1-01 | | | F1-12 | | |
| t1-02 | | | F1-13 | | |
| t1-03 | | | F1-14 | | |
| t1-04 | | | F1-15 | | |
| t1-05 | | | F1-16 | | |
| t1-06 | | | F1-17 | | |
| t1-07 | | | F1-18 | | |
| t1-08 | | | | | |
| t1-09 | | | | | |
| t1-10 | | | | | |
| t1-11 | | | | | |
| t1-12 | | | | | |
| t2-00 | | | | | |
| t2-02 | | | | | |
| t2-03 | | | | | |
| t2-04 | | | | | |
| t2-05 | | | | | |
| t2-06 | | | | | |
| t2-07 | | | | | |
| t2-08 | | | | | |
| t2-09 | | | | | |
| t2-10 | | | | | |
| t2-11 | | | | | |
| t2-12 | | | | | |
| t2-13 | | | | | |
| t2-14 | | | | | |
| t2-15 | | | | | |
| t2-16 | | | | | |
| t2-17 | | | | | |
| F1-00 | | | | | |
| F1-01 | | | | | |
| F1-02 | | | | | |
| F1-03 | | | | | |
| F1-04 | | | | | |
| F1-06 | | | | | |
| F1-07 | | | | | |
| F1-08 | | | | | |
| F1-09 | | | | | |

Notes :

ALL INDIA SERVICE NETWORK

- Regional Offices
- 🏭 Works
- ✂ Service Centre: Drives
- ✂ Service Centre: Servo Motors



BB ServiceLINE™
Customer Service Helpdesk for Industrial Systems

+91 22 - 2763 7290 | serviceline@bharatbijlee.com



Bharat Bijlee Drives & Automation

Mobile App for Troubleshooting and Maintenance of Drives & Servo Motors

Download for free from Google Play Store

B Bharat Bijlee

REGISTERED OFFICE

Electric Mansion, 6th Floor,
Appasaheb Marathe Marg,
Prabhadevi, Mumbai 400 025
T: +91 22 2430 6237 / 6375
E: info@bharatbijlee.com
CIN: L31300MH1946PLC005017

WORKS

No. 2, MIDC Thane-Belapur Road, Airoli,
Navi Mumbai 400 708
T: +91 22 2763 7200 / +91 22 2760 0401
E: drivesales@bharatbijlee.com

www.bharatbijlee.com